

BASIC USER'S GUIDE



MFC-9970CDW

Version B

USA/CAN

If you need to call Customer Service

Please complete the following information for future reference:

Model Number: MFC-9970CDW

Serial Number:

Date of Purchase:

Place of Purchase:

1 The serial number is on the back of the unit. Retain this User's Guide with your sales receipt as a permanent record of your purchase, in the event of theft, fire or warranty service.

Register your product on-line at

http://www.brother.com/registration/

By registering your product with Brother, you will be recorded as the original owner of the product. Your registration with Brother:

- may serve as confirmation of the purchase date of your product should you lose your receipt;
- may support an insurance claim by you in the event of product loss covered by insurance; and,
- will help us notify you of enhancements to your product and special offers.

The most convenient and efficient way to register your new product is online at http://www.brother.com/registration/.

Brother numbers

!MPORTANT

For technical help, you must call the country where you bought the machine. Calls must be made *from within* that country.

Register your product

By registering your product with Brother International Corporation, you will be recorded as the original owner of the product. Your registration with Brother:

- may serve as confirmation of the purchase date of your product should you lose your receipt;
- may support an insurance claim by you in the event of product loss covered by insurance; and,
- will help us notify you of enhancements to your product and special offers.

Please complete and fax the Brother Warranty Registration and Test Sheet or, for your convenience and most efficient way to register your new product, register on-line at

http://www.brother.com/registration/

FAQs (frequently asked questions)

The Brother Solutions Center is our one-stop resource for all your Fax Machine/Multi-Function Center needs. You can download the latest software and utilities and read FAQs and troubleshooting tips to learn how to get the most from your Brother product.

http://solutions.brother.com/



You can check here for Brother driver updates.

To keep your machine's performance up to date, check here for the latest firmware upgrade.

For Customer Service

In USA: 1-877-BROTHER (1-877-276-8437)

1-901-379-1215 (fax)

In Canada: 1-877-BROTHER

(514) 685-4898 (fax)

Service Center Locator (USA only)

For the location of a Brother authorized service center, call 1-877-BROTHER (1-877-276-8437) or visit us on-line at http://www.brother-usa.com/service/.

Service Center Locations (Canada only)

For the location of a Brother authorized service center, call 1-877-BROTHER.

i

Ordering accessories and supplies

For best quality results use only genuine Brother accessories, which are available at most Brother retailers. If you cannot find the accessory you need and you have a Visa, MasterCard, Discover, or American Express credit card, you can order accessories directly from Brother. (You can visit us online for a complete selection of the Brother accessories and supplies that are available for purchase.)



In Canada, only Visa and MasterCard are accepted.

In USA: 1-877-552-MALL (1-877-552-6255)

1-800-947-1445 (fax)

http://www.brothermall.com/

In Canada: 1-877-BROTHER

http://www.brother.ca/

Description	Item	
Toner Cartridge <black></black>	TN-310BK (Approx. 2,500 pages) ^{1 2 3}	
Toner Gartinage Ablack	TN-315BK (Approx. 6,000 pages) ^{1 2 4}	
Toner Cartridge <cyan></cyan>	TN-310C (Approx. 1,500 pages) ^{1 2 3}	
Toner Cartiluge Cyanz	TN-315C (Approx. 3,500 pages) ^{1 2 4}	
Toner Cartridge <magenta></magenta>	TN-310M (Approx. 1,500 pages) ^{1 2 3}	
	TN-315M (Approx. 3,500 pages) ¹²⁴	
Toner Cartridge <yellow></yellow>	TN-310Y (Approx. 1,500 pages) ^{1 2 3}	
Toner Cartriage Tellows	TN-315Y (Approx. 3,500 pages) ^{1 2 4}	
Drum Unit	DR-310CL (Approx. 25,000 pages) ^{5 6}	
Waste Toner Box	WT-300CL (Approx. 50,000 pages) ¹	

Description	Item	
Belt Unit	BU-300CL (Approx. 50,000 pages) ¹	
Telephone Line Cord	LG3077001	
Paper Tray #2 (Option)	LT-300CL	
Basic User's Guide	LX4383001 (English for USA and Canada)	
	LX4383002 (French for Canada)	
Quick Setup Guide	LX4864001 (English for USA and Canada)	
	LX4385002 (French for Canada)	

¹ Letter or A4 size single-sided pages.

 $^{^{2}\,\,}$ Approx. cartridge yield is declared in accordance with ISO/IEC 19798.

³ Standard toner cartridge

⁴ High capacity toner cartridge

⁵ 1 page per job.

 $^{^{\}rm 6}$ $\,$ Drum life is approximate and may vary by type of use.

Notice - Disclaimer of Warranties (USA and Canada)

BROTHER'S LICENSOR(S), AND THEIR DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS (COLLECTIVELY BROTHER'S LICENSOR) MAKE NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, REGARDING THE SOFTWARE. BROTHER'S LICENSOR(S) DOES NOT WARRANT, GUARANTEE OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY, CURRENTNESS OR OTHERWISE. THE ENTIRE RISK AS TO THE RESULTS AND PERFORMANCE OF THE SOFTWARE IS ASSUMED BY YOU. THE EXCLUSION OF IMPLIED WARRANTIES IS NOT PERMITTED BY SOME STATES IN THE USA AND SOME PROVINCES IN CANADA. THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

IN NO EVENT WILL BROTHER'S LICENSOR(S) BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL OR INDIRECT DAMAGES (INCLUDING DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, AND THE LIKE) ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE EVEN IF BROTHER'S LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES IN THE USA AND SOME PROVINCES IN CANADA DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. IN ANY EVENT BROTHER'S LICENSOR'S LIABILITY TO YOU FOR ACTUAL DAMAGES FROM ANY CAUSE WHATSOEVER, AND REGARDLESS OF THE FORM OF THE ACTION (WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY OR OTHERWISE), WILL BE LIMITED TO \$50.

Compilation and Publication Notice

Under the supervision of Brother Industries Ltd., this manual has been compiled and published, covering the latest product descriptions and specifications.

The contents of this manual and the specifications of this product are subject to change without notice.

Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.

Brother™ Color Laser One-Year On-Site Limited Warranty (USA only)

Who is covered:

- This limited warranty ("warranty") is given only to the original end-user/retail purchaser (referred to in this warranty as "Original Purchaser") of the accompanying product, consumables and accessories (collectively referred to in this warranty as "this Product").
- If you purchased a product from someone other than an authorized Brother reseller in the United States or if the product was used (including but not limited to floor models or refurbished product by someone other than Brother), prior to your purchase you are not the Original Purchaser and the product that you purchased is not covered by this warranty.

What is covered:

- This Product includes a Machine and Consumable and Accessory Items. Consumable and Accessory Items include but are not limited to Toner Cartridges, Drum Units, Belt Unit, and Waste Toner Box.
- Except as otherwise provided herein, Brother warrants that the Machine and the accompanying Consumable and Accessory Items will be free from defects in materials and workmanship, when used under normal conditions.
- This warranty applies only to products purchased and used in the United States. For products purchased in, but used outside, the United States, this warranty covers only warranty service within the United States (and does not include shipping outside the United States).

What is the length of the Warranty Periods:

- Machines: one year from the original purchase date.
- Accompanying Consumable and Accessory Items: 90 days from the original purchase date or the rated life of consumable, whichever comes first.

What is NOT covered:

This warranty does not cover:

- Physical damage to this Product;
- 2 Damage caused by improper installation, improper or abnormal use, misuse, neglect or accident (including but not limited to transporting this Product without the proper preparation and/or packaging);
- 3 Damage caused by another device or software used with this Product (including but not limited to damage resulting from use of non Brother™-brand parts and Consumable and Accessory Items);
- 4 Consumable and Accessory Items that expired in accordance with a rated life;
- 5 Problems arising from other than defects in materials or workmanship; and,
- 6 Normal Periodic Maintenance Items, such as Paper Feeding Kit, Fuser and Laser Units.

This limited warranty is VOID if this Product has been altered or modified in any way (including but not limited to attempted warranty repair without authorization from Brother and/or alteration/removal of the serial number).

What to do if you think your Product is eligible for warranty service:

Report your issue to our Customer Service Hotline at 1-877-BROTHER (1-877-276-8437) or to a Brother Authorized Service Center **within the applicable warranty period**. Supply Brother or the Brother Authorized Service Center with a copy of your dated bill of sale showing that this Product was purchased within the U.S. For the name of local Brother Authorized Service Center(s), call 1-877-BROTHER (1-877-276-8437) or visit www.brother-usa.com.

What Brother will ask you to do:

After contacting Brother or a Brother Authorized Service Center, you may be required to provide information pertaining to the defect or malfunction of this Product.

Brother™ Color Laser One-Year On-Site Limited Warranty (USA only)

What Brother will do:

If the problem reported concerning your Machine and/or accompanying Consumable and Accessory Items is covered by this warranty and if you first reported the problem to Brother or an Authorized Service Center within the applicable warranty period, Brother or its Authorized Service Center will evaluate your report of a possible defect to determine whether a defect exists, and if it does exist, Brother or an Authorized Service Center will provide "On-site Warranty Service" during "Normal Working Hours" and will repair the Machine and/or accompanying Consumable and Accessory Items at no charge to you for parts or labor. "On-site Warranty Service" shall consist of the remedial service, as necessitated by normal usage, to restore this product to good operating condition at your location and does not guarantee uninterrupted operation of this Product, "Normal Working Hours" shall mean 9:00am to 5:00pm (local time), Monday through Friday, excluding legal and local holidays observed by Brother or the Authorized Service Center.

If the Machine and/or accompanying Consumable and Accessory Items are not covered by this warranty, you will be charged for any service and/or replacement parts/products at Brother's or the Authorized Service Center's then current published rates.

The foregoing are your sole (i.e., only) and exclusive remedies under this warranty.

What you must provide:

Reasonable cooperation with the Brother Representative in troubleshooting as they diagnose the problem, provide access to this Product at reasonable times and provide adequate working space including heat, light, ventilation, electric current and outlets for the use of the Brother representative.

Limitations:

Brother is not responsible for damage to or loss of any equipment, media, programs or data related to the use of this Product.

Except for the repair as described above,
Brother shall not be liable for any direct, indirect, incidental or consequential damages or specific relief. Because some states do not allow the exclusion or limitation of consequential or incidental damages, the above limitation may not apply to you.

THIS WARRANTY IS GIVEN IN LIEU OF ALL OTHER WARRANTIES, WRITTEN OR ORAL, WHETHER EXPRESSED BY AFFIRMATION, PROMISE, DESCRIPTION, DRAWING, MODEL OR SAMPLE. ANY AND ALL WARRANTIES OTHER THAN THIS ONE, WHETHER EXPRESS OR IMPLIED, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED.

- This Limited Warranty is the only warranty that Brother is giving for this Product. It is the *final expression and the exclusive and only statement* of Brother's obligations to you. It replaces all other agreements and understandings that you may have with Brother or its representatives.
- This warranty gives you certain rights and you may also have other rights that may vary from state to state.
- This Limited Warranty (and Brother's obligation to you) may not be changed in any way unless you and Brother sign the same piece of paper in which we (1) refer to this Product and your bill of sale date, (2) describe the change to this warranty and (3) agree to make that change.

BROTHER LASER PRINTER / MULTIFUNCTION CENTER® / FAX ON-SITE LIMITED WARRANTY (Canada Only)

For a limited on-site warranty of 1 year labour and parts from the date of purchase, Brother International Corporation (Canada) Ltd. ("Brother"), or its authorized on-site service providers, will repair or replace (at Brother's sole discretion) this Laser Printer/MFC/Fax machine free of charge if defective in material or workmanship.

This warranty applies only to products purchased and used in Canada. This limited Warranty does not include cleaning, consumables (including, without limitation, toner cartridges and drum units, OPC belts, fixing units, print heads, paper feed rollers, transfer rolls, cleaning rollers, waste toner packs, oil bottles) or damage caused by accident, neglect, misuse or improper installation or operation or any damage caused from service, maintenance, modifications, or tampering by anyone other than a Brother Authorized Service Representative, or if shipped out of the country. Damage caused by the use of non-Brother toner is not covered under this warranty. This limited warranty ceases when this machine is rented, sold, or otherwise disposed of. Operation of the laser printer/MFC/Fax in excess of the specifications or with the Serial Number or Rating Label removed shall be deemed abuse and all repairs thereafter shall be the sole liability of the end-user/purchaser. The Laser Printer/MFC/Fax machine will be serviced on-site. Canadian Proof of Purchase in the form of a Sales Receipt must be provided if requested by the service personnel. In the event that geographical location does not permit us to provide on-site service to you, Brother reserves the right to exchange your machine with an equivalent or better one through a courier service.

When shipping or transporting your Laser Printer/MFC/Fax machine, please refer to your Operation Manual for the proper packaging procedures. Failure to remove the Toner Cartridge (and Toner Drum Unit, waste toner packs or oil bottles on applicable models) during shipping or transport will cause severe damage to the Laser Printer/MFC/Fax machine and will void the Warranty. Improper packaging may cause severe damage to the machine during shipping and will void the warranty.

BROTHER DISCLAIMS ALL OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING, WITHOUT LIMITATIONS, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FOR A PARTICULAR PURPOSE, EXCEPT TO THE EXTENT THAT ANY WARRANTIES IMPLIED BY LAW CANNOT BE VALIDLY WAIVED.

No oral or written information, advice or representation provided by Brother, its Authorized Service Centres, Distributors, Dealers, Agents or employees, shall create another warranty or modify this warranty. The warranty states Brother's entire liability and your exclusive remedy against Brother for any failure of the Laser Printer/MFC/Fax machine to operate properly. Neither Brother nor anyone else involved in the development, production, or delivery of this Laser Printer/MFC/Fax machine shall be liable for any indirect, incidental, special, consequential, exemplary, or punitive damages, including lost profits, arising from the use of or inability to use the product, even if advised by the end user/purchaser of the possibility of such damages. Since some Provinces do not allow the above limitation of liability, such limitation, may not apply to you.

This Limited Warranty gives you specific legal rights and you may also have other rights which vary from Province to Province.

Warranty Service is available at Brother Authorized Service Centres throughout Canada. For Technical Assistance or for the name and location of your nearest Authorized Service Centre call 1-877-Brother.



Internet support: support@brother.ca or browse Brother's Web Site www.brother.ca.

User's Guides and where do I find it?

Which manual?	What's in it?	Where is it?
Safety and Legal	Read this Guide first. Please read the Safety Instructions before you set up your machine. See this Guide for trademarks and legal limitations.	Printed / In the Box
Quick Setup Guide	Follow the instructions for setting up your machine and installing the drivers and software for the operating system and connection type you are using.	Printed / In the Box
Basic User's Guide	Learn the basic Fax, Copy, Scan and Direct Print operations and how to replace consumables. See troubleshooting tips.	Printed / In the Box
Advanced User's Guide	Learn more advanced operations: Fax, Copy, security features, printing reports and performing routine maintenance.	PDF file / Documentation CD-ROM / In the Box
Software User's Guide	Follow these instructions for Printing, Scanning, Network Scanning, Remote Setup, PC-Fax, and using the Brother ControlCenter utility.	PDF file / Documentation CD-ROM / In the Box
Network Glossary	This Guide provides basic information about advanced network features of Brother machines along with explanations about general networking and common terms.	PDF file / Documentation CD-ROM / In the Box
Network User's Guide	This Guide provides useful information about wired and wireless network settings and security settings using the Brother machine. You can also find supported protocol information for your machine and detailed troubleshooting tips.	PDF file / Documentation CD-ROM / In the Box

Table of Contents (BASIC USER'S GUIDE)

1	General information	1
	Using the documentation	1
	Symbols and conventions used in the documentation	1
	Accessing the Advanced User's Guide, Software User's Guide and	
	Network User's Guide	2
	Viewing Documentation	
	Accessing Brother Support (Windows®)	4
	Accessing Brother Support (Macintosh)	5
	Control panel overview	6
	LCD Touchscreen	8
	Basic Operations	
2	Loading paper	10
	Loading paper and print media	10
	Loading paper and print mediaLoading paper in the standard paper tray	
	Loading paper in the multi-purpose tray (MP tray)	
	Unscannable and unprintable areas	
	Paper settings	
	Paper Size and Type	
	Tray Use in copy mode	
	Tray Use in fax mode	
	Tray Use in print mode	
	Acceptable paper and other print media	
	Recommended paper and print media	
	Type and size of paper	
	Handling and using special paper	∠ა
3	Loading documents	26
	How to load documents	26
	Using the automatic document feeder (ADF)	26
	Using the scanner glass	27
4	Sending a fax	28
	How to send a fax	20
	Faxing A4/Legal/Folio size documents from the scanner glass	
	Color fax transmission	
	Canceling a fax in progress	
	Transmission verification report	30

5	Receiving a fax	32
	Receive modes	32
	Choose the correct Receive Mode	
	Using receive modes	
	Fax Only	
	Fax/Tel	
	Manual	
	External TAD	
	Receive Mode settings	
	Ring Delay	
	F/T Ring Time (Fax/Tel mode only)	
	Easy Receive	36
6	Telephone services and external devices	37
	Telephone line services	37
	Voice Mail	37
	Distinctive Ring	
	Connecting an external TAD (telephone answering device)	
	Connections	
	Recording an outgoing message (OGM)	
	Multi-line connections (PBX)	
	External and extension telephones	
	Connecting an external or extension telephone	
	Using external and extension telephones	
	Using a non-Brother cordless external handset	
	Using Remote Codes	
	Osing Remote Codes	
7	Dialing and storing numbers	44
	How to dial	44
	Manual dialing	44
	One touch dialing	
	Speed dialing	
	Search	
	LDAP search	
	Fax redial	
	Storing numbers	
	Storing a pause	
	One Touch and Speed Dial Storage Options	
	Storing One Touch Dial numbers	
	Storing Speed Dial numbers	
	Changing or Deleting One Touch and Speed Dial numbers	
_		
8	Making copies	53
	How to copy	
	Stop copying	
	Copy settings	53

9 	Supporting mass storage	era 54
	Creating a PRN or PostScript [®] 3™ file for direct printing	54
	Printing data directly from the USB Flash memory drive or digital camera	
	supporting mass storage	
	Changing the default settings for direct print	56
10	How to print from a computer	57
	Printing a document	57
11	How to scan to a computer	58
	Scanning a document as PDF file using ControlCenter4 (Windows®)	58
	Changing the SCAN key settings	
	Before scanning	
	SCAN key settings	
	Scanning using the SCAN key	63
Α	Routine maintenance	64
	Replacing the consumable items	64
	Replacing a Toner cartridge	
	Cleaning the corona wires	
	Replacing the drum unit	
	Replacing the belt unit	
	Replacing the waste toner box	92
В	Troubleshooting	99
	Error and maintenance messages	
	Transferring your faxes or Fax Journal report	
	Document jams	
	Document is jammed in the top of the ADF unit	
	Document is jammed under the document cover	
	Removing small documents jammed in the ADF Document is jammed at the output tray	
	Paper jams	
	Paper is jammed in the MP tray	
	Paper is jammed in paper tray 1 or tray 2	
	Paper is jammed at the back of the machine	
	Paper is jammed inside the machine	
	Paper is jammed underneath paper tray 1	118
	If you are having difficulty with your machine	121
	Setting Dial Tone detection	
	Telephone line interference / VoIP	
	Improving the print quality	
	Machine Information	
	Checking the Serial Number	
	Reset functions How to reset the machine	
	1 10 W TO 10301 THE HIGHING	100

С	Menu and features	140
	On-screen programming	140
	Menu table	
	MENU button and mode keys	140
	Menu table	141
	Entering text	176
D	Specifications	177
	General	177
	Document Size	179
	Print media	180
	Fax	182
	Copy	183
	Scanner	184
	Printer	185
	Interfaces	186
	Direct Print feature	187
	Scan to USB feature	188
	Computer requirements	189
	Consumable items	191
	Network (LAN)	192
E	Index	193

Table of Contents (ADVANCED USER'S GUIDE)

The Advanced User's Guide explains the following features and operations.

You can view the Advanced User's Guide on the Documentation CD-ROM in the box.

1 General Setup

Memory storage

Volume settings

Automatic daylight savings time

Ecology features

LCD screen

Dial Prefix

Mode Timer

2 Security features

Secure Function Lock 2.0

Setting Lock

Restricting dialing

3 Sending a fax

Additional sending options

Additional sending operations

Polling overview

4 Receiving a fax

Remote Fax Options (black & white only)

Additional receiving operations

Polling overview

5 Dialing and storing numbers

Telephone line services

Additional dialing operations

Additional ways to store numbers

6 Printing reports

Fax reports

Reports

7 Making copies

Copy settings

A Routine maintenance

Cleaning and checking the machine

Replacing periodic maintenance parts

Packing and shipping the machine

B Options

Options

Optional paper tray (LT-300CL)

Memory board

C Glossary

D Index

General information

Using the documentation

Thank you for buying a Brother machine! Reading the documentation will help you make the most of your machine.

Symbols and conventions used in the documentation

The following symbols and conventions are used throughout the documentation.

Bold Bold style identifies keys on the

machine control panel or

computer screen.

Italics Italicized style emphasizes an

important point or refers you to

a related topic.

Courier New Courier New font identifies the messages shown on the LCD

of the machine.

WARNING

<u>WARNING</u> indicates a potentially hazardous situation which, if not avoided, could result in death or serious injuries.

CAUTION

<u>CAUTION</u> indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injuries.

IMPORTANT

<u>IMPORTANT</u> indicates a potentially hazardous situation which, if not avoided, may result in damage to property or loss of product functionality.



Electrical Hazard icons alert you to a possible electrical shock.



Hot Surface icons warn you not to touch machine parts that are hot.



Notes tell you how you should respond to a situation that may arise or give tips about how the current operation works with other features.

Accessing the Advanced User's Guide, Software User's Guide and Network User's Guide

This Basic User's Guide does not contain all the information about the machine such as how to use the advanced features for Fax, Copy, Printer, Scanner, PC-Fax and Network. When you are ready to learn detailed information about these operations, read the Advanced User's Guide, Software User's Guide, Network User's Guide, and Network Glossary that are on the Documentation CD-ROM.

Viewing Documentation

1 Turn on your computer. Insert the Documentation CD-ROM into your CD-ROM drive. For Windows® users, go to step 3.



(Windows[®] users) If the screen does not appear automatically, go to **My Computer** (**Computer**), double-click the CD-ROM icon, and then double-click **index.html**.

(Macintosh users) Double-click the Documentation CD-ROM icon, and then double-click index.html.

3 Click your country.



4 Point to your language, point to View Guide, and then click the guide you want to read.







- (Windows[®] users only) Your Web browser may display a yellow bar at the top of the page that contains a security warning about Active X controls. For the page to display correctly you must click on the bar, click Allow Blocked Content, then click Yes in the Security Warning dialog box.
- (Windows[®] users only) ¹ For faster access, you can copy all user documentation in PDF format to a local folder on your computer. Point to your language, then click Copy to local disk.
 - Microsoft[®] Internet Explorer[®] 6.0 or greater.

How to find Scanning instructions

There are several ways you can scan documents. You can find the instructions as follows:

Software User's Guide

- Scanning
- ControlCenter
- Network Scanning

ScanSoft™ PaperPort™12SE with OCR How-to-Guides

(Windows®)

■ The complete ScanSoft™ PaperPort™12SE with OCR How-to-Guides can be viewed from the Help selection in the ScanSoft™ PaperPort™12SE application.

Presto! PageManager User's Guide (Macintosh)



Presto! PageManager is available as a download from

http://nj.newsoft.com.tw/download/brother/PM9SEInstaller BR multilang.dmg

■ The complete Presto! PageManager User's Guide can be viewed from the Help selection in the Presto! PageManager application.

How to find Network setup instructions

Your machine can be connected to a wireless or wired network. You can find basic setup instructions in the *Quick Setup Guide*. If your wireless access point or router supports Wi-Fi Protected Setup or AOSS™, you can also follow the steps in the *Quick Setup Guide*. For more information about network setup please see the *Network User's Guide* on the Documentation CD-ROM.

Accessing Brother Support (Windows®)

You can find all the contacts you will need, such as Web support (Brother Solutions Center), Customer Service and Brother Authorized Service Centers on page i and on the Installation CD-ROM.

Click Brother Support on the main menu. The following screen will appear:



- To access our Web site (<u>http://www.brother.com/</u>) click **Brother Home Page**.
- To view all Brother Numbers, including Customer Service numbers for the USA and Canada, click Support Information.
- To access the USA Brother online shopping mall (http://www.brothermall.com/) for additional product and service information, click Brother Mall.com.
- To access Canada's Brother online shopping mall (<u>http://www.brother.ca/</u>) for additional product and services information, click **Shop Online (Canada)**.
- For the latest news and product support information (http://solutions.brother.com/), click Brother Solutions Center.
- To visit our web site for genuine Brother supplies (http://www.brother.com/original/), click
 Supplies Information.

■ To access the Brother CreativeCenter (http://www.brother.com/creativecenter/) for FREE photo projects and printable downloads, click **Brother** CreativeCenter.

To return to the main page, click **Back**. Or, if you have finished, click **Exit**.

Accessing Brother Support (Macintosh)

You can find all the contacts you will need, such as Web support (Brother Solutions Center), Customer Service and Brother Authorized Service Centers in *Brother numbers* on page i and on the Installation CD-ROM.

Double-click the Brother Support icon. The following screen will appear:



- To download and install Presto! PageManager, click Presto! PageManager.
- To register your machine from the Brother Product Register Page (http://www.brother.com/registration/), click On-Line Registration.
- To view all Brother Numbers, including Customer Service numbers for the USA and Canada, click Support Information.
- For the latest news and product support information (http://solutions.brother.com/), click
 Brother Solutions Center.
- To visit our Web site for genuine Brother Supplies (http://www.brother.com/original/), click Supplies Information.

Control panel overview



1 One Touch keys

These 20 keys give you instant access to 40 previously stored numbers.

21-40 ▼

The **21-40** ▼ lets you access One Touch numbers 21 to 40 when held down.

2 LCD

This is a Touchscreen LCD. You can access the menus and options by pressing buttons displayed on the screen.

3 Mode keys:



Puts the machine in Fax mode.



Puts the machine in Scan mode.



Puts the machine in Copy mode.

4 Dial pad

Use these keys to dial telephone and fax numbers and as a keyboard for entering information into the machine.

This function transfers to the touchscreen when you store quick dial numbers.

(Canada only) The # key temporarily switches the dialing mode from Pulse to Tone during a telephone call.

5 Stop/Exit

Stops an operation or exits from a menu.

6 Start:

Color

Lets you start sending faxes or making copies in full color.

Black

Lets you start sending faxes or making copies in black & white.



7 FAX keys:

Hook

Press before dialing if you want to make sure a fax machine will answer, and then press **Black Start** or **Color Start**. Also, press this key after you pick up the handset of an external telephone during the F/T ring (fast double-rings).

Redial/Pause

Redials the last number called. It also inserts a pause when programming quick dial numbers or when dialing a number manually.

8 Print Data / Job Cancel


Cancels a programmed print job and clears it from the machine's memory. To cancel multiple print jobs, hold down this key until the LCD shows Cancel Printing (All).

Also, this key will flash depending on the machine's status.

Machine Status	Description
Ready Mode	The machine is ready to print, in sleep mode, there is no print data, or the power switch is off.
Receiving Data	The machine is either receiving data from the computer, processing data in memory, or printing data.
Green (blinking)	
Data Remaining in Memory	Print data remains in the machine memory.
Green	

LCD Touchscreen

The LCD Touchscreen shows the current machine status when the machine is idle.



1 Date and Time

Lets you see date and time.

2 MENU

Lets you access the main menu.

3 Fax duplex (2-sided) receiving indicator

Appears when duplex printing is set to on for received faxes.

4 Secure Print

Lets you access the secure print menu.

Active only when the machine has secure print data.

5 Fax in memory

Shows how many received faxes are in the memory.

6 Wireless Status

In FAX mode and SCAN mode a four level indicator shows the current wireless signal strength if you are using a wireless connection.



7 Current Receive Mode

Lets you see the current receive mode.

- Fax (Fax only)
- F/T (Fax/Tel)
- TAD (External TAD)
- Mnl (Manual)

8 Direct Print

Lets you print data from a USB flash memory drive or a digital camera supporting mass storage directly to the machine. (See *Printing data directly from the USB Flash memory drive or digital camera supporting mass storage* on page 55.)

Active only when you insert a USB flash memory drive or digital camera in the machine's USB direct interface.

9 Security indicator

Shows machine's security status. Appears when you turn on Secure Function Lock or Setting Lock.

10 Warning icon

Appears when there is an error or maintenance message; press the Warning icon to view it, and then press **Stop/Exit** to return to the Ready screen.

11 Address Book

Lets you search the number you want to fax/dial/E-mail/I-Fax.

Basic Operations

To operate the Touchscreen use your finger to press the MENU or option button directly on the LCD screen.

To display and access all the screen menus or options in a setting, press ▲ ▼ or ◀ ▶ to scroll through them.

Press to return to the previous menu.

IMPORTANT


DO NOT press the Touchscreen with a sharp object, such as a pen or stylus. It may damage the machine.

The following steps show how to change a setting in the machine. In this example the LCD back light setting is changed from Light to Dark.

- 1 Press MENU.
- Press ▲ or ▼ to display General Setup. Press General Setup.



3 Press A or V to display LCD Settings.
Press LCD Settings.



4 Press Backlight.



5 Press Dark.



6 Press Stop/Exit.

Loading paper

Loading paper and print media

The machine can feed paper from the standard paper tray, optional lower tray or multi-purpose tray.

When you put paper into the paper tray, note the following:


If your application software supports paper size selection on the print menu, you can select it through the software. If your application software does not support it, you can set the paper size in the printer driver or by pressing the buttons on the Touchscreen.

Loading paper in the standard paper tray

You can load up to 250 sheets for Tray 1 and 500 sheets for the optional lower tray (Tray 2). Paper can be loaded up to the maximum paper mark (▼ ▼) on the sliding paper width guide. (For recommended paper to use, see Paper capacity of the paper trays on page 22.)


Printing on plain paper, thin paper or recycled paper from the standard paper tray (Tray 1)

1) Pull the paper tray completely out of the machine.




▲ WARNING


DO NOT touch the shaded parts shown in the illustration. These rollers may be rotating at high speed and can pinch or entrap your hand.




While pressing the green paper-guide release lever (1), slide the paper guides to fit the paper size you are loading in the tray. Make sure that the guides are firmly in the slots.




3 Fan the stack of paper well to avoid paper jams and misfeeds.



- 4 Put paper in the tray and make sure:
 - The paper is below the maximum paper mark (▼ ▼ ▼) (1).
 - Overfilling the paper tray will cause paper jams.
 - The side to be printed on must be face down.
 - The paper guides touch the sides of the paper so it will feed properly.



- 5 Put the paper tray firmly back in the machine. Make sure that it is completely inserted into the machine.
- 6 Lift up the support flap (1) to prevent paper from sliding off the *face down* output tray or remove each page as soon as it comes out of the machine.




Loading paper in the multi-purpose tray (MP tray)

You can load up to 3 envelopes or special print media in the MP tray or up to 50 sheets of plain paper. Use this tray to print or copy on thick paper (28 - 43 lb.), bond paper, glossy paper, labels, or envelopes. (For recommended paper to use, see *Paper capacity of the paper trays* on page 22.)

Printing on plain paper, bond paper, labels or glossy paper from the MP tray


Open the MP tray and lower it gently.



Pull out the MP tray support and unfold the flap (1).



- 3 Put paper in the MP tray and make sure:
 - The paper stays under the maximum paper mark (1).
 - The top of paper edge is positioned between the arrows (2).
 - The side to be printed on must be face up with the leading edge (top of the paper) in first.





When you are using glossy paper, put only one sheet at a time in the MP tray to avoid a paper jam.

Chapter 2

4 Lift up the support flap to prevent paper from sliding off the *face down* output tray, or remove each page as soon as it comes out of the machine.




Printing on envelopes and thick paper from the MP tray

Before loading, press the corners and sides of the envelopes to make them as flat as possible.




1 Open the MP tray and lower it gently.




Pull out the MP tray support and unfold the flap (1).




3 Lift up the support flap to prevent envelopes or sheets of thick paper from sliding off the *face down* output tray. If the support flap is closed you should remove each envelope as soon as it comes out of the machine.




- 4 Put up to 3 envelopes or up to 25 sheets of thick paper [43 lb (163 g/m²)] in the MP tray. If you add more envelopes or paper it may cause a jam. Make sure:
 - The top edge of the envelope is positioned between the arrows (1).
 - The side to be printed on must be face up.



Open the back cover (Face up output tray).



6 Pull down the two gray levers, one on the left-hand side and one on the right-hand side, to the envelope position as shown in the illustration below.




- Close the back cover.
- 8 Send the print data to the machine.
- When you have finished printing, open the back cover and reset the two gray levers which were pulled down in step 6 back to their original positions.

Note

- Remove each printed envelope immediately to prevent a paper jam.
- If your thick paper curls during printing, put only one sheet at a time in the MP tray and open the back cover (face up output tray) to let the printed pages exit to the face up output tray.

Unscannable and unprintable areas

The figures below show maximum unscannable and unprintable areas. The unscannable and unprintable areas may vary depending on the paper size or settings in the application you are using.



Usage	Document	Top (1)	Left (2)
	Size	Bottom (1)	Right (2)
Fax (Sending)	Letter	0.12 in. (3 mm)	0.16 in. (4 mm)
	A4	0.12 in. (3 mm)	0.12 in. (3 mm)
Copy*	Letter	0.16 in. (4 mm)	0.16 in. (4 mm)
*a single copy or a 1 in 1 copy	A4	0.16 in. (4 mm)	0.16 in. (4 mm)
Scan	Letter	0.12 in. (3 mm)	0.12 in. (3 mm)
	A4	0.12 in. (3 mm)	0.12 in. (3 mm)
Print	Letter	0.16 in. (4 mm)	0.16 in. (4 mm)
	A4	0.16 in. (4 mm)	0.16 in. (4 mm)

Paper settings

Paper Size and Type

When you change the size of paper in the tray, you will also need to change the setting for paper size at the same time so your machine can fit the document or an incoming fax on the page.

You can use the following sizes of paper for printing copies: A4, Letter, Legal, Executive, A5, A5 L, A6, B5, B6 and Folio and the following sizes for printing faxes: A4, Letter, Legal or Folio (8.5 in. × 13 in.).

Following on the paper size setting, you can set up the machine for the type of paper you are using. This will give you the best print quality.

- 1 Press MENU.
- Press ▲ or ▼ to display
 General Setup.
 Press General Setup.
- 3 Press A or ▼ to display Tray Setting. Press Tray Setting.
- 4 Do one of the following:
 - To set the paper type for the MP Tray press A or V to display MP Tray.

Press MP Tray

■ To set the paper type for Tray#1 press A or V to display Tray#1.

Press Tray#1

■ To set the paper type for Tray#2 press or to display Tray#2.

Press Tray#2 ¹ if you installed the optional tray.

The Tray#2 button will be selectable if the optional tray is installed.

Press ◀ or ▶ to display the paper size options.

Press A4, Letter, Legal, Executive, A5, A5 L, A6, B5, B6, Folio Or Any.



Note

- Any size appears only when you choose the MP tray.
- If you choose Any for the MP Tray Paper Size: You must choose MP Only for the Tray Use setting. You cannot use the Any Paper Size selection for the MP tray when making N in 1 copies. You must choose one of the other available Paper Size selections for the MP tray.
- A5 L and A6 size are not available for Tray#2.
- 6 Press Thin, Plain, Thick, Thicker, Recycled Paper Or Glossy.
- 7 Press Stop/Exit.



Note

You can choose Glossy for the MP Tray.

Tray Use in copy mode

You can change the priority tray that the machine will use for printing copies.

When you choose Tray#1 Only, MP Only or Tray#2 Only ¹, the machine pulls the paper only from that tray. If the selected tray is out of paper, No Paper will appear on the LCD. Insert the paper in the empty tray.

To change the tray setting follow the instructions below:

- 1 Press MENU.
- Press ▲ or ▼ to display
 General Setup.
 Press General Setup.
- Press ▲ or ▼ to display Tray Setting. Press Tray Setting.
- 4 Press ▲ or ▼ to display Tray Use:Copy. Press Tray Use:Copy.
- Press Tray#1 Only, Tray#2 Only ¹, MP Only, MP>T1>T2 ¹ or T1>T2 ¹>MP.
 - The Tray#2 Only or T2 appears only if the optional tray is installed.
- 6 Press Stop/Exit.



- When loading the documents in the ADF and MP>T1>T2 or T1>T2>MP is selected, the machine looks for the tray with the most suitable paper and pulls paper from that tray. If no tray has suitable paper, the machine pulls paper from the higher priority tray.
- When using the scanner glass, your document is copied from the higher priority tray even if more suitable paper is in another paper tray.

Tray Use in fax mode

You can change the default tray that the machine will use for printing received faxes.

When you choose Tray#1 Only, MP Only or Tray#2 Only ¹, the machine pulls the paper only from that tray. If the selected tray is out of paper, No Paper will appear on the LCD. Insert the paper in the empty tray.

When you choose T1>T2 ¹>MP, the machine pulls paper from Tray #1 until it is empty, then from Tray #2, and then from the MP tray.

When you choose MP>T1>T2 ¹, the machine pulls paper from the MP tray until it is empty, then from Tray #1, and then from Tray #2.



- You can use four sizes of paper for printing faxes: A4, Letter, Legal or Folio. When a suitable size is not in any of the trays received faxes will be stored in the machine's memory and Size mismatch will appear on the LCD. (For details, see Error and maintenance messages on page 99.)
- If the tray is out of paper and received faxes are in the machine's memory,
 No Paper will appear on the LCD. Insert paper in the empty tray.
- 1 Press MENU.
- 2 Press ▲ or ▼ to display
 General Setup.
 Press General Setup.
- 3 Press ▲ or ▼ to display Tray Setting.
 Press Tray Setting.
- 4 Press ▲ or ▼ to display Tray Use: Fax.
 Press Tray Use: Fax.
- Fress Tray#1 Only, Tray#2 Only 1, MP Only, MP>T1>T2 1 or T1>T2 1>MP.
 - The Tray#2 Only or T2 appears only if the optional tray is installed.
- 6 Press Stop/Exit.

Tray Use in print mode

You can change the default tray the machine will use for printing from your computer.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display
 General Setup.
 Press General Setup.
- 3 Press A or ▼ to display Tray Setting.
 Press Tray Setting.
- 4 Press ▲ or ▼ to display
 Tray Use:Print.
 Press Tray Use:Print.
- Press Tray#1 Only, Tray#2 Only ¹, MP Only, MP>T1>T2 ¹ or T1>T2 ¹>MP.
 - The Tray#2 Only or T2 appears only if the optional tray is installed.
- 6 Press Stop/Exit.

Acceptable paper and other print media

Print quality may vary according to the type of paper you are using.

You can use the following types of print media: thin paper, plain paper, thick paper, bond paper, recycled paper, glossy paper, labels or envelopes.

For best results, follow the instructions below:

- DO NOT put different types of paper in the paper tray at the same time because it may cause paper jams or misfeeds.
- For proper printing, you must choose the same paper size from your software application as the paper in the tray.
- Avoid touching the printed surface of the paper immediately after printing.
- Before you buy a lot of paper, test a small quantity to make sure the paper is suitable.

Recommended paper and print media

Paper Type	Item
Plain Paper	Xerox 4200DP 20 lb
	Hammermill Laser Print (24 lb=90 g/m ²)
Recycled Paper	No specific brand recommended
Labels	Avery laser labels white #5160
Envelope	No specific brand recommended
Glossy Paper	Glossy Laser Paper

Type and size of paper

The machine feeds paper from the installed standard paper tray, multi-purpose tray or optional lower tray.

The name for the paper trays in the printer driver in this Guide are as follows:

Tray and optional unit	Name
Standard paper tray	Tray 1
Multi-purpose tray	MP Tray
Optional lower tray	Tray 2

Paper capacity of the paper trays

	Paper size	Paper types	No. of sheets
Paper Tray (Tray 1)	A4, Letter, Legal, B5, Executive, A5, A5 (Long Edge), A6, B6, Folio ¹	Plain paper, Thin paper and Recycled paper	up to 250 [20 lb (80 g/m ²)]
Multi-purpose Tray (MP Tray)	Width: 2.75 to 8.5 in. (69.8 to 216 mm) Length: 4.57 to 16 in. (116 to 406.4 mm)	Plain paper, Thin paper, Thick paper, Thicker paper, Bond paper, Recycled paper, Envelopes, Labels and Glossy paper	50 sheets [20 lb (80 g/m²)] 3 Envelopes 1 Glossy paper
Optional lower Tray (Tray 2)	A4, Letter, Legal, B5, Executive, A5, B6, Folio ¹	Plain paper, Thin paper and Recycled paper	up to 500 [20 lb (80 g/m ²)]

¹ Folio size is 8.5 in. × 13 in. (215.9 mm x 330.2 mm)

Recommended paper specifications

The following paper specifications are suitable for this machine.

Basis weight	20-24 lb (75-90 g/m ²)
Thickness	80-110 μm
Roughness	Higher than 20 sec.
Stiffness	90-150 cm ³ /100
Grain direction	Long grain
Volume resistivity	10e ⁹ -10e ¹¹ ohm
Surface resistivity	10e ⁹ -10e ¹² ohm-cm
Filler	CaCO ₃ (Neutral)
Ash content	Below 23 wt%
Brightness	Higher than 80%
Opacity	Higher than 85%

- Use paper made for plain paper copying.
- Use paper that is 20 to 24 lb (75 to 90 g/m^2).
- Use long grain paper with a neutral Ph value, and a moisture content of approx. 5%.
- This machine can use recycled paper that meets DIN 19309 specifications.

Handling and using special paper

The machine is designed to work well with most types of xerographic and bond paper. However, some paper variables may have an effect on print quality or handling reliability. Always test samples of paper before purchasing to ensure desirable performance. Store paper in its original packaging and keep it sealed. Keep the paper flat and away from moisture, direct sunlight and heat.

Some important guidelines when selecting paper are:

- DO NOT use inkjet paper because it may cause a paper jam or damage your machine.
- Preprinted paper must use ink that can withstand the temperature of the machine's fusing process 392 degrees Fahrenheit (200 degrees centigrade).
- If you use bond paper, paper having a rough surface or paper that is wrinkled or creased, the paper may exhibit degraded performance.
- When you are using glossy paper, put only one sheet at a time in the MP tray to avoid a paper jam.


Types of paper to avoid

! IMPORTANT

Some types of paper may not perform well or may cause damage to your machine.

DO NOT use paper:

- · that is highly textured
- · that is extremely smooth or shiny
- · that is curled or warped



- 1 A curl of 0.08 in. (2 mm) or greater may cause jams to occur.
- · that is coated or has a chemical finish
- · that is damaged, creased or folded
- that exceeds the recommended weight specification in this guide
- with tabs and staples
- with letterheads using low temperature dyes or thermography
- that is multipart or carbonless
- · that is designed for inkjet printing

If you use any of the types of paper listed above, they may damage your machine. This damage is not covered under any Brother warranty or service agreement.

Envelopes

Most envelopes designed for laser printers will be suitable for your machine. However, some envelopes may have feed and print-quality problems because of the way they have been made. A suitable envelope should have edges with straight, well-creased folds and the leading edge should not be thicker than two sheets of paper. The envelope should lie flat and not be of baggy or flimsy construction. You should buy quality envelopes from a supplier who understands that you will be using the envelopes in a laser machine.

We recommend that you print a test envelope to make sure the print results are what you want.


Types of envelopes to avoid

IMPORTANT

DO NOT use envelopes:

- that are damaged, curled, wrinkled or an unusual shape
- that are extremely shiny or textured
- with clasps, staples, snaps or tie strings
- · with self-adhesive closures
- that are of a baggy construction
- · that are not sharply creased
- that are embossed (have raised writing on them)
- that were previously printed by a laser machine
- · that are pre-printed on the inside
- that cannot be arranged neatly when stacked
- that are made of paper that weighs more than the paper weight specifications for the machine
- with edges that are not straight or consistently square

- with windows, holes, cut-outs or perforations
- with glue on surface as shown in figure below



 with double flaps as shown in figure below



- with sealing flaps that are not folded down when purchased
- with sealing flaps as shown in figure below



with each side folded as shown in figure below



If you use any of the types of envelopes listed above, they may damage your machine. This damage may not be covered under any Brother warranty or service agreement.

Labels

The machine will print on most types of labels designed for use with a laser machine. Labels should have an adhesive that is acrylic-based since this material is more stable at the high temperatures in the fuser unit. Adhesives should not come in contact with any part of the machine, because the label stock may stick to the drum unit or rollers and cause jams and print quality problems. No adhesive should be exposed between the labels. Labels should be arranged so that they cover the entire length and width of the sheet. Using labels with spaces may result in labels peeling off and causing serious jams or print problems.

All labels used in this machine must be able to withstand a temperature of 392 degrees Fahrenheit (200 degrees centigrade) for a period of 0.1 seconds.

Types of labels to avoid

Do not use labels that are damaged, curled, wrinkled or an unusual shape.









IMPORTANT

- Avoid feeding labels with the carrier sheet exposed because your machine will be damaged.
- Label sheets should not exceed the paper weight specifications described in this User's Guide. Labels exceeding this specification may not feed or print properly and may cause damage to your machine.
- DO NOT reuse or insert labels that have previously been used or are missing a few labels on the sheet.

Loading documents

How to load documents

You can send a fax, make copies, and scan from the ADF (Automatic Document Feeder) and the scanner glass.

Using the automatic document feeder (ADF)

The ADF can hold up to 50 pages and feeds each sheet individually. Use standard 20 lb (80 g/m²) paper and always fan the pages before putting them in the ADF.

Document Sizes Supported

Length:	5.8 to 14 in. (147.3 to 356.0 mm)
Width:	5.8 to 8.5 in. (147.3 to 215.9 mm)
Weight:	17 to 24 lb (64 to 90 g/m ²)


How to load documents

IMPORTANT


- DO NOT leave thick documents on the scanner glass. If you do this, the ADF may jam.
- DO NOT use paper that is curled, wrinkled, folded, ripped, stapled, paperclipped, pasted or taped.
- DO NOT use cardboard, newspaper or fabric.
- To avoid damaging your machine while using the ADF, DO NOT pull on the document while it is feeding.

Note

- To scan documents that are not suitable for the ADF, see *Using the scanner glass* on page 27.
- It is easier to use the ADF if you are loading a multiple page document.
- Make sure documents with correction fluid or written with ink are completely dry.
- 1 Unfold the ADF document support (1). Lift up and unfold the ADF document output support flap (2).



- Pan the pages well.
- 3 Place your document face up top edge first in the ADF until the LCD display message changes and you feel it touch the feed rollers.
- 4 Adjust the paper guides (1) to fit the width of your document.





- To avoid damaging your machine while using the ADF, DO NOT pull on the document while it is feeding.
- To scan non-standard documents, see *Using the scanner glass* on page 27.

Using the scanner glass

You can use the scanner glass to fax, copy or scan pages of a book one page at a time.

Document Sizes Supported

 Length:
 Up to 14.0 in. (355.6 mm)

 Width:
 Up to 8.5 in. (215.9 mm)

 Weight:
 Up to 4.4 lb (2.0 kg)


How to load documents



To use the scanner glass, the ADF must be empty.

1 Lift the document cover.

Using the document guidelines on the left and top, place the document *face down* in the upper left corner of the scanner glass.



3 Close the document cover.


! IMPORTANT

If the document is a book or is thick, do not slam or press on the cover.

How to send a fax

The following steps show how to send a fax.

When you want to send a fax, or change fax send or receive settings, press the (FAX) key to illuminate it in blue.



■ The LCD shows:



- Do one of the following to load your document:
 - Place the document *face up* in the ADF. (See Using the automatic document feeder (ADF) on page 26.)
 - Load your document face down on the scanner glass. (See Using the scanner glass on page 27.)



To send color faxes with multiple pages use the ADF.

3 Set the scanner glass size, fax resolution or contrast if you want to change them.



M Note

For more advanced fax sending operations and settings, see Sending a fax in Chapter 3 of the Advanced User's Guide:

- · Broadcasting
- Duplex Fax (2-sided fax layout)
- Delayed Fax
- Batch TX
- Real Time TX
- Polled TX
- Overseas Mode
- Fax Resolution
- Contrast
- Glass ScanSize
- Coverpage Setup
- Coverpage Message
- Set New Default
- Factory Reset
- Choose one of the options below:
 - If you want to send a single-sided document, go to step 6.
 - If you want to send a 2-sided document, you need to choose the duplex scanning format of your 2-sided document.

Press Duplex Fax and choose DuplexScan :LongEdge or DuplexScan : ShortEdge.



You can send 2-sided documents from the ADF.

- 5 Enter the fax number using the dial pad. You can also enter the fax number on the LCD by pressing Address Book and Send a fax, or you can press an One Touch key on the machine's control panel. (For details, see How to dial on page 44.)
- 6 Press Black Start or Color Start.

Faxing from the ADF

■ The machine starts scanning the document.

Faxing from the scanner glass

If Real Time TX is On, the machine will send the document without asking if there are additional pages to scan.

If you press Black Start, the machine starts scanning the first page.

Do one of the following:

- To send a single page, press No (or press Black Start again). The machine starts sending the document.
- To send more than one page, press Yes and place the next page on the scanner glass. Press Black Start. The machine starts scanning the page. (Repeat this step for each additional page.)
- If you press Color Start and
 Yes (Color fax), the machine starts sending the document.



To cancel, press Stop/Exit.

Faxing A4/Legal/Folio size documents from the scanner glass

When faxing A4/Legal/Folio size documents, you will need to set the scan glass size to A4 or Legal/Folio; otherwise, a portion of your faxes will be missing.

- 1 Press (FAX).
- Press ◀ or ▶ to display Glass ScanSize. Press Glass ScanSize.
- 3 Press A4 or Legal/Folio.
- 4 Press Stop/Exit.



You can save the setting you use most often by setting it as the default. (See Setting your changes as the new default in Chapter 3 of the Advanced User's Guide.)

Color fax transmission

Your machine can send a color fax to machines that support this feature. Color faxes cannot be stored in the machine's memory. When you send a color fax, the machine will send it in real time (even if Real Time TX is set to Off).

Canceling a fax in progress

Press **Stop/Exit** to cancel the fax. If you press **Stop/Exit** while the machine is dialing or sending, the LCD will show Cancel Job?.

Press Yes to cancel the fax.

Transmission verification report

You can use the Transmission Verification Report as proof that you sent a fax. This report lists the receiving party's name or fax number, the time and date of transmission, duration of transmission, number of pages sent, and whether or not the transmission was successful.

There are several settings available for the Transmission Verification Report:

- On: Prints a report after every fax you send.
- On+Image: Prints a report after every fax you send. A portion of the fax's first page appears on the report.
- Off: Prints a report if your fax is unsuccessful due to a transmission error.
 Off is the default setting.
- Off+Image: Prints a report if your fax is unsuccessful due to a transmission error. A portion of the fax's first page appears on the report.
- 1 Press MENU.
- Press ▲ or ▼ to display Fax.
 Press Fax.
- 3 Press ▲ or ▼ to display
 Report Setting.
 Press Report Setting.
- 4 Press Transmission.
- 5 Press On, On+Image, Off or Off+Image.
- 6 Press Stop/Exit.



- If you choose On+Image or Off+Image, the image will only appear on the Transmission Verification Report if Real Time Transmission is set to Off. (See Real Time Transmission in Chapter 3 of the Advanced User's Guide.)
- If your transmission is successful, OK will appear next to RESULT on the Transmission Verification Report.
 If transmission is not successful, NG will appear next to RESULT.

Receiving a fax

Receive modes

Choose the correct Receive Mode

The correct Receive Mode is determined by the external devices and telephone subscriber services (Voice Mail, Distinctive Ring, etc.) you have (or will be using) on the same line as the Brother machine.

Will you be using a Distinctive Ring number for receiving faxes?

Brother uses the term "Distinctive Ring" but different telephone companies may have other names for this service such as Custom Ringing, RingMaster, Personalized Ring, Teen Ring, Ident-A-Ring, Ident-A-Call, Data Ident-A-Call, Smart Ring and SimpleBiz Fax & Alternate Number Ringing. (See *Distinctive Ring* on page 38 for instructions on setting up your machine using this feature.)

Will you be using Voice Mail on the same telephone line as your Brother machine?

If you have Voice Mail on the same telephone line as your Brother machine, there is a strong possibility that Voice Mail and the Brother machine will conflict with each other when receiving incoming calls. (See *Voice Mail* on page 37 for instructions on setting up your machine using this service.)

Will you be using a Telephone Answering Device on the same telephone line as your Brother machine?

Your external telephone answering device (TAD) will automatically answer every call. Voice messages are stored on the external TAD and fax messages are printed. Choose External TAD as your receive mode. (See Connecting an external TAD (telephone answering device) on page 40.)

Will you be using your Brother machine on a dedicated fax line?

Your machine automatically answers every call as a fax. Choose Fax Only as your receive mode. (See Fax Only on page 34.)

Will you be using your Brother machine on the same line as your telephone?

Do you want to receive voice calls and faxes automatically?

The Fax/Tel receive mode is used when sharing the Brother machine and your telephone on the same line. Choose Fax/Tel as your receive mode. (See Fax/Tel on page 34.)

Important Note: You can not receive voice messages on either Voice Mail or an answering machine when choosing the Fax/Tel mode.

Do you expect to receive very few faxes?

Choose Manual as your receive mode. You control the telephone line and must answer every call yourself. (See *Manual* on page 34.)

To set the receive mode follow the instructions below:

- 1 Press MENU.
- Press ▲ or ▼ to display Initial Setup.
 Press Initial Setup.
- 3 Press ▲ or ▼ to display Receive Mode.
 Press Receive Mode.
- 4 Press Fax Only, Fax/Tel, External TAD or Manual.
- 5 Press Stop/Exit.

The LCD will display the current receive mode.

Using receive modes

Some receive modes answer automatically (Fax Only and Fax/Tel). You may want to change the Ring Delay before using these modes. (See *Ring Delay* on page 35.)

Fax Only

Fax Only mode will automatically answer every call as a fax.

Fax/Tel

Fax/Tel mode helps you automatically manage incoming calls, by recognizing whether they are fax or voice calls and handling them in one of the following ways:

- Faxes will be automatically received.
- Voice calls will start the F/T ring to tell you to pick up the line. The F/T ring is a fast double ring made by your machine.

(Also see *F/T Ring Time* (*Fax/Tel mode only*) on page 35 and *Ring Delay* on page 35.)

Manual

Manual mode turns off all automatic answering functions unless you are using the Distinctive Ring Receive feature.

To receive a fax in Manual mode lift the handset of the external telephone or press **Hook**. When you hear fax tones (short repeating beeps), press **Black Start** or **Color Start**, and choose Receive to receive the fax. You can also use the Easy Receive feature to receive faxes by lifting a handset on the same line as the machine.

(Also see Easy Receive on page 36.)

External TAD

External TAD mode lets an external answering device manage your incoming calls. Incoming calls will be handled in the following ways:

- Faxes will be automatically received.
- Voice callers can record a message on the external TAD.

(For more information see Connecting an external TAD (telephone answering device) on page 40.)

Receive Mode settings

Ring Delay

The Ring Delay setting sets the number of times the machine rings before it answers in Fax Only and Fax/Tel modes.

If you have external or extension telephones on the same line as the machine, keep the Ring Delay setting of 4. (See *Easy Receive* on page 36.)

- 1 Press MENU.
- Press ▲ or ▼ to display Fax.
 Press Fax.
- 3 Press ▲ or ▼ to display Setup Receive. Press Setup Receive.
- Press A or ▼ to display Ring Delay. Press Ring Delay.
- 5 Press 0, 1, 2, 3 or 4 for how many times the line rings before the machine answers.
- 6 Press Stop/Exit.



Choose 0 in step **5** to have the machine answer immediately.

F/T Ring Time (Fax/Tel mode only)

When somebody calls your machine, you and your caller will hear the normal telephone ring sound. The number of rings is set by the Ring Delay setting.

If the call is a fax, then your machine will receive it; however, if it is a voice call the machine will sound the F/T ring (a fast double-ring) for the time you have set in the F/T Ring Time setting. If you hear the F/T ring it means that you have a voice caller on the line.

Because the F/T ring is made by the machine, extension and external telephones will *not* ring; however, you can still answer the call on any telephone. (For more information see *Using Remote Codes* on page 43.)

- 1 Press MENU.
- Press ▲ or ▼ to display Fax. Press Fax.
- 3 Press ▲ or ▼ to display
 Setup Receive.
 Press Setup Receive.
- Press ▲ or ▼ to display F/T Ring Time. Press F/T Ring Time.
- 5 Press how long the machine will ring to alert you that you have a voice call (20, 30, 40 or 70 seconds).
- 6 Press Stop/Exit.

Easy Receive

If Easy Receive is On:

The machine can receive a fax automatically, even if you answer the call. When you see Receiving on the LCD or hear a click on the phone line through the handset you are using, just replace the handset. Your machine will do the rest.

If Easy Receive is Off:

If you are at the machine and answer a fax call first by lifting the external handset, then press **Black Start** or **Color Start**, and then press Receive to receive the Fax.

If you answered at an extension telephone press ***51**.



- If this feature is set to On, but your machine does not connect a fax call when you lift an extension telephone handset, press the fax receive code *51.
- If you send faxes from a computer on the same telephone line and the machine intercepts them, set Easy Receive to Off.
- 1 Press MENU.
- Press ▲ or ▼ to display Fax.
 Press Fax.
- 3 Press A or ▼ to display
 Setup Receive.
 Press Setup Receive.
- Press ▲ or ▼ to display Easy Receive. Press Easy Receive.
- 5 Press On (or Off).
- 6 Press Stop/Exit.

6

Telephone services and external devices

Telephone line services

Voice Mail

If you have Voice Mail on the same telephone line as your Brother machine, Voice Mail and the Brother machine will conflict with each other when receiving incoming calls.

For example, if your Voice Mail is set to answer after 4 rings and your Brother machine is set to answer after 2 rings, then your Brother machine will answer first. This will prevent callers from being able to leave a message in your Voice Mail.

Similarly, if your Brother machine is set to answer after 4 rings and your Voice Mail is set to answer after 2 rings, then your Voice Mail will answer first. This will prevent your Brother machine from being able to receive an incoming fax, since Voice Mail cannot transfer the incoming fax back to the Brother machine.

To avoid conflicts between your Brother machine and your Voice Mail service, do one of the following:

Get the Distinctive Ring service from your telephone company. Distinctive Ring is a feature of your Brother machine that allows a person with one line to receive fax and voice calls through two different telephone numbers on that one line. Brother uses the term 'Distinctive Ring,' but telephone companies market the service under a variety of names, such as Custom Ringing, Personalized Ring, Smart Ring, RingMaster, Ident-A-Ring, Ident-A-Call, Data Ident-A-Call,

Teen Ring, and SimpleBiz Fax & Alternate Number Ringing. This service establishes a second telephone number on the same line as your existing telephone number, and each number has its own ring pattern. Typically, the original number rings with the standard ring pattern and is used for receiving voice calls, and the second number rings with a different ring pattern and is used for receiving faxes. (See *Distinctive Ring* on page 38.)

OR

Set your Brother machine's Receive Mode to "Manual". Manual Mode requires that you answer every incoming call if you want to be able to receive a fax. If the incoming call is a telephone call, then complete the call as you normally would. If you hear fax sending tones you must transfer the call to the Brother machine. (See *Using external and extension telephones* on page 42.) Unanswered fax and voice calls will go to your Voice Mail. (To set the machine in **MANUAL** Mode, see *Choose the correct Receive Mode* on page 32.)

Distinctive Ring

Distinctive Ring is a function of your Brother machine that allows a person with one line to receive fax and voice calls through two different phone numbers on that one line. Brother uses the term "Distinctive Ring," but telephone companies market the service under a variety of names, such as Smart Ring, Ring Master or Ident-a-Ring. This service establishes a second telephone number on the same line as your existing telephone number, and each number has its own ring pattern. Typically, the original number rings with the standard ring pattern and is used for receiving voice calls, and the second number rings with a different ring pattern and is used for receiving faxes.



- You must pay for your telephone company's Distinctive Ring service before you program the machine to work with it.
- Please call your telephone company for availability and rates.

What does your telephone company's 'Distinctive Ring' do?

Your telephone company's Distinctive Ring service allows you to have more than one number on the same telephone line. If you need more than one telephone number, it is cheaper than paying for an extra line. Each telephone number has its own distinctive ring pattern, so you will know which telephone number is ringing. This is one way you can have a separate telephone number for your machine.



Please call your telephone company for availability and rates.

What does Brother's 'distinctive ring' do?

The Brother machine has a Distinctive Ring feature that allows you to use your machine to take full advantage of the telephone company's Distinctive Ring service. The new telephone number on your line can just receive faxes.



Note

You must pay for your telephone company's Distinctive Ring service before you program the machine to work with it.

Do you have Voice Mail?

If you have Voice Mail on the telephone line that you will install your new machine on, there is a strong possibility that Voice Mail and the machine will conflict with each other while receiving incoming calls. However, the Distinctive Ring feature allows you to use more than one number on your line, so both Voice Mail and the machine can work together without any problems. If each one has a separate telephone number, neither will interfere with the other's operations.

If you decide to get the Distinctive Ring service from the telephone company, you will need to follow the directions below to 'register' the new Distinctive Ring pattern they give you. This is so your machine can recognize its incoming calls.



You can change or cancel the Distinctive Ring pattern at any time. You can switch it off temporarily, and turn it back on later. When you get a new fax number, make sure you reset this feature.

Before you choose the ring pattern to register

You can only register one Distinctive Ring pattern with the machine. Some ring patterns cannot be registered. The ring patterns below are supported by your Brother machine. Register the one your telephone company gives you.

Ring Pattern	Rings	
1	long-long	7
2	short-long-short	
3	short-short-long	
4	very long (normal pattern)	



- Ring Pattern #1 is often called Short-Short and is the most commonly used.
- If the ring pattern you received is not on this chart, please call your telephone company and ask for one that is shown.
- The machine will only answer calls to its registered number.
- The first two rings are silent on the machine. This is because the fax must <isten>> to the ring pattern (to compare it to the pattern that was 'registered'). (Other telephones on the same line will ring.)
- If you program the machine properly, it will recognize the registered ring pattern of the 'fax number' within 2 ring patterns and then answer with a fax tone. When the 'voice number' is called, the machine will not answer.

Registering the distinctive ring pattern Very important!

After you have set the Distinctive Ring feature to On, your Distinctive Ring number will receive faxes automatically. The receive mode is automatically set to Manual and you cannot change it to another receive mode while Distinctive Ring is set to On. This ensures the Brother machine will only answer the Distinctive Ring number and not interfere when your main telephone number is called.

- 1 Press MENU.
- Press ▲ or ▼ to display Fax. Press Fax.
- Press ▲ or ▼ to display
 Miscellaneous.
 Press Miscellaneous.
- 4 Press Distinctive.
- 5 Press Set.
- 6 Press the stored ring pattern you want to use.

Press OK.

(You will hear each pattern as you press four buttons. Make sure you choose the pattern that the telephone company gave you.)

7 Press **Stop/Exit**.
Distinctive Ring is now set to On.

Turning off distinctive ring

- 1 Press MENU.
- Press ▲ or ▼ to display Fax. Press Fax.
- 3 Press ▲ or ▼ to display
 Miscellaneous.
 Press Miscellaneous.
- 4 Press Distinctive.
- 5 Press Off.
- 6 Press Stop/Exit.




If you do not want to receive faxes on your Distinctive Ring number, you can turn off Distinctive Ring. The machine will stay in Manual receive mode so you will need to set the Receive Mode again. (See Choose the correct Receive Mode on page 32.)

Connecting an external TAD (telephone answering device)

You can connect an external Telephone Answering Device (TAD) to the same line as your machine. When the TAD answers a call, your machine will "listen" for the CNG (fax calling) tones sent by a sending fax machine. If it hears them it will take over the call and receive the fax. If it does not hear them, it will let your TAD take a voice message and the display will show Telephone.

The external TAD must answer within four rings (we recommend you set it to two rings). This is because your machine cannot hear the CNG tones until the external TAD has picked up the call. The sending machine will send CNG tones for only eight to ten seconds longer. We do not recommend using the toll saver feature on your external TAD if it needs more than four rings to activate it. Unless you are using Distinctive Ring, the TAD must be connected to the EXT. jack of

Before you connect an external TAD (telephone answering device), remove the protective cap (2) from the EXT. jack on the machine.



1 TAD

the machine.

2 Protective Cap



If you have problems receiving faxes, reduce the ring delay setting on your external TAD.

Connections

The external TAD must be plugged into the back of the machine, into the jack labeled EXT. Your machine cannot work properly if you plug the TAD into a wall jack (unless you are using Distinctive Ring).

- 1 Plug the telephone line cord from the telephone wall jack into the back of the machine, in the jack labeled LINE.
- Plug the telephone line cord from your external TAD into the back of the machine, in the jack labeled EXT. (Make sure this cord is connected to the TAD at the TAD's telephone line jack, and not its handset jack.)
- 3 Set your external TAD to four rings or less. (The machine's Ring Delay setting does not apply.)
- 4 Record the outgoing message on your external TAD.
- 5 Set the TAD to answer calls.
- 6 Set the Receive Mode to

 External TAD. (See Choose the
 correct Receive Mode on page 32.)

Recording an outgoing message (OGM)

- 1 Record 5 seconds of silence at the beginning of your message. This allows your machine time to listen for fax tones.
- 2 Limit your speaking to 20 seconds.
- 3 End your 20-second message by giving your Fax Receive Code for people sending manual faxes. For example: "After the beep, leave a message or press *51 and Start to send a fax."



We recommend beginning your OGM with an initial 5 second silence because the machine cannot hear fax tones over a loud voice. You may try leaving out this pause, but if your machine has trouble receiving, then you should re-record the OGM to include it.

Multi-line connections (PBX)

We suggest you ask the company who installed your PBX to connect your machine. If you have a multi line system we suggest you ask the installer to connect the unit to the last line on the system. This prevents the machine being activated each time the system receives telephone calls. If all incoming calls will be answered by a switchboard operator we recommend that you set the Receive Mode to Manual.

We cannot guarantee that your machine will operate properly under all circumstances when connected to a PBX. Any difficulties with sending or receiving faxes should be reported first to the company who handles your PBX.


External and extension telephones

Connecting an external or extension telephone

You can connect a separate telephone directly to your machine as shown in the diagram below.

Connect the telephone line cord to the jack labeled EXT.

Before you connect an external telephone, remove the protective cap (3) from the EXT. iack on the machine.



- 1 Extension telephone
- 2 External telephone
- 3 Protective Cap

When you are using an external telephone, the LCD shows Telephone.

Using external and extension telephones

Using extension telephones

If you answer a fax call at an extension telephone, you can make your machine receive the fax by pressing the Fax Receive Code *51.

If the machine answers a voice call and pseudo/double-rings for you to take over, you can take the call at an extension telephone by pressing the Telephone Answer Code **#51**. (See *F/T Ring Time (Fax/Tel mode only)* on page 35.)

Using an external telephone (Connected to the EXT. jack of the machine)

If you answer a fax call at the external telephone connected to the EXT jack of the machine, you can make the machine receive the fax by pressing **Black Start** or **Color Start** and choosing Receive.

If the machine answers a voice call and pseudo/double-rings for you to take over, you can take the call at the external telephone by pressing **Hook**.

If you answer a call and no one is on the line:

You should assume that you're receiving a manual fax.

Press *51 and wait for the chirp or until the LCD shows Receiving, and then hang up.



You can also use the Easy Receive feature to make your machine automatically take the call. (See *Easy Receive* on page 36.)

Using a non-Brother cordless external handset

If your non-Brother cordless telephone is connected to the EXT. jack of the machine (see page 42) and you typically carry the cordless handset elsewhere, it is easier to answer calls during the Ring Delay.

If you let the machine answer first, you will have to go to the machine so you can press **Hook** to transfer the call to the cordless handset.

6

Using Remote Codes

Fax Receive Code

If you answer a fax call on an extension telephone, you can tell your machine to receive it by pressing the Fax Receive Code *51. Wait for the chirping sounds then replace the handset. (See *Easy Receive* on page 36.)

If you answer a fax call at the external telephone, you can make the machine receive the fax by pressing **Black Start** or **Color Start**.

Telephone Answer Code

If you receive a voice call and the machine is in F/T mode, it will start to sound the F/T (double-ring) after the initial ring delay. If you pick up the call on an extension telephone you can turn the F/T ring off by pressing **#51** (make sure you press this *between* the rings).

If the machine answers a voice call and pseudo/double-rings for you to take over, you can take the call at the external telephone by pressing **Hook**.

Changing the Remote Codes

The preset Fax Receive Code is ***51**. The preset Telephone Answer Code is **#51**. If you are always disconnected when accessing your External TAD, try changing the three-digit remote codes, for example **###** and 999.

- 1 Press MENU.
- Press ▲ or ▼ to display Fax. Press Fax.
- 3 Press ▲ or ▼ to display
 Setup Receive.
 Press Setup Receive.
- 4 Press ▲ or ▼ to display Remote Codes.
 Press Remote Codes.
- 5 Press on (or off).
- 6 If you chose On in step 6, enter the new Fax Receive Code.
 Press OK.
- Tenter the new Telephone Answer Code. Press OK.
- 8 Press Stop/Exit.

7

Dialing and storing numbers

How to dial

You can dial in any of the following ways.


Manual dialing

Use the dial pad to enter all the digits of the telephone or fax number.



One touch dialing

Press the One Touch key that stores the number you want to call. (See *Storing One Touch Dial numbers* on page 48.)



To dial One Touch numbers 21 to 40, hold down **21-40** as you press the One Touch key.

Speed dialing

- 1 Press Address Book.
- Press the three-digit number you want to call. You can also display the numbers in alphabetical order by pressing on the Touchscreen.
- 3 Press Send a fax or Send a E-mail.
- 4 Press Black Start or Color Start.



If the LCD shows Not Registered when you enter or search a Speed Dial number, a number has not been stored at this location.

Search

You can search alphabetically for names you have stored in the One Touch and Speed Dial memories. (See *Storing One Touch Dial numbers* on page 48 and *Storing Speed Dial numbers* on page 50.)

- 1 Press Address Book.
- Press on the Touchscreen.
- 3 Press the first few letters of the name on the Touchscreen.

 Press OK.
- Press ▲ or ▼ to scroll until you find the name you are looking for. Press the name you are looking for.
- 5 Press Send a fax or Send a E-mail.
- 6 Press Black Start or Color Start.



stored.

- If the LCD shows
 Results cannot be found. when
 you enter the first few letters of the name,
 it means that a name for the letter is not
- One Touch Dial number and Speed Dial numbers stored without the name cannot be retrieved by the search function.

LDAP search

If the machine is connected to your LDAP server, you can search for information such as fax numbers and E-mail addresses from your server. (For details about how to set up LDAP see the *Network User's Guide*.)

Fax redial

If you are sending a fax manually and the line is busy, press **Redial/Pause** and try it again. You can call the last number dialed, by pressing **Redial/Pause**.

Redial/Pause only works if you dialed from the control panel.

If you are sending a fax automatically and the line is busy, the machine will automatically redial one time after five minutes.

Storing numbers

You can set up your machine to do the following types of easy dialing: One Touch, Speed Dial and Groups for Broadcasting faxes. You can also specify the default resolution for each One Touch and Speed Dial number. When you dial a quick dial number, the LCD shows the name, if you stored it, or the number. A scan profile can also be stored along with the fax number.

If you lose electrical power, the quick dial numbers stored in the memory will not be lost.

A scan profile is the resolution and other scan settings that you choose when you store a number.

Storing a pause

Press Pause to insert a 3.5-second pause between numbers. You can press Pause as many times as needed to increase the length of the pause.

One Touch and Speed Dial Storage Options

The following chart shows the selections for the settings for One Touch and Speed Dial numbers. When you store numbers, the LCD instructs you to choose from the options shown in the following steps.


Step 1	Step 2	Step 3	Step 4	Step 5
Enter Name	Select Registration Type	Enter Number or E-mail Address	Select Resolution	Select File type
Enter the name you want to	Fax	Enter the Fax Number	Standard, Fine, S.Fine, Photo	-
store or	IFAX	Enter the E-mail Address	Standard, Fine, Photo	-
Press OK	E-Mail B&W PDF		200 dpi, 200 x 100 dpi	PDF, PDF/A, Secure PDF, Signed PDF
	E-Mail B&W TIFF		200 dpi, 200 x 100 dpi	-
	E-Mail Color PDF		100 dpi,200 dpi, 300 dpi,600 dpi	PDF, PDF/A, Secure PDF, Signed PDF
	E-Mail Color JPEG		100 dpi,200 dpi, 300 dpi,600 dpi	-
	E-Mail Color XPS		100 dpi,200 dpi, 300 dpi,600 dpi	-
	E-Mail Gray PDF		100 dpi,200 dpi, 300 dpi	PDF, PDF/A, Secure PDF, Signed PDF
	E-Mail Gray JPEG		100 dpi,200 dpi, 300 dpi	-
	E-Mail Gray XPS		100 dpi,200 dpi, 300 dpi	-



- If you choose Signed PDF, you must install a certificate on your machine using Web Based Management. Choose **Configure Signed PDF Settings** from **Administrator Settings** in Web Based Management. For how to install a certificate, see the *Network User's Guide*.
- PDF/A is a PDF file format intended for long-term archiving. This format contains all the necessary information to be able to reproduce the document after long-term storage.
- A Signed PDF helps prevent data tampering and the impersonation of an author by including a digital certificate within the document.

Storing One Touch Dial numbers

Your machine has 20 One Touch keys where you can store 40 fax or telephone numbers or E-mail addresses for automatic dialing. To access numbers 21 to 40, hold down **21-40** as you press the One Touch key.



21-40

1 Press the One Touch key where you want to store the number or E-mail address.

If a number or E-mail address is not stored there, the LCD shows

Not Registered Register Now?.

Press Yes.

Or, you can use the LCD buttons by pressing Address Book, More and Set One Touch Dial, and then enter the number of the One Touch key where you want to store the number or E-mail address and press OK.



If the One Touch number you choose is already taken, the OK button on the LCD will not work. Choose a different number.

- 2 Do one of the following:
 - Enter the name (up to 15 characters) by pressing the buttons on the Touchscreen. Use the chart on Entering text on page 176 to help you enter letters.

Press OK.

■ Press OK to store the number or E-mail address without a name.

3 Press ◀ or ▶ to select

Fax,

IFAX,

E-Mail B&W PDF,

E-Mail B&W TIFF,

E-Mail Color PDF,

E-Mail Color JPEG,

E-Mail Color XPS,

E-Mail Gray PDF,

E-Mail Gray JPEG,

E-Mail Gray XPS.

4 Enter the telephone, fax number (up to 20 characters each) or E-mail address (up to 60 characters each). Use the chart on *Entering text* on page 176 to help you enter letters.

Press OK.



[®]Note

- If you selected an E-mail Registration Type in step 3 and save the E-mail address, you can only use the E-mail address when you are in Scan mode.
- If you selected the IFAX Registration Type in step 3 and save the E-mail address, you can only use the E-mail address when you are in Fax mode.

To save a fax/scan resolution along with the fax number/E-mail address, go to the appropriate step as shown in the following table.

Option selected in step 3	Go to step
Fax	6
IFAX	•
E-Mail B&W PDF	8
E-Mail B&W TIFF	•
E-Mail Color PDF	
E-Mail Color JPEG	9
E-Mail Color XPS	
E-Mail Gray PDF	
E-Mail Gray JPEG	•
E-Mail Gray XPS	



- When you do a broadcast and you have saved a scan profile along with the number or E-mail address, the scan profile of the One Touch, Speed Dial or Group number you chose first will be applied to the broadcast.
- For details about the file format, see Using the SCAN key in the Software User's Guide.
- 6 Select the resolution from Standard, Fine, S. Fine or Photo and go to step **12**.
- 7 Select the resolution from Standard, Fine or Photo and go to step 10.
- 8 Select the resolution from 200 dpi or 200 x 100 dpi.
 - If you chose E-Mail B&W PDF, go to step ①.
 - If you chose E-Mail B&W TIFF, go to step ②.

- 9 Select the resolution from 100 dpi, 200 dpi, 300 dpi or 600 dpi.
 - If you chose E-Mail Color PDF, go to step ①.
 - If you chose E-Mail Color JPEG or E-Mail Color XPS, go to step ②.
- Select the resolution from 100 dpi, 200 dpi or 300 dpi.
 - If you chose E-Mail Gray PDF, go to step ①.
 - If you chose E-Mail Gray JPEGor E-Mail Gray XPS, go to step ②.
- Select the PDF type from PDF, PDF/A, Secure PDF or Signed PDF that will be used to send to your PC.



If you choose Secure PDF, the machine will ask you to enter a fou-digit password using numbers 0-9 before it starts scanning.

- When the LCD displays your settings, press OK to confirm.
- 13 Press Stop/Exit.

Storing Speed Dial numbers

You can store your frequently used numbers as Speed Dial numbers, so that when you dial you will only have to press a few keys (for example: press Address Book, the number you want to call and Send a fax). The machine can store 300 Speed Dial numbers (001-300).

- 1 Press Address Book.
- 2 Press More.
- 3 Press Set Speed Dial.
- 4 Do one of the following:
 - Enter the name (up to 15 characters) by pressing the buttons on the Touchscreen. Use the chart on Entering text on page 176 to help you enter letters.

Press OK.

- Press OK to store the number or E-mail address without a name.
- 5 Press ◀ or ▶ to select

Fax,

IFAX,

E-Mail B&W PDF,

E-Mail B&W TIFF,

E-Mail Color PDF,

E-Mail Color JPEG,

E-Mail Color XPS,

E-Mail Gray PDF,

E-Mail Gray JPEG,

E-Mail Gray XPS.

6 Enter the fax/telephone number (up to 20 characters each) or E-mail address (up to 60 characters each). Use the chart on *Entering text* on page 176 to help you enter letters.

Press OK.



- If you selected an E-mail Registration Type in step and save the E-mail address, you can only use the E-mail address when you are in Scan mode.
- If you selected the IFAX Registration Type in step 6 and save the E-mail address, you can only use the E-mail address when you are in Fax mode.
- 7 To save a fax/scan resolution along with the fax number/E-mail address, go to the appropriate step as shown in the following table.

Option selected in step 6	Go to step
Fax	8
IFAX	9
E-Mail B&W PDF	•
E-Mail B&W TIFF	
E-Mail Color PDF	
E-Mail Color JPEG	•
E-Mail Color XPS	
E-Mail Gray PDF	
E-Mail Gray JPEG	12
E-Mail Gray XPS	



- When you do a broadcast and you have saved a scan profile along with the number or E-mail address, the scan profile of the One Touch, Speed Dial or Group number you chose first will be applied to the broadcast.
- For details about the file format, see Using the SCAN key in the Software User's Guide.
- 8 Select the resolution from Standard, Fine, S. Fine or Photo and go to step 1.
- 9 Select the resolution from Standard, Fine or Photo and go to step @.

- Select the resolution from 200 dpi or 200 x 100 dpi.
 - If you chose E-Mail B&W PDF, go to step 18.
 - If you chose E-Mail B&W TIFF, go to step 4.
- Select the resolution from 100 dpi, 200 dpi, 300 dpi or 600 dpi.
 - If you chose E-Mail Color PDF, go to step 18.
 - If you chose E-Mail Color JPEG or E-Mail Color XPS, go to step 4.
- Select the resolution from 100 dpi, 200 dpi or 300 dpi.
 - If you chose E-Mail Gray PDF, go to step ❸.
- Select the PDF type from PDF, PDF/A, Secure PDF or Signed PDF that will be used to send to your PC.



If you choose Secure PDF, the machine will ask you to enter a four-digit password using numbers 0-9 before it starts scanning.

- Enter a three-digit Speed Dial location number (001-300).
 Press OK.
- When the LCD displays your settings, press OK to confirm.
- 16 Press Stop/Exit.

Changing or Deleting One Touch and Speed Dial numbers

You can change or delete a One Touch or Speed Dial number that has already been stored.

If the stored number has a scheduled job, such as a delayed fax or a fax forwarding number, it will be dimmed on the LCD. You cannot select the number to make changes or to delete it unless you first cancel the scheduled job. (See Checking and canceling waiting jobs in chapter 3 of the Advanced User's Guide.)

- 1 Press Address Book.
- Press More.
- 3 Do one of the following:
 - Press Change to edit the name, number or E-mail address and go to step 4.
 - Press Delete to delete all information in a Speed Dial or One Touch number.

Select the number you want to delete by pressing it to display a red check mark.

Press OK.

When Erase This Data? appears, press Yes to accept it.

Go to step 8.

Press ▲ or ▼ to display the number you want to change.
Press the number you want to change.



One Touch Dial numbers begin with *. Speed Dial numbers begin with #.

Press Name:
 Number/Address:
 Resolution: Or

PDF Type:

- 6 Do one of the following:
 - If you chose Name:, enter the name (up to 15 characters) by pressing the buttons on the Touchscreen.

Press OK.

If you chose Number/Address:, enter the new number (up to 20 digits) or E-mail address (up to 60 digits) by pressing the buttons on the Touchscreen.

Press OK.

- If you chose Resolution:, press one of the available resolution options displayed on the Touchscreen.
- If you chose PDF Type:, press one of the available file type options displayed on the Touchscreen.



How to change the stored name or number:

If you want to change a character, press ◀ or ▶ to position the cursor under the character you want to change, and then press ☑. Re-enter the character.

The LCD will display your new setting.

- 7 Do one of the following:
 - When you are finished making changes, press OK.
 - To change more details, go to step **6**.
- 8 Press Stop/Exit.

8

Making copies


How to copy

The following steps show the basic copy operation. For details about each option, see *Advanced User's Guide*.



When you want to make a copy, press (COPY) to illuminate it in blue.

■ Make sure you are in Copy mode.



■ The LCD shows:



You can enter the number of copies you want by pressing the + and - buttons on the Touchscreen.



The default setting is Fax mode. You can change the amount of time that the machine stays in Copy mode after the last copy operation. (See *Mode Timer* in *Chapter 1* of the *Advanced User's Guide*.)

- Do one of the following to load your document:
 - Place the document face up in the ADF. (See Using the automatic document feeder (ADF) on page 26.)
 - Load your document *face down* on the scanner glass. (See *Using the scanner glass* on page 27.)



Press Black Start or Color Start.



If the LCD shows Please Wait and the machine stops copying while you are making multiple copies, please wait for 30 to 40 seconds until the machine finishes the color registrations and cleaning process of the belt unit.

Stop copying

To stop copying, press Stop/Exit.

Copy settings

Press **COPY** and then press **◄** or **▶** to choose the setting you want. For details about changing the copy settings, see *Copy* settings in *Chapter 7* of the *Advanced User's Guide*.

You can change the following copy settings:

- Quality
- Enlarge/Reduce
- Duplex Copy
- Tray Use
- Brightness
- Contrast
- Stack/Sort
- Page Layout
- 2in1(ID) (Page Layout)
- Color Adjust (Saturation)
- Set New Default
- Factory Reset
- Favorite Settings

9

Printing data from a USB Flash memory drive or digital camera supporting mass storage

With the Direct Print feature, you do not need a computer to print data. You can print by just plugging your USB Flash memory drive into the machine's USB direct interface. You can also connect and print directly from a camera set to USB mass storage mode.



- Some USB Flash memory drives may not work with the machine.
- If your camera is in PictBridge mode, you cannot print data. Please refer to the documentation supplied with your camera to switch from PictBridge mode to mass storage mode.


Creating a PRN or PostScript[®] 3[™] file for direct printing



The screens in this section may vary depending on your application and operating system.

1 From the menu bar of an application, click **File**, then **Print**.

Choose Brother MFC-XXXX Printer (1) and check the Print to file box (2). Click Print.



Choose the folder you want to save the file to and enter the file name if you are prompted to.

If you are prompted for a file name only, you can also specify the folder you want to save the file in by entering the directory name. For example:


C:\Temp\FileName.prn


If you have a USB Flash memory drive or digital camera connected to your computer, you can save the file directly to the USB Flash memory drive.

Printing data directly from the USB Flash memory drive or digital camera supporting mass storage

1 Connect your USB Flash memory drive or digital camera to the USB direct interface (1) on the front of the machine.

Press Direct Print. Your machine will enter Direct Print Mode.







- Make sure your digital camera is turned on.
- If your machine has been set to Secure Function Lock On, you may not be able to access Direct Print. (For explanations about error messages that may occur, see Switching Users in chapter 2 of the Advanced User's Guide.)
- Press ▲ or ▼ to choose the folder name and file name you want to print. If you have chosen the folder name, press ▲ or ▼ to choose the file name you want to print.



Note

- Your digital camera must be switched from PictBridge mode to mass storage mode.
- If you want to print an index of the files, press Index Print on the Touchscreen. Press Black Start or Color Start to print the data.
- When the machine is in Deep Sleep mode, the LCD does not show any information even if you connect a USB flash memory drive to the USB direct interface. Press the Touchscreen or any key to wake up the machine. Press Direct Print on the Touchscreen, the LCD will show the Direct Print menu.
- 3 Enter the number of copies you want by pressing the + and buttons on the Touchscreen.
- 4 Do one of the following:
 - Press Print Settings. Go to step **5**.
 - If you do not need to change the current default settings, go to step 7.

Press ▲ or ▼ to display an option setting you need to change. Press the option and change the setting.



You can choose the following settings:

Paper Size
Paper Type
Multiple Page
Orientation
Duplex

Collate

Tray Use

Print Quality

PDF Option

- Depending on the file type, some of these settings may not appear.
- 6 Do one of the following:
 - If you want to change other option settings repeat step 6.
 - If you do not want to change any other options, press and go to step ?.
- Press Black Start or Color Start to print the data.

! IMPORTANT

- To prevent damage to your machine, DO NOT connect any device other than a digital camera or USB Flash memory drive to the USB direct interface.
- DO NOT remove the USB Flash memory drive or digital camera from the USB direct interface until the machine has finished printing.

Changing the default settings for direct print

You can change the default settings for Direct Print.

- 1 Connect your USB Flash memory drive or digital camera to the USB direct interface on the front of the machine.
- 2 Press Direct Print on the LCD.
- 3 Press Default Settings.
- Press ▲ or ▼ to display the setting you want to change.
 Press the setting.
- 5 Press the new option you want. Repeat steps 4 to 5 for each setting you want to change.



// Note

How to display all available options:

When the LCD displays the ◀ and ▶ buttons, press ◀ or ▶ to display all available options.

How to print from a computer

Printing a document

The machine can receive data from your computer and print it. To print from a computer, install the printer driver. (See Printing for Windows® or Printing and Faxing for Macintosh in the Software User's Guide for details about the print settings.)

- 1) Install the Brother printer driver on the Installation CD-ROM. (See the Quick Setup Guide.)
- 2 From your application, choose the Print command.
- Choose the name of your machine in the Print dialog box and click Properties.
- 4 Choose the settings you want in the Properties dialog box.
 - Paper Size
 - Orientation
 - Copies
 - Media Type
 - Print Quality
 - Color / Mono
 - Multiple Page
 - Duplex / Booklet
 - Paper Source

Click OK.

Click **OK** to begin printing.

11

How to scan to a computer

Scanning a document as PDF file using ControlCenter4 (Windows®)


(For Macintosh users) See Scanning in the Software User's Guide.



The screens on your PC may vary depending on your model.

ControlCenter4 is a software utility that lets you quickly and easily access the applications you use most often. Using ControlCenter4 eliminates the need to manually launch specific applications. You can use ControlCenter4 on your computer.

- 1 Load your document. (See How to load documents on page 26.)
- Open ControlCenter4 by clicking start/All Programs/Brother/XXX-XXXX (where XXX-XXXX is your model name)/ControlCenter4. The ControlCenter4 application will open.
- 3 Choose Home Mode or Advanced Mode before you use ControlCenter4.




4 Make sure the machine you want to use is selected from the **Model** pull-down list.

5 Set the file type for saving to a folder. By default, the scanned data is saved as **JPEG** (*.jpg). Click **Configuration**, and then select **Button settings**, **Scan** and **File**.



The configuration dialog box appears. You can change the default settings.



- 1 Choose PDF (*.pdf) from the File Type pull-down list.
- 2 You can enter the file name you want to use for the document.
- 3 You can save the file to the default folder, or choose your preferred folder by clicking the **Browse** button.
- 4 You can choose a scanning resolution from the **Resolution** pull-down list.
- 5 You can choose the document size from the pull-down list.
- 6 Click **OK**.

7 Click File.

The machine starts the scanning process. The folder where the scanned data is saved will open automatically.



11

Changing the SCAN key settings

Before scanning

To use the machine as a scanner, install a scanner driver. If the machine is on a network, configure it with a TCP/IP address.

- Install the scanner drivers on the Installation CD-ROM. (See the Quick Setup Guide.)
- Configure the machine with a TCP/IP address if network scanning does not work. (See Configuring Network Scanning in the Software User's Guide.)


SCAN key settings

You can change your machine's **SCAN** key settings using ControlCenter4.

- Open ControlCenter4 by clicking start/All Programs/Brother/XXX-XXXX (where XXX-XXXX is your model name)/ControlCenter4. The ControlCenter4 application will open.
- Make sure the machine you want to use is selected from the Model pull-down list.
- 3 Click the **Device Settings** tab.
- 4 Click Device Scan Settings.



5 Choose the File tab. You can change the default settings.



- 1 You can choose the file type from the pull-down list.
- 2 You can enter the file name you want to use for the document.
- 3 You can save the file to the default folder, or choose your preferred folder by clicking the **Browse** button.
- 4 You can choose a scanning resolution from the **Resolution** pull-down list.
- 5 You can choose the document size from the pull-down list.
- 6 Click **OK**.

Scanning using the SCAN key

- 1 Load your document. (See *How to load documents* on page 26.)
- Press (SCAN).
- 3 Press Scan to PC.
- 4 Press File.
- (For Network users)

Press ▲ or ▼ to choose the destination computer you want to send to.

Press OK.

If the LCD prompts you to enter a PIN number, enter the 4-digit PIN number for the destination computer using the dial pad on the control panel.

Press OK.

- 6 Do one of the following:
 - If you want to change the duplex setting, press Duplex Scan. Then press Off, DuplexScan :LongEdge Or DuplexScan :ShortEdge.
 - To start scanning without changing additional settings, go to step <a>T.
- Press Black Start or Color Start. The machine starts the scanning process.



Choose the scan mode you want.

Scan to:

- USB
- Network
- FTP
- E-mail (Server)
- E-mail (Scan to PC)
- Image (Scan to PC)
- OCR (Scan to PC)
- File (Scan to PC)



Routine maintenance

Replacing the consumable items

The following messages appear on the LCD in the Ready mode. These messages provide advanced warnings to replace the consumable items before they reach the end of their life. To avoid any inconvenience, you may want to buy spare consumable items before the machine stops printing.

Toner cartridge	Drum unit	
See Replacing a Toner cartridge on page 68.	See Replacing the drum unit on page 79.	
Order No. TN-310BK, TN-315BK, TN-310C, TN-315C, TN-310M, TN-315M, TN-310Y, TN-315Y	Order No. DR-310CL	
Belt unit	Waste toner box	
See Replacing the belt unit on page 86.	See Replacing the waste toner box on page 92.	
Order No. BU-300CL	Order No. WT-300CL	

LCD messages	Consumable item to replace	Approximate life	How to replace	Order No.
Toner Low Prepare New Toner Cartridge.X	Toner cartridge X = Black, Cyan, Magenta, Yellow	<black> 2,500 pages ^{1 2 3} 6,000 pages ^{1 2 4} <cyan, magenta,="" yellow=""> 1,500 pages ^{1 2 3} 3,500 pages ^{1 2 4}</cyan,></black>	See page 68.	TN-310BK ³ , TN-315BK ⁴ , TN-310C ³ , TN-315C ⁴ , TN-310M ³ , TN-315M ⁴ , TN-310Y ³ , TN-315Y ⁴
Replace Parts WT Box End Soon	Waste toner box	50,000 pages ¹	See page 92.	WT-300CL

¹ Letter or A4 size single-sided pages.

² Approx. cartridge yield is declared in accordance with ISO/IEC 19798.

³ Standard toner cartridge

⁴ High capacity toner cartridge

You will need to clean the machine regularly and replace the consumable items when the following messages are displayed on the LCD.

LCD messages	Consumable item to replace	Approximate life	How to replace	Order No.
Replace TonerX	Toner cartridge	<black></black>	See page 68.	TN-310BK ⁵ ,
	X = Black, Cyan, Magenta, Yellow	2,500 pages ^{1 2 5}		TN-315BK ⁶ ,
		6,000 pages ^{1 2 6}		TN-310C ⁵ , TN-315C ⁶ .
		<cyan, magenta,<br="">Yellow></cyan,>		TN-310M ⁵ , TN-315M ⁶ .
		1,500 pages ^{1 2 5}		TN-310Y ⁵ ,
		3,500 pages ^{1 2 6}		TN-315Y ⁶
Replace Parts Drum Unit	Drum unit	25,000 pages ^{1 3 4}	See page 80.	DR-310CL
Drum Stop				
Replace Parts Belt Unit	Belt unit	50,000 pages ¹	See page 86.	BU-300CL
Replace WT Box	Waste toner box	50,000 pages ¹	See page 92.	WT-300CL
Replace Parts Fuser Unit	Fuser unit	100,000 pages ¹	Call your dealer or Brother Customer Service for a replacement fuser unit.	
Replace Parts Laser Unit	Laser unit	100,000 pages ¹	Call your dealer or Brother Customer Service for a replacement laser unit.	
Replace Parts PF Kit 1	Paper feeding kit 1	100,000 pages ¹	Call your dealer or Brother Customer Service for a replacement paper feeding kit 1.	
Replace Parts PF Kit 2	Paper feeding kit 2	100,000 pages ¹	Call your dealer or Brother Customer Service for a replacement paper feeding kit 2.	
Replace Parts PF Kit MP	Paper feeding kit MP	50,000 pages ¹	Call your dealer or Brother Customer Service for a replacement paper feeding kit MP.	

Letter or A4 size single-sided pages.

² Approx. cartridge yield is declared in accordance with ISO/IEC 19798.

³ 1 page per job.

⁴ Drum life is approximate and may vary by type of use.

⁵ Standard toner cartridge

⁶ High capacity toner cartridge

A

Note

- Go to http://www.brother.com/original/index.html for instructions on how to return your used consumable items to the Brother collection program. If you choose not to return your used consumable, please discard the used consumable according to local regulations, keeping it separate from domestic waste. If you have questions, call your local waste disposal office.
- We recommend placing used consumable items on a piece of paper to prevent accidentally spilling or scattering the material inside.
- If you use paper that is not a direct equivalent for the recommended paper, the life of consumable items and machine parts may be reduced.
- The projected life of the toner cartridges is based on ISO/IEC 19798. Frequency of replacement will vary depending on the complexity of printed pages, percentage of coverage and type of media used.

Replacing a Toner cartridge

Order No. For the Order No. of toner cartridges, see *Replacing the consumable items* on page 64.

The Standard toner cartridges can print approximately 2,500 pages (black) or approximately 1,500 pages (cyan, magenta, yellow) ¹. The High Yield toner cartridges can print approximately 6,000 pages (black) or approximately 3,500 pages (cyan, magenta, yellow) ¹. Actual page count will vary depending on your average type of document. When a toner cartridge is running low, the LCD shows Toner Low.

The toner cartridges that come supplied with the machine are standard toner cartridges.

Approx. cartridge yield is declared in accordance with ISO/IEC 19798.



- It is a good idea to keep a new toner cartridge ready for use when you see the Toner Low warning.
- To ensure high quality printing, we recommend that you use only Genuine Brother Brand toner cartridges. When you want to buy toner cartridges, please call Brother Customer Service.
- We recommend that you clean the machine when you replace the toner cartridge. See Cleaning and Checking the machine in Appendix A of the Advanced User's Guide.
- If you change the print density setting for lighter or darker printing, the amount of toner used will change.
- Wait to unpack the toner cartridge until immediately before you put it into the machine.

Toner Low

If the LCD shows Toner Low
Prepare New Toner Cartridge.X, buy
a new toner cartridge and have it ready
before you get a Replace Toner message.
The LCD indicates the toner color that is near
the end of its life (Cyan, Magenta, Yellow or
Black).


Replace Toner

When the LCD shows Replace Toner the machine will stop printing until you replace the toner cartridge. The message on the LCD will indicate which color you need to replace.


A new or unused genuine Brother toner cartridge will reset the Replace Toner mode.

Replacing the toner cartridges


- 1 Make sure that the machine is turned on.
- 2 Press the front cover release button and then open the front cover.



Hold the green handle of the drum unit. Pull the drum unit out until it stops.



4 Hold the handle of the toner cartridge and slightly push it toward the machine to unlock it. Then pull it out of the drum unit. Repeat this for all the toner cartridges.



WARNING

DO NOT put a toner cartridge into a fire. It could explode, resulting in injuries.

DO NOT use cleaning materials that contain ammonia, alcohol, any type of spray or any type of flammable substance to clean the inside or outside of the machine. Doing this may cause a fire or electrical shock.

See To use the product safely in the Safety and Legal Booklet for how to clean the machine.








Be careful not to inhale toner.

IMPORTANT


- We recommend that you place the drum unit and/or the toner cartridge on a clean, flat, level, stable surface with a sheet of disposable paper or cloth underneath it in case you accidentally spill or scatter toner.
- Handle the toner cartridge carefully. If toner scatters on your hands or clothes, immediately wipe or wash it off with cold water.
- To avoid print quality problems, DO NOT touch the shaded parts shown in the illustration.






- Be sure to seal up the toner cartridge tightly in a suitable bag so that toner powder does not spill out of the cartridge.
- Go to http://www.brother.com/original/
 index.html for instructions on how to return your used consumable items to the Brother collection program. If you choose not to return your used consumable, please discard the used consumable according to local regulations, keeping it separate from domestic waste. If you have questions, call your local waste disposal office.

5 Push to release the latches of the corona wire cover (1), and then open the cover.




6 Clean the corona wires inside the drum unit by gently sliding the green tabs from left to right and right to left several times.






Be sure to return the tab to the home position (**A**) (1). If you do not, printed pages may have a vertical stripe.

Close the corona wire cover.







- 8 Repeat steps **5** to **7** to clean each of three remaining corona wires.
- Unpack the new toner cartridge. Gently shake it from side to side several times to distribute the toner evenly inside the cartridge.



! IMPORTANT


- Wait to unpack the new toner cartridge until immediately before you put it in the machine. If a toner cartridge is left unpacked for a long time, the toner life will be shortened.
- If an unpacked drum unit is put in direct sunlight or room light, the unit may be damaged.
- · Brother strongly recommends that you DO NOT refill the toner cartridge provided with your machine. We also strongly recommend that you continue to use only Genuine Brother Brand replacement toner cartridges. Use or attempted use of potentially incompatible toner and/or cartridges in the Brother machine may cause damage to the machine and/or may result in unsatisfactory print quality. Our warranty coverage does not apply to any problem that is caused by the use of unauthorized third party toner and/or cartridges. To protect your investment and obtain premium performance from the Brother machine, we strongly recommend the use of Genuine Brother Supplies.







! IMPORTANT

Put the toner cartridge in the drum unit immediately after you have removed the protective cover. To prevent any degradation to the print quality, DO NOT touch the shaded parts shown in the illustrations.



Hold the handle of the toner cartridge and slide the toner cartridge into the drum unit, then slightly pull it toward you until you hear it click into place. Make sure that you match the toner cartridge color to the same color label on the drum unit. Repeat this for all the toner cartridges.






C - Cyan

M - Magenta

Y - Yellow

K - Black

12 Push the drum unit in until it stops.



13 Close the front cover of the machine.




After you replace a toner cartridge, DO NOT turn off the machine's power switch or open the front cover until the LCD clears the Please Wait message and returns to Ready mode.


Cleaning the corona wires

If you have print quality problems, clean the four corona wires as follows:


1 Press the front cover release button and then open the front cover.




2 Hold the green handle of the drum unit. Pull the drum unit out until it stops.




3 Hold the handle of the toner cartridge and slightly push it toward the machine to unlock it. Then pull it out of the drum unit. Repeat this for all the toner cartridges.



4 Push to release the latches of the corona wire cover (1), and then open the cover.




5 Clean the corona wires inside the drum unit by gently sliding the green tabs from left to right and right to left several times.






- Be sure to return the tab to the home position (▲) (1). If you do not, printed pages may have a vertical stripe.
- We recommend that you clean the corona wire for each color. If you want to clean only the corona wire of the color that caused the print quality problem, see the illustration below to identify the position of each of the corona wires.



- C: Corona wire for Cyan
- M: Corona wire for Magenta
- Y: Corona wire for Yellow
- K: Corona wire for Black
- c: Cyan toner position label
- m: Magenta toner position label
- y: Yellow toner position label
- k: Black toner position label


The corona wires for black, yellow and magenta are located under the next toner cartridge. For example, when you clean the corona wire for black, you need to remove the yellow toner cartridge to access the corona wire for black.


6 Close the corona wire cover.




Repeat steps 4 to 6 to clean each of three remaining corona wires.

8 Hold the handle of the toner cartridge and slide the toner cartridge into the drum unit, then slightly pull it toward you until you hear it click into place. Make sure that you match the toner cartridge color to the same color label on the drum unit. Repeat this for all the toner cartridges.





C - Cyan M - Magenta Y - Yellow K - Black 9 Push the drum unit in until it stops.



10 Close the front cover of the machine.

A

Replacing the drum unit

Order No. DR-310CL

A new drum unit can print approximately 25,000 Letter or A4 size single-sided pages.



- There are many factors that determine the actual drum life, such as the temperature, humidity, type of paper, type of toner used and so on. Under ideal conditions, the average drum life is estimated at approximately 25,000 pages. The actual number of pages that your drum will print may be significantly less than this estimate. Because we have no control over the many factors that determine the actual drum life, we cannot guarantee a minimum number of pages that will be printed by your drum.
- For best performance, use only genuine Brother toner. The machine should be used only in a clean, dust-free environment with adequate ventilation.
- Printing with a non-Brother drum unit may reduce not only the print quality but also the quality and life of the machine itself.
 Warranty coverage does not apply to problems caused by the use of a non-Brother drum unit.

Drum Error

The corona wires have become dirty. Clean the corona wires in the drum unit. (See *Cleaning the corona wires* on page 74.)

If you cleaned the corona wires and Drum Error was not cleared then the drum unit is at the end of its life. Replace the drum unit with a new one.

Replace Parts Drum

The drum unit has exceeded its rated life. Please replace the drum unit with a new one. We recommend a genuine Brother drum unit be installed at this time.

After replacement, reset the drum counter by following the instructions included with the new drum unit.

Drum Stop

We cannot guarantee the print quality. Please replace the drum unit with a new one. We recommend a genuine Brother drum unit be installed at this time.


After replacement, reset the drum counter by following the instructions included with the new drum unit.

Replacing the drum unit


! IMPORTANT

- While removing the drum unit, handle it carefully because it may contain toner. If toner scatters on your hands or clothes, immediately wipe or wash it off with cold water.
- Every time you replace the drum unit, clean the inside of the machine. (See Cleaning and Checking the machine in Appendix A of the Advanced User's Guide.)
- 1 Make sure that the machine is turned on.


2 Press the front cover release button and then open the front cover.



Hold the green handle of the drum unit.
Pull the drum unit out until it stops.




4 Turn the green lock lever (1) at the left of the machine counterclockwise to the release position. Holding the green handles of the drum unit, lift the front of the drum unit and remove it from the machine.




! IMPORTANT

- We recommend that you place the drum unit and/or the toner cartridge on a clean, flat surface with a sheet of disposable paper or cloth underneath it in case you accidentally spill or scatter toner.
- To prevent damage to the machine from static electricity, DO NOT touch the electrodes shown in the illustration.



 Hold the green handles of the drum unit when you carry it. DO NOT hold the sides of the drum unit. Hold the handle of the toner cartridge and slightly push it to unlock it. Then pull it out of the drum unit. Repeat this for all the toner cartridges.



A WARNING

DO NOT put a toner cartridge into a fire. It could explode, resulting in injuries.

DO NOT use cleaning materials that contain ammonia, alcohol, any type of spray, or any type of flammable substance to clean the outside or inside of the machine. Doing this may cause a fire or electrical shock.

See To use the product safely in the Safety and Legal Booklet for how to clean the machine.








Be careful not to inhale toner.

Â١

! IMPORTANT


- Handle the toner cartridge carefully. If toner scatters on your hands or clothes, immediately wipe or wash it off with cold water.
- We recommend that you place the drum unit and/or the toner cartridge on a clean, flat surface with a sheet of disposable paper or cloth underneath it in case you accidentally spill or scatter toner.
- To avoid print quality problems, DO NOT touch the shaded parts shown in the illustrations.



Note


- Be sure to seal up the used drum unit tightly in a bag so that toner powder does not spill out of the unit.
- Go to http://www.brother.com/original/
 index.html for instructions on how to return your used consumable items to the Brother collection program. If you choose not to return your used consumable, please discard the used consumable according to local regulations, keeping it separate from domestic waste. If you have questions, call your local waste disposal office.

6 Unpack the new drum unit and remove the protective cover.




! IMPORTANT

 To avoid print quality problems, DO NOT touch the shaded parts shown in the illustrations.



 Wait to unpack the new drum unit until immediately before you put it in the machine. Exposure to direct sunlight or room light may damage the drum unit.

7 Hold the handle of the toner cartridge and slide the toner cartridge into the new drum unit, then slightly pull it toward you until you hear it click into place. Make sure that you match the toner cartridge color to the same color label on the drum unit. Repeat this for all the toner cartridges.




C - Cyan

M - Magenta


Y - Yellow

K - Black


8 Make sure the green lock lever (1) is in the release position as shown in the illustration.




9 Match the guide ends (2) of the drum unit to the ▶ marks (1) on both sides of the machine, then gently slide the drum unit into the machine until it stops at the green lock lever.



10 Turn the green lock lever (1) clockwise to the lock position.



11 Push the drum unit in until it stops.



Close the front cover of the machine.

Resetting the drum counter

When you replace a drum unit with a new one, you will need to reset the drum counter by completing the following steps:

- 1 Press MENU.
- Press ▲ or ▼ to display
 Machine Info..
 Press Machine Info..
- 3 Press Reset Menu.
- 4 Press Drum.
- 5 The machine will display
 Reset Drum?.
 Press Yes.
- 6 Press Stop/Exit.

Replacing the belt unit

Order No. BU-300CL

A new belt unit can print approximately 50,000 Letter or A4 size single-sided pages.


Replace Parts Belt Unit

When the Replace Parts Belt Unit message appears on the LCD, you will need to replace the belt unit:


! IMPORTANT

- DO NOT touch the surface of the belt unit.
 If you touch it, it could degrade print quality.
- Damage caused by incorrect handling of the belt unit may void your warranty.
- 1 Make sure that the machine is turned on.


2 Press the front cover release button and then open the front cover.



3 Hold the green handle of the drum unit. Pull the drum unit out until it stops.




4 Turn the green lock lever (1) at the left of the machine counterclockwise to the release position. Holding the green handles of the drum unit, lift the front of the drum unit and remove it from the machine.




! IMPORTANT

- We recommend that you place the drum unit and/or the toner cartridge on a clean, flat surface with a sheet of disposable paper or cloth underneath it in case you accidentally spill or scatter toner.
- To prevent damage to the machine from static electricity, DO NOT touch the electrodes shown in the illustration.




 Hold the green handles of the drum unit when you carry it. DO NOT hold the sides of the drum unit.

 To avoid print quality problems, DO NOT touch the shaded parts shown in the illustrations.





5 Hold the green handle of the belt unit with both hands and lift the belt unit up, then pull it out.



! IMPORTANT


To avoid print quality problems, DO NOT touch the shaded parts shown in the illustration.






6 Unpack the new belt unit.


7 Put the new belt unit back in the machine. Make sure the belt unit is level and fits firmly into place.




8 Make sure the green lock lever (1) is in the release position as shown in the illustration.




Match the guide ends (2) of the drum unit to the ► marks (1) on both sides of the machine, then gently slide the drum unit into the machine until it stops at the green lock lever.



10 Turn the green lock lever (1) clockwise to the lock position.



11 Push the drum unit in until it stops.



12 Close the front cover of the machine.

Resetting the belt unit counter

When you replace a belt unit with a new one, you will need to reset the belt unit counter by completing the following steps:

- 1 Press MENU.
- Press ▲ or ▼ to display
 Machine Info..
 Press Machine Info..
- 3 Press Reset Menu.
- 4 Press Belt Unit.
- 5 The machine will display Reset Belt Unit?.
 Press Yes.
- 6 Press Stop/Exit.

Replacing the waste toner box

Order No. WT-300CL

A new waste toner box can print approximately 50,000 Letter or A4 size single-sided pages.

Replace Parts WT Box End Soon

If the LCD shows Replace Parts WT Box End Soon, it means the waste toner box is near the end of its life. Buy a new waste toner box and have it ready before you get a Replace WT Box message.

Replace WT Box

When the Replace WT Box message appears on the LCD, you will need to replace the waste toner box:

▲ WARNING

DO NOT put the waste toner box into a fire. It could explode.


Be careful not to spill the toner. DO NOT inhale or allow it to get into your eyes.

! IMPORTANT


DO NOT reuse the waste toner box.

Make sure that the machine is turned on.


2 Press the front cover release button and then open the front cover.



Hold the green handle of the drum unit.
Pull the drum unit out until it stops.




4 Turn the green lock lever (1) at the left of the machine counterclockwise to the release position. Holding the green handles of the drum unit, lift the front of the drum unit and remove it from the machine.




! IMPORTANT


- We recommend that you place the drum unit and/or the toner cartridge on a clean, flat surface with a sheet of disposable paper or cloth underneath it in case you accidentally spill or scatter toner.
- To prevent damage to the machine from static electricity, DO NOT touch the electrodes shown in the illustration.



 Hold the green handles of the drum unit when you carry it. DO NOT hold the sides of the drum unit. To avoid print quality problems, DO NOT touch the shaded parts shown in the illustrations.





5 Hold the green handle of the belt unit with both hands and lift the belt unit up, then pull it out.




! IMPORTANT

To avoid print quality problems, DO NOT touch the shaded parts shown in the illustration.






6 Remove the two pieces of orange packing material and discard them.





This step is only necessary when you are replacing the waste toner box for the first time, and are not required for the replacement waste toner box. The orange packing pieces are installed at the factory to protect your machine during shipment.

7 Hold the green handle of the waste toner box and remove the waste toner box from the machine.




A CAUTION

Handle the waste toner box carefully in case you accidentally spill or scatter toner. If toner scatters on your hands or clothes, immediately wipe or wash it off with cold water.




Discard the used waste toner box according to local regulations, keeping it separate from domestic waste. If you have questions, call your local waste disposal office.


8 Unpack the new waste toner box and put the new waste toner box in the machine using the green handle. Make sure the waste toner box is level and fits firmly into place.




9 Put the belt unit back into the machine. Make sure the belt unit is level and fits firmly into place.




Make sure the green lock lever (1) is in the release position as shown in the illustration.




11 Match the guide ends (2) of the drum unit to the ▶ marks (1) on both sides of the machine, then gently slide the drum unit into the machine until it stops at the green lock lever.



12 Turn the green lock lever (1) clockwise to the lock position.



13 Push the drum unit in until it stops.



14 Close the front cover of the machine.

B

Troubleshooting

Error and maintenance messages

As with any sophisticated office product, errors may occur and consumable items may need to be replaced. If this happens, your machine identifies the error or required routine maintenance and shows the appropriate message. The most common error and maintenance messages are shown below.

You can correct most errors and perform routine maintenance by yourself. If you need more help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips:

Visit us at http://solutions.brother.com/.

Error Message	Cause	Action
Access Denied	The function you want to use is restricted by Secure Function Lock.	Contact your administrator to check your Secure Function Lock Settings.
Access Error	The device is removed from the USB direct interface while the data is processing.	Press Stop/Exit . Reinsert the device and try to print with Direct Print.
Calibration failed.	Calibration failed.	Turn off the machine. Wait a few seconds, then turn it on again.
		■ Put in a new drum unit. (See Replacing the drum unit on page 80.)
		■ Put in a new belt unit. (See Replacing the belt unit on page 86.)
		■ Put in a new waste toner box. (See Replacing the waste toner box on page 92.)
		If the problem continues, call Brother Customer Service.
Cartridge Error Put the Black (K) Toner Cartridge back in. 1 1 The toner cartridge color with the problem	The toner cartridge is not installed properly.	Pull out the drum unit and remove the toner cartridge for the color that is indicated on the LCD, then re-install the toner cartridge in the drum unit. Put the drum unit back into the machine again.
is shown in the message.		
Comm.Error	Poor telephone line quality caused a communication error.	Send the fax again or connect the machine to another telephone line. If the problem continues, call the telephone company and ask them to check your telephone line.

Error Message	Cause	Action
Condensation	One of the issues that can cause this error is that condensation may form inside the machine after a room temperature change.	Leave the machine powered on, and fully open the front cover. Wait 30 minutes, switch OFF and close the cover, then switch ON. If this does not clear the error, call Brother Customer Service.
Connection Fail	You tried to poll a fax machine that is not in Polled Waiting mode.	Check the other fax machine's polling setup.
Cooling Down Wait for a while	The temperature of the drum unit or toner cartridge is too hot. The machine will pause its current print job and go into cooling down mode. During the cooling down mode, you will hear the cooling fan running while the LCD shows Cooling Down, and Wait for a while.	Make sure that you can hear the fan in the machine spinning and that the exhaust outlet is not blocked by something. If the fan is spinning, remove any obstacles that surround the exhaust outlet, and then leave the machine turned on but do not use it for several minutes. If the fan is not spinning, disconnect the machine from the power for several minutes,
Cover is Open.	The front cover is not completely closed.	then reconnect it. Close the front cover of the machine.
Cover is Open	The ADF cover is not completely closed.	Close the ADF cover of the machine.
	The ADF is open while loading a document.	Close the ADF cover of the machine, then press Stop/Exit .
Cover is Open	The fuser cover is not completely closed or paper was jammed in the back of the machine when you turned on the power.	 Close the fuser cover of the machine. Make sure paper is not jammed inside the back of the machine, and then close the fuser cover and press Black Start or Color Start.
DIMM Error	The DIMM is not installed correctly.	■ Turn off the machine and remove the DIMM.
	The DIMM is broken.The DIMM does not meet the required specifications.	■ Confirm the DIMM meets the required specifications. (See <i>Memory board</i> in <i>Appendix B</i> of the <i>Advanced User's Guide</i> .)
		■ Re-install the DIMM correctly. Wait a few seconds, and then turn it on again.
		■ If this error message appears again, replace the DIMM with a new one. (See Installing extra memory in Appendix B of the Advanced User's Guide.)
Disconnected	The other person or other person's fax machine stopped the call.	Try to send or receive again.

Error Message	Cause	Action
Document Jam	The document was not inserted or fed properly, or the document scanned from the ADF was too long.	See Document jams on page 108 or Using the automatic document feeder (ADF) on page 26.
Drum Error	The corona wire on the drum unit needs to be cleaned.	Clean the corona wire on the drum unit. (See Cleaning the corona wires on page 74.)
Drum Stop	It is time to replace the drum unit.	Replace the drum unit. (See Replacing the drum unit on page 80.)
Duplex Disabled Close the Back Cover of the machine.	The back of the machine is not closed completely.	Close the back cover of the machine.
Duplex Disabled Reload paper, then press Start.	Although the size of paper in the paper tray matches the paper size that was selected from the control panel or printer driver, the machine has stopped printing when it encountered an additional, different size of paper in the tray.	Make sure the paper tray contains only the size of paper you select in either the control panel or printer driver, then press Black Start or Color Start .
	The paper tray was pulled out before the machine completed printing on both sides of the paper.	Re-install the paper tray and press Black Start or Color Start.
Fuser Error	The temperature of the fuser unit does not rise to a specified temperature within the specified time.	Turn the power switch off, wait a few seconds, and then turn it on again. Leave the machine for 15 minutes with the power on.
Jam Duplex	The fuser unit is too hot. The paper is jammed underneath Paper Tray 1 or in the fuser unit.	(See Paper is jammed underneath paper tray 1 on page 118.)
Jam Inside	The paper is jammed inside the machine.	(See Paper is jammed inside the machine on page 114.)
Jam MP	The paper is jammed in the MP tray of the machine.	(See Paper is jammed in the MP tray on page 110.)
Jam Rear	The paper is jammed in the back of the machine.	(See Paper is jammed at the back of the machine on page 112.)

Error Message	Cause	Action
Jam Tray 1 Jam Tray 2	The paper is jammed in the paper tray of the machine.	(See Paper is jammed in paper tray 1 or tray 2 on page 111.)
Limit Exceeded	The printing limit set by Secure Function Lock 2.0 was reached.	Contact your administrator to check your Secure Function Lock Settings.
Low Temperature	The room temperature is too low for the machine to operate.	Increase the room temperature to allow the machine to operate.
No Belt Unit	The belt unit is not installed properly.	Re-install the belt unit. (See Replacing the belt unit on page 86.)
No Paper	The machine is out of paper or	Do one of the following:
	paper is not properly loaded in the paper tray.	■ Refill the paper in the paper tray.
	the paper day.	Remove the paper and load it again.
		■ If the problem is not resolved, the paper pick-up roller may need to be cleaned. Clean the paper pick-up roller. (See Cleaning the paper pick-up rollers in Appendix A of the Advanced User's Guide.)
No Permission	Printing color documents is restricted by Secure Function Lock 2.0. The print job will be canceled.	Contact your administrator to check your Secure Function Lock Settings.
No Response/Busy	The number you dialed does not answer or is busy.	Verify the number and try again.
No Toner	The toner cartridge for the color indicated on the LCD is not installed correctly.	Pull out the drum unit. Take out the toner cartridge for the color indicated on the LCD, and then put it back into the drum unit.
No Tray	The paper tray indicated on the LCD is not installed properly.	Re-install the paper tray that is indicated on the LCD.
No Waste Toner	The waste toner box is not installed properly.	Re-install the waste toner box. (See Replacing the waste toner box on page 92.)

Error Message	Cause	Action
Out of Memory	The machine's memory is full.	Fax sending or copy operation in progress
		Do one of the following:
		Press Black Start or Color Start to send or copy the scanned pages.
		Press Stop/Exit and wait until the other operations in progress finish, and then try again.
		■ Clear the faxes from the memory.
		Print the faxes that are stored in the memory to restore the memory to 100%. Then turn off Fax Storage to avoid storing more faxes in the memory. (See Printing a fax from the memory in Chapter 4 of the Advanced User's Guide and Fax Storage in Chapter 4 of the Advanced User's Guide.)
		Add optional memory. (See Memory board in Appendix B of the Advanced User's Guide.)
		Print operation in process
		Do one of the following:
		■ Reduce the print quality. (See Basic tab in the Software User's Guide.)
		■ Clear the faxes from the memory. (See the above explanation.)
Print Unable XX	The machine has a mechanical	Do one of the following:
	problem.	■ Turn the power switch off, wait for a few minutes, and then turn it on again. (See Transferring your faxes or Fax Journal report on page 107.)
		■ If the problem continues, call Brother Customer Service.
Protected Device	The protect switch of the USB Flash memory drive is on.	Turn off the protect switch of the USB Flash memory drive.

Error Message	Cause	Action
Registration	Registration failed.	Do one of the following:
failed		Turn off the machine's power switch. Wait a few seconds, then turn it on again.
		■ Try Manual Registration, MENU, Printer, Manual Regist (See Manual Registration in Appendix A of the Advanced User's Guide.)
		■ Put in a new belt unit. (See Replacing the belt unit on page 86.)
		If the problem continues, call Brother Customer Service.
Rename the File	There is already a file on the USB Flash memory drive with the same name as the file you are trying to save.	Change the name of the file on the USB Flash memory drive or the file you are trying to save.
Replace Parts Belt Unit	It is time to replace the belt unit.	Replace the belt unit. (See Replacing the belt unit on page 86.)
Replace Parts Drum Unit	It is time to replace the drum unit.	Replace the drum unit.
		(See Replacing the drum unit on page 80.)
	The drum unit counter was not reset when a new drum was installed.	Reset the drum unit counter.
		(See Resetting the drum counter on page 86.)
Replace Parts Fuser Unit	It is time to replace the fuser unit.	Call Brother Customer Service or a Brother Authorized Service Center to replace the fuser unit.
		To replace Fuser Unit call Brother Customer Service at:
		1-877-BROTHER (1-877-276-8437) (in USA) 1-877-BROTHER (in Canada)
		or to locate a Brother Authorized Service Center, visit us at:
		http://www.brother-usa.com/service/

Error Message	Cause	Action
Replace Parts PF Kit 1	It is time to replace the paper feeding kit.	Call Brother Customer Service or a Brother Authorized Service Center to replace the PF Kit.
PF Kit 2 PF Kit MP		To replace PF Kit call Brother Customer Service at:
		1-877-BROTHER (1-877-276-8437) (in USA) 1-877-BROTHER (in Canada)
		or to locate a Brother Authorized Service Center, visit us at:
		http://www.brother-usa.com/service/
Replace Parts WT Box End Soon	The waste toner box is near the end of its life.	Buy a new waste toner box before you get a Replace WT Box message.
Replace Toner X	The toner cartridge is at the end of its life.	Replace the toner cartridge for the color indicated on the LCD. (See <i>Replacing a Toner cartridge</i> on page 68.)
Replace WT Box	It is time to replace the waste toner box.	Replace the waste toner box. (See Replacing the waste toner box on page 92.)
Scan Unable XX	The machine has a mechanical problem.	■ Turn off the power switch and then turn it on again. (See <i>Transferring your faxes or Fax Journal report</i> on page 107.)
		If the problem continues, call Brother Customer Service.
	Document is too long for duplex scanning.	Press Stop/Exit . Use the suitable size of paper for duplex scanning. (See <i>Document Size</i> on page 179.)
Short paper	The length of the paper in the tray is too short for the machine to deliver it to the <i>Face down</i> output tray.	Open the back cover (face-up output tray) to let the printed paper out on the face up output tray. Remove the printed pages and then press Black Start or Color Start.
Size Error DX	The paper size defined in the printer driver is not usable for the automatic duplex printing.	Press Black Start or Color Start . Choose a paper size which is supported by the duplex tray. (See <i>Print media</i> on page 180.)
Size mismatch	The paper in the tray is not the correct size.	Load the correct size of paper in the tray and set the "Paper Size" (MENU, General Setup, Tray Setting). (See Paper Size and Type on page 18.)
Small paper	The paper size specified in the printer driver is too small for the machine to deliver it to the <i>Face down</i> output tray.	Open the back cover (face-up output tray) to let the printed paper out on the face up output tray and then press Black Start or Color Start.
Toner Error	One or more toner cartridges are not installed correctly.	Pull out the drum unit. Take out all the toner cartridges, and then put them back into the drum unit.

Error Message	Cause	Action
Toner Low	The toner cartridge is near the end of its life.	Buy a new toner cartridge for the color that is indicated on the LCD before you get a Replace Toner message.
Too Many Files	There are too many files stored on the USB Flash memory drive.	Reduce the number of files stored on the USB Flash memory drive.
Unusable Device	An incompatible or defective device has been connected to the USB direct interface.	Remove the USB Flash memory drive from the USB direct interface.

Transferring your faxes or Fax Journal report

If the LCD shows:

- Print Unable XX
- Scan Unable XX

We recommend transferring your faxes to another fax machine or to your PC. (See *Transferring faxes to another fax machine* on page 107 or *Transferring faxes to your PC* on page 107.)

You can also transfer the Fax Journal report to see if there are any faxes you need to transfer. (See *Transferring the Fax Journal report to another fax machine* on page 107.)



If there is an error message on the machine's LCD after the faxes have been transferred, disconnect the machine from the power source for several minutes, and then reconnect it.

Transferring faxes to another fax machine

If you have not set up your Station ID, you cannot enter fax transfer mode. (See Set your Station ID in the Quick Setup Guide.)

- 1 Press MENU.
- Press ▲ or ▼ to display Service.
 Press Service.
- Open Press Data Transfer.
- 4 Press Fax Transfer.
- 5 Do one of the following:
 - If the LCD shows No Data, there are no faxes left in the machine's memory. Press Stop/Exit.
 - Enter the fax number to which faxes will be forwarded.
- 6 Press Black Start or Color Start.

Transferring faxes to your PC

You can transfer the faxes from your machine's memory to your PC.

- 1 Make sure that you have installed MFL-Pro Suite on your PC, and then turn on PC-Fax Receiving on the PC. (For details about PC-Fax Receive, see PC-FAX receiving in the Software User's Guide.)
- 2 Make sure that you have set

 PC Fax Receive on the machine.

 (See PC-Fax Receive in Chapter 4 of
 the Advanced User's Guide.)

 If faxes are in the machine's memory
 when you set up PC-Fax Receive, the
 LCD will ask if you want to transfer the
 faxes to your PC.
- 3 Do one of the following:
 - To transfer all faxes to your PC, press Yes. You will be asked if you want a backup print.
 - To exit and leave the faxes in the memory, press No.
- 4 Press Stop/Exit.

Transferring the Fax Journal report to another fax machine

If you have not set up your Station ID, you cannot enter fax transfer mode. (See Set your station ID in the Quick Setup Guide.)


- 1 Press MENU.
- Press ▲ or ▼ to display Service.

 Press Service.
- 3 Press Data Transfer.
- 4 Press Report Trans..
- 5 Enter the fax number to which the Fax Journal report will be forwarded.
- 6 Press Black Start or Color Start.

Document jams

Document is jammed in the top of the ADF unit

- 1 Take out any paper from the ADF that is not jammed.
- Open the ADF cover.
- Pull the jammed document out to the left.



- 4 Close the ADF cover.
- 5 Press Stop/Exit.

Document is jammed under the document cover


- 1 Take out any paper from the ADF that is not jammed.
- 2 Lift the document cover.
- 3 Pull the jammed document out to the right.



- 4 Close the document cover.
- 5 Press Stop/Exit.

Removing small documents jammed in the ADF

- Lift the document cover.
- 2 Insert a piece of stiff paper, such as cardstock, into the ADF to push any small paper scraps through.



- Close the document cover.
- 4 Press Stop/Exit.

Document is jammed at the output tray

- 1 Take out any paper from the ADF that is not jammed.
- 2 Pull the jammed document out to the right.




3 Press Stop/Exit.

Paper jams

Paper is jammed in the MP tray

If the LCD shows Jam MP, follow these steps:


- 1 Remove the paper from the MP tray.
- Remove any jammed paper from in and around the MP tray.



Fan the paper stack, and then put it back in the MP tray.



When loading paper in the MP tray, make sure that the paper stays under the maximum paper mark (1) on both sides of the tray.




5 Press Black Start or Color Start to resume printing.

Paper is jammed in paper tray 1 or tray 2


If the LCD shows Jam Tray 1 or Jam Tray 2, follow these steps:

1 Pull the paper tray completely out of the machine.

For Jam Tray 1:




For Jam Tray 2:




▲ WARNING

DO NOT touch the shaded parts shown in the illustration. These rollers may be rotating at high speed and can pinch or entrap your hand.



Use both hands to slowly pull out the jammed paper.




! IMPORTANT

If the paper cannot easily be removed in this direction, stop and follow the instructions for *Paper is jammed inside the machine* on page 114.



Pulling out the jammed paper downwards allows you to remove the paper easier.

Make sure the paper is below the maximum paper mark (▼ ▼ ▼) (1) of the paper tray. While pressing the green paper-guide release lever, slide the paper guides to fit the paper size. Make sure that the guides are firmly in the slots. (See Loading paper in the standard paper tray on page 10.)




4 Put the paper tray firmly back in the machine.

Paper is jammed at the back of the machine

If the LCD shows Jam Rear, a paper jam occurred behind the back cover. Follow these steps:


- 1 Leave the machine turned on for 10 minutes to cool down.
- Open the back cover.




▲ WARNING

MHOT SURFACE

After you have just used the machine, some internal parts of the machine will be extremely hot. Wait for the machine to cool down before you touch the internal parts of the machine.




3 Pull the green tabs (2) at the left and right hand sides toward you and fold down the fuser cover (1).






If the envelope levers (3) inside the back cover are pulled down to the envelope position, lift these levers to the original position before pulling the green tabs (2) down.

4 Using both hands, gently pull the jammed paper out of the fuser unit.



5 Close the fuser cover (1).






If you are printing on envelopes, pull down the envelope levers (2) to the envelope position again before closing the back cover.

6 Fully close the back cover.


Paper is jammed inside the machine

If the LCD shows Jam Inside, follow these steps:


- 1 Turn off the machine's power switch.
 Unplug the telephone line cord first,
 disconnect all cables, and then unplug
 the power cord from the AC power
 outlet.
- 2 Press the front cover release button and then open the front cover.



Hold the green handle of the drum unit.
Pull the drum unit out until it stops.




Turn the green lock lever (1) at the left of the machine counterclockwise to the release position. Holding the green handles of the drum unit, lift the front of the drum unit and remove it from the machine.




! IMPORTANT


- We recommend that you place the drum unit and the toner cartridges on a clean, flat surface with a sheet of disposable paper or cloth underneath it in case you accidentally spill or scatter toner.
- To prevent damage to the machine from static electricity, DO NOT touch the electrodes shown in the illustration.




 Hold the green handles of the drum unit when you carry it. DO NOT hold the sides of the drum unit. 5 Pull out the jammed paper slowly.




6 Make sure the green lock lever (1) is in the release position as shown in the illustration.




Match the guide ends (2) of the drum unit to the ▶ marks (1) on both sides of the machine, then gently slide the drum unit into the machine until it stops at the green lock lever.



8 Turn the green lock lever (1) clockwise to the lock position.



9 Push the drum unit in until it stops.



10 Close the front cover of the machine.



If you turn off the machine while the LCD shows Jam Inside, the machine will print incomplete data from your computer. Before you turn on the machine, delete the print spool job on your computer.

Plug the machine's power cord back into the AC power outlet first, and reconnect all cables and the telephone line cord. Turn on the machine's power switch.

Paper is jammed underneath paper tray 1


If the LCD shows Jam Duplex, follow these steps:

- 1 Leave the machine turned on for 10 minutes to cool down.
- Pull the paper tray completely out of the machine.




WARNING

DO NOT touch the shaded parts shown in the illustration. These rollers may be rotating at high speed and can pinch or entrap your hand.




If paper is not caught inside the machine, turn the paper tray over and check underneath the paper tray.





DO NOT put the paper tray back in at this point.


4 If the paper is not caught in the paper tray, open the back cover.




▲ WARNING

⚠HOT SURFACE


After you have just used the machine, some internal parts of the machine will be extremely hot. Wait for the machine to cool down before you touch the internal parts of the machine.




5 Push down and pull the green tabs at the left and right hand sides toward you and fold down the fuser cover (1).



6 Using both hands, gently pull out the jammed paper.



7 Close the fuser cover (1).



- 8 Fully close the back cover.
- Put the paper tray firmly back in the machine.

В

If you are having difficulty with your machine

! IMPORTANT

For technical help, you must call the country where you bought the machine. Calls must be made *from within* that country.

If you think there is a problem, check the chart below and follow the troubleshooting tips. You can solve most problems by yourself.

If you need additional help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at http://solutions.brother.com/.

Printing or printing received faxes

Difficulties	Suggestions
■ Condensed print	Usually this is caused by a poor telephone connection. If your copy looks good,
■ Horizontal streaks	you probably had a bad connection, with static or interference on the telephone line. Ask the other party to send the fax again.
■ Top and bottom sentences are cut off	J. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1.
■ Missing lines	
Poor print quality	See Improving the print quality on page 131.
Vertical black lines when receiving	The corona wires for printing may be dirty. Clean the corona wires on the drum unit. (See <i>Cleaning the corona wires</i> on page 74.)
	The sender's scanner may be dirty. Ask the sender to make a copy to see if the problem is with the sending machine. Try receiving from another fax machine.
	If the problem continues, call Brother Customer Service at 1-877-BROTHER (1-877-276-8437) (in USA) or 1-877-BROTHER (in Canada).
Received faxes appear as split or blank pages.	If the received faxes are divided and printed on two pages or if you get an extra blank page, your paper size setting may not be correct for the paper you are using. (See <i>Paper Size and Type</i> on page 18.)
	Turn on Auto Reduction. (See <i>Printing a reduced incoming fax</i> in <i>Chapter 4</i> of the <i>Advanced User's Guide</i> .)

Telephone line or connections

Difficulties	Suggestions
Dialing does not work.	Check for a dial tone.
	Change Tone/Pulse setting. (See the Quick Setup Guide.) (Canada only)
	Check all line cord connections.
	Check that the machine is plugged in and switched on.
	Send a manual fax by pressing Hook or by lifting the handset of the external telephone and dialing the number. Wait to hear fax receiving tones before pressing Black Start or Color Start .

Telephone line or connections (continued)

Difficulties	Suggestions
The machine does not answer when called.	Make sure the machine is in the correct receive mode for your setup. (See <i>Receive Mode settings</i> on page 35.) Check for a dial tone. If possible, call your machine to hear it answer. If there is still no answer, check the telephone line cord connection. If you do not hear ringing when you call your machine, ask your telephone company to check the line.

Receiving Faxes

Difficulties	Suggestions
Cannot receive a fax.	Make sure your machine has a dial tone by pressing the Hook key. If you hear static or interference on your fax line, please contact your local telephone company.
	Check all line cord connections. Make sure the telephone line cord is plugged into the telephone wall jack and the LINE jack of the machine. If you subscribe to DSL or VoIP services, please contact your service provider for connection instructions.
	Make sure the machine is in the correct Receive Mode. This is determined by the external devices and telephone subscriber services you have on the same line as the Brother machine. (See <i>Receive Mode settings</i> on page 35.)
	If you have a dedicated fax line and want your Brother machine to automatically answer all incoming faxes, you should select Fax Only mode.
	If your Brother machine shares a line with an external answering machine, you should select the External TAD mode. In External TAD mode, your Brother machine will automatically receive incoming faxes and voice callers will be able to leave a message on your answering machine.
	If your Brother machine shares the line with a Voice Mail subscriber service, please see <i>Voice Mail</i> on page 37.
	If your Brother machine is on a line with the Distinctive Ring subscriber service, please see <i>Distinctive Ring</i> on page 38.
	If your Brother machine shares a line with other telephones and you want it to automatically answer all incoming faxes, you should select the Fax/Tel mode. In Fax/Tel mode, your Brother machine will automatically receive faxes and produce a pseudo/double-ring to alert you to answer voice calls.
	If you do not want your Brother machine to automatically answer any incoming faxes, you should select the Manual mode. In Manual mode, you must answer every incoming call and activate the machine to receive faxes.

Receiving Faxes (continued)

Difficulties	Suggestions
Cannot receive a fax. (continued)	Another device or service at your location may be answering the call before your Brother machine answers. To test this, lower the ring delay setting:
(55	■ If the answer mode is set to Fax Only or Fax/Tel, reduce the ring delay to 1 ring. (See <i>Ring Delay</i> on page 35.)
	If the answer mode is set to External TAD, reduce the number of rings programmed on your answering machine to 2.
	■ If the answer mode is set to Manual, DO NOT adjust the ring delay setting.
	Have someone send you a test fax:
	■ If you received the test fax successfully, your machine is operating properly. Remember to reset your ring delay or answering machine setting back to your original setting. If receiving problems recur after resetting the ring delay, then a person, device, or subscriber service is answering the fax call before the machine has a chance to answer.
	If you were not able to receive the fax, then another device or subscriber service may be interfering with your fax reception or there may be a problem with your fax line.
	If you are using a telephone answering machine (External TAD mode) on the same line as the Brother machine, make sure your answering machine is set up correctly. (See Connecting an external TAD (telephone answering device) on page 40.)
	Plug the telephone line cord directly from the wall telephone jack to your Brother machine's LINE jack.
	2 Remove the protective cap from your Brother machine's EXT jack, and then plug the telephone line cord from your answering machine into the EXT jack.
	3 Set your answering machine to answer within 4 rings.
	If you are having problems receiving faxes or voice messages, set your answering machine to answer within 2 or 3 rings.
	4 Record the outgoing message on your answering machine.
	Record five seconds of silence at the beginning of your outgoing message.
	■ Limit your speaking to 20 seconds.
	End your outgoing message with your Fax Receive Code for people sending manual faxes. For example: "After the beep, leave a message or press *51 and Start to send a fax."
	5 Set your answering machine to answer calls.
	6 Set your Brother machine's Receive Mode to External TAD. (See Receive Mode settings on page 35.)
	Make sure your Brother machine's Easy Receive feature is turned On. Easy Receive is a feature that allows you to receive a fax even if you have answered the call on an external or extension telephone. (See <i>Easy Receive</i> on page 36.)
	If you often get transmission errors due to possible interference on the telephone line, try changing the Compatibility setting to <code>Basic(for VoIP)</code> . (See Telephone line interference / VoIP on page 130.)
	Contact your administrator to check your Secure Function Lock Settings.

Sending faxes

Difficulties	Suggestions
Poor sending quality.	Try changing your resolution to Fine or S.Fine. Make a copy to check your machine's scanner operation. If the copy quality is not good, clean the scanner. (See Cleaning the scanner in Appendix A of the Advanced User's Guide.)
Transmission Verification Report says RESULT:NG.	There is probably temporary noise or static on the line. Try sending the fax again. If you are sending a PC-Fax message and get RESULT:NG on the Transmission Verification Report, your machine may be out of memory. To free up extra memory, you can turn off fax storage (see Changing Remote Fax Options in Chapter 4 of the Advanced User's Guide), print fax messages in memory (see Printing a fax from the memory in Chapter 4 of the Advanced User's Guide) or cancel a delayed fax or polling job (see Checking and canceling waiting jobs in Chapter 3 of the Advanced User's Guide). If the problem continues, ask the telephone company to check your telephone line.
	If you often get transmission errors due to possible interference on the telephone line, try changing the Compatibility setting to Basic (for VoIP). (See Telephone line interference / VoIP on page 130.)
Sent faxes are blank.	Make sure you are loading the document properly. (See <i>Loading documents</i> on page 26.)
Vertical black lines when sending.	Black vertical lines on faxes you send are typically caused by dirt or correction fluid on the glass strip. (See Cleaning the scanner in Appendix A of the Advanced User's Guide.)
Cannot send a fax.	Contact your administrator to check your Secure Function Lock Settings.

Handling incoming calls

Difficulties	Suggestions
The machine 'Hears' a voice as a CNG Tone.	If Easy Receive is set to On, your machine is more sensitive to sounds. It may mistakenly interpret certain voices or music on the line as a fax machine calling and respond with fax receiving tones. Deactivate the machine by pressing Stop/Exit . Try avoiding this problem by turning Easy Receive to Off. (See Easy Receive on page 36.)
Sending a Fax Call to the machine.	If you answered on an external or extension telephone, press your Fax Receive Code (default setting is *51). When your machine answers, hang up.
Custom features on a single line.	If you have Call Waiting, Call Waiting/Caller ID, Caller ID, RingMaster, Voice Mail, an answering machine, an alarm system or other custom feature on a single telephone line with your machine, it may create a problem sending or receiving faxes.
	For Example: If you subscribe to Call Waiting or some other custom service and its signal comes through the line while your machine is sending or receiving a fax, the signal can temporarily interrupt or disrupt the faxes. Brother's ECM feature should help overcome this problem. This condition is related to the telephone system industry and is common to all devices that send and receive information on a single, shared line with custom features. If avoiding a slight interruption is crucial to your business, a separate line with no custom features is recommended.

Copy difficulties

Difficulties	Suggestions
Cannot make a copy.	■ Make sure that COPY is illuminated. (See <i>How to copy</i> on page 53.)
	■ Contact your administrator to check your Secure Function Lock Settings.

Copy difficulties (continued)

Difficulties	Suggestions
Vertical black line appears in copies.	Black vertical lines on copies are typically caused by dirt or correction fluid on the glass strip, or the corona wire is dirty. (See Cleaning the scanner in Appendix A of the Advanced User's Guide and Cleaning the corona wires on page 74.)
Copies are blank.	Make sure you are loading the document properly. (See <i>Using the automatic document feeder (ADF)</i> on page 26 or <i>Using the scanner glass</i> on page 27.)

Printing difficulties

Difficulties	Suggestions
No printout.	■ Check that the machine is plugged in and the power switch is turned on.
	Check that the toner cartridge and drum unit are installed properly. (See Replacing the drum unit on page 80.)
	■ Check the interface cable connection on both the machine and your computer. (See the <i>Quick Setup Guide</i> .)
	■ Check that the correct printer driver has been installed and chosen.
	 Check to see if the LCD is showing an error message. (See Error and maintenance messages on page 99.)
	■ Check that the machine is online: (Windows [®] 7 and Windows Server [®] 2008 R2) Click the Start button and Devices and Printers . Right-click Brother MFC-XXXX Printer . Make sure that Use Printer Offline is unchecked.
	(Windows Vista [®]) Click the Start button, Control Panel , Hardware and Sound , and then Printers . Right-click Brother MFC-XXXX Printer . Make sure that Use Printer Offline is unchecked.
	(Windows® XP and Windows Server® 2003/2008) Click the Start button and choose Printers and Faxes . Right-click Brother MFC-XXXX Printer . Make sure that Use Printer Offline is unchecked.
	(Windows [®] 2000) Click the Start button and choose Settings and then Printers . Right-click Brother MFC-XXXX Printer . Make sure that Use Printer Offline is unchecked.
	■ Contact your administrator to check your Secure Function Lock settings.
	■ If either the Cyan, Magenta or Yellow toner reaches the end of its life while printing a color document, the print job cannot be completed. You can choose to start the print job again in Mono mode, as long as black toner is available. See Basic tab in the Software User's Guide.
The machine prints unexpectedly	■ Press Job Cancel to cancel print jobs.
or it prints garbage.	Check the settings in your application to make sure it is set up to work with your machine.
The machine prints the first couple of pages correctly, then some pages have text missing.	Check the settings in your application to make sure that it is set up to work with your machine.
	Your computer is not recognizing the machine's input buffer's full signal. Make sure that you connected the interface cable correctly. (See the Quick Setup Guide.)
The headers or footers appear when the document displays on the screen but they do not show up when it is printed.	There is an unprintable area on the top and bottom of the page. Adjust the top and bottom margins in your document to allow for this. (See <i>Unscannable and unprintable areas</i> on page 17.)

Printing difficulties (continued)

Difficulties	Suggestions
The machine does not print on both sides of the paper even though the printer driver setting is Duplex.	Check the paper size setting in the printer driver. You need to choose Letter, Legal or Folio [16 to 28 lb (60 to 105 g/m²)].
The machine is not printing or has stopped printing.	■ If either the Cyan, Magenta or Yellow toner reaches the end of its life while printing a color document, the print job cannot be completed. You can choose to start the print job again in Mono mode, as long as black toner is available. See Basic tab in the Software User's Guide.
	■ Press Job Cancel.
	As the machine cancels the print job and clears it from the memory it may produce an incomplete printout.
The machine does not change to Direct Print mode when a USB flash memory drive is connected to the USB direct interface.	When the machine is in Deep Sleep mode, the machine does not wake up when a USB flash memory drive is connected to the USB direct interface. Press the LCD surface or any key to wake up the machine. Then press <code>Direct Print</code> on the LCD to display the Direct Print menu.

Scanning difficulties

Difficulties	Suggestions
TWAIN errors appear while scanning.	Make sure that the Brother TWAIN driver is chosen as the primary source. In PaperPort™ 12SE, click File , Scan or Get Photo and choose the Brother TWAIN driver.
OCR does not work.	Try increasing the scanning resolution.
	(Macintosh users) Make sure you have downloaded and installed Presto! PageManager from http://nj.newsoft.com.tw/download/brother/PM9SEInstaller_BR_multilang.dmg
Network scanning does not work.	See Network difficulties on page 128.
Cannot scan.	Contact your administrator to check your Secure Function Lock Settings.

Software difficulties

Difficulties	Suggestions
Cannot install software or print.	Run the Repair MFL-Pro Suite program on the CD-ROM. This program will repair and reinstall the software.
Cannot perform '2 in 1' or '4 in 1' printing.	Check that the paper size setting in the application and in the printer driver are the same.
The machine does not print from Adobe [®] Illustrator [®] .	Try to reduce the print quality. (See Basic tab in the Software User's Guide.)

Paper handling difficulties

Difficulties	Suggestions
The machine does not feed paper.	■ If there is no paper, load a new stack of paper into the paper tray.
The LCD shows No Paper or a Paper Jam message.	If there is paper in the paper tray, make sure it is straight. If the paper is curled, you should straighten it. Sometimes it is helpful to remove the paper, turn the stack over and put it back into the paper tray.
	■ Reduce the amount of paper in the paper tray, and then try again.
	■ Make sure that manual feed mode is not chosen in the printer driver.
	Clean the paper pick-up roller. See Cleaning the paper pick-up rollers in Appendix A of the Advanced User's Guide.
	■ If the LCD shows the Paper Jam message and you still have a problem, see Error and maintenance messages on page 99.
The machine does not feed paper	■ Make sure that MP tray is chosen in the printer driver.
from the MP tray.	■ Fan the paper well and put it back in the tray firmly.
How do I print on envelopes?	You can load envelopes in the MP tray. Your application must be set up to print the envelope size you are using. This is usually done in the Page Setup or Document Setup menu of your application. (See your application's manual for more information.)
What paper can I use?	You can use thin paper, plain paper, thick paper, bond paper, recycled paper, glossy paper, envelopes and labels that are made for laser machines. (For details, see <i>Acceptable paper and other print media</i> on page 21.)
There is a paper jam.	Clear the jammed paper. (See Error and maintenance messages on page 99.)

Print quality difficulties

Difficulties	Suggestions
Printed pages are curled.	Low quality thin or thick paper or not printing on the recommended side of the paper could cause this problem. Try turning over the stack of paper in the paper tray.
	■ Make sure that you choose the Paper Type that suits the print media type you are using. (See <i>Acceptable paper and other print media</i> on page 21.)
Printed pages are smeared.	The Paper Type setting may be incorrect for the type of print media you are using, or the print media may be too thick or have a rough surface. (See Acceptable paper and other print media on page 21 and Basic tab in the Software User's Guide.)
Printouts are too light.	■ If this problem occurs when making copies or printing received faxes, turn Toner Save mode to Off in the machine menu settings. (See <i>Toner Save</i> in <i>Chapter 1</i> of the <i>Advanced User's Guide</i>)
	■ Remove the check in the Toner Save Mode check box in the Advanced tab of the printer driver. (See <i>Advanced tab</i> in the <i>Software User's Guide</i> .)
	In the Basic tab of the printer driver, click the Settings button and check the Enhance Black Printing check box.

Network difficulties

Difficulties	Suggestions
Cannot print over a wired Network.	If you are having Network problems see the <i>Network User's Guide</i> for more information.
	Make sure your machine is powered on and is on-line and in Ready mode. Print the Network Configuration report to see your current Network settings. (See <i>Reports</i> in <i>Chapter 6</i> of the <i>Advanced User's Guide</i> .) Reconnect the LAN cable to the hub to verify that the cable and network connections are good. If possible, try connecting the machine to a different port on your hub using a different cable. You can check the current wired network status from the Network control panel menu.
The network scanning feature does not work.	(Windows®) It is necessary to set the third-party Security/Firewall Software to allow Network scanning. To add port 54925 for Network scanning, enter the information below:
	■ In Name: Enter any description, for example Brother NetScan.
	■ In Port number: Enter 54925.
	■ In Protocol: UDP is selected.
	Please refer to the instruction manual that came with your third-party Security/Firewall Software or contact the software manufacturer.
	For more details, you can read FAQs and troubleshooting suggestions at http://solutions.brother.com/ .
	(Macintosh)
	■ The network scanning feature may not work due to the firewall settings. Change or disable the firewall settings. If you are using a third-party personal Firewall software, see the User's Guide for your software or contact the software manufacturer.
	Re-select your machine in the Device Selector application located in Macintosh HD/Library/Printers/Brother/Utilities/DeviceSelector or from the model list in ControlCenter2.
The network PC-Fax Receive feature does not work.	(Windows® only) It is necessary to set the third-party Security/Firewall Software to allow PC-FAX Rx. To add port 54926 for Network PC-FAX Rx, enter the information below:
	■ In Name: Enter any description, for example Brother PC-FAX Rx.
	■ In Port number: Enter 54926.
	■ In Protocol: UDP is selected.
	Please refer to the instruction manual that came with your third-party Security/Firewall Software or contact the software manufacturer.
	For more details, you can read FAQs and troubleshooting suggestions at http://solutions.brother.com/ .

Network difficulties (continued)

Difficulties	Suggestions
Your computer cannot find your machine.	(Windows®) The firewall setting on your PC may be rejecting the necessary network connection. (For details, see the instructions above.)
	(Macintosh)
	■ The computer may be unable to detect the machine due to the firewall settings. Change or disable the firewall settings. If you are using a third-party personal Firewall software, see the User's Guide for your software or contact the software manufacturer.
	Re-select your machine in the Device Selector application located in Macintosh HD/Library/Printers/Brother/Utilities/DeviceSelector or from the Model pop-up menu of ControlCenter2.
Cannot connect to wireless network.	Investigate the problem using the WLAN Report. Press MENU, Print Reports, WLAN Report. and then press Black Start or Color Start . For more details, see the <i>Quick Setup Guide</i> .

Other

Difficulties	Suggestions
The machine will not turn on.	Adverse conditions on the power connection (such as lightning or a power surge) may have triggered the machine's internal safety mechanisms. Turn the machine off and unplug the power cord. Wait for ten minutes, then plug in the power cord and turn the machine on.
	If the problem is not solved, turn off the machine. Plug the power cord into a different known working outlet and turn on the machine.

Setting Dial Tone detection

Setting the Dial Tone to Detection will shorten the Dial Tone detect pause.

- 1 Press MENU.
- Press ▲ or ▼ to display
 Initial Setup.
 Press Initial Setup.
- Press ▲ or ▼ to display Dial Tone.

 Press Dial Tone.
- 4 Press Detection or No Detection.
- 5 Press Stop/Exit.

Telephone line interference / VoIP

If you are having difficulty sending or receiving a fax due to possible interference on the telephone line, we recommend that you adjust the Equalization for compatibility to reduce the modem speed for fax operations.

- 1 Press MENU.
- Press ▲ or ▼ to display Fax.
 Press Fax.
- 3 Press ▲ or ▼ to display
 Miscellaneous.
 Press Miscellaneous.
- 4 Press Compatibility.
- 5 Press Basic (for VoIP), Normal or High.
 - Basic (for VoIP) reduces the modem speed to 9600 bps and turns the error correction mode (ECM) off.

For a standard telephone line: If you regularly experience interference on your standard telephone line try this setting.

If you are using VoIP: VoIP service providers offer fax support using various standards. If you regularly experience fax transmission errors try this setting.

- Normal sets the modem speed at 14400 bps.
- High sets the modem speed at 33600 bps.
- 6 Press Stop/Exit.



When you change the Compatibility to Basic(for VoIP), the ECM feature is only available for color fax sending.

Improving the print quality

If you have a print quality problem, print a test page first (MENU, Printer, Print Options, Test Print). If the printout looks good, the problem is probably not the machine. Check the interface cable connections or try printing a different document. If the printout or test page printed from the machine has a quality problem, check the following steps first. And then, if you still have a print quality problem, check the chart below and follow the recommendations.



Using non-Brother supplies may affect the print quality, hardware performance, and machine reliability.

- To get the best print quality, we suggest using the recommended paper. Check that you use paper that meets our specifications. (See Acceptable paper and other print media on page 21.)
- Check that the drum unit and toner cartridges are installed properly.

Examples of poor print quality	Recommendation
White lines, bands or ribbing across the page	■ Put in a new drum unit. (See Replacing the drum unit on page 80.)
Colors are light or unclear on the whole page	Make sure Toner Save mode is off in the control panel of the machine or the printer driver.
	Make sure that you choose the proper media type in the printer driver or in the machine's Paper Type menu setting. (See Acceptable paper and other print media on page 21 and Basic tab in the Software User's Guide.)
	■ Shake all four toner cartridges gently.
	■ Wipe the laser scanner windows with a dry lint-free soft cloth. (See Cleaning the laser scanner windows in Appendix A of the Advanced User's Guide.)
	■ Perform the calibration. (See <i>Calibration</i> in <i>Appendix A</i> of the <i>Advanced User's Guide</i> .)


Examples of poor print Recommendation quality White streaks or bands down ■ Clean the scanner glass and scanner glass strip. (See Cleaning the the page scanner in Appendix A of the Advanced User's Guide.) ■ Wipe the laser scanner windows with a dry lint-free soft cloth. (See Cleaning the laser scanner windows in Appendix A of the Advanced User's Guide.) ■ Clean the drum unit. (See Cleaning the drum unit in Appendix A of the Advanced User's Guide.) Identify the missing color and put in a new toner cartridge. (See Replacing a Toner cartridge on page 68.) To identify the color of the toner cartridge, visit us at http://solutions.brother.com/ to view our FAQs and troubleshooting tips. Colored streaks or bands down ■ Clean all four corona wires (one for each color) inside the drum unit the page by sliding the green tab. (See *Cleaning the corona wires* on page 74.) ■ Make sure the corona wire green tabs are at their home positions (▲). ■ Clean the scanner glass and scanner glass strip. (See Cleaning the scanner in Appendix A of the Advanced User's Guide.) ■ Replace the toner cartridge that matches the color of the streak or band. (See Replacing a Toner cartridge on page 68.) To identify the color of the toner cartridge, visit us at http://solutions.brother.com/ to view our FAQs and troubleshooting tips. ■ Put in a new drum unit. (See Replacing the drum unit on page 80.) ■ If colored lines appear at 1.2 in. (30 mm) intervals, replace the toner Colored lines across the page cartridge that matches the color of the line. (See Replacing a Toner cartridge on page 68.) To identify the color of the toner cartridge, visit us at http://solutions.brother.com/ to view our FAQs and troubleshooting ■ If colored lines appear at 3.7 in. (94 mm) intervals, put in a new drum unit. (See Replacing the drum unit on page 80.) White spots or hollow print ■ Make sure that the media type settings in the printer driver and in the machine's Paper Type menu match the type of paper you are using. (See Acceptable paper and other print media on page 21 and Basic tab in the Software User's Guide.) ■ Check the machine's environment. Conditions such as high humidity can cause white spots or hollow print. (See Choosing a location in the Safety and Legal Booklet.) ■ Clean the drum unit. (See Cleaning the drum unit in Appendix A of the Advanced User's Guide.)

Examples of poor print Recommendation quality Completely blank or some ■ Put in a new toner cartridge. (See Replacing a Toner cartridge colors are missing on page 68.) To identify the color of the toner cartridge, visit us at http://solutions.brother.com/ to view our FAQs and troubleshooting tips. ■ Put in a new drum unit. (See Replacing the drum unit on page 80.) Colored spots at 3.7 in. ■ If the problem is not solved after printing, the drum may have foreign material, such as glue from a label, stuck on the drum surface. Clean (94 mm) the drum unit. (See Cleaning the drum unit in Appendix A of the Advanced User's Guide.) 3.7 in. (94 mm) ■ Put in a new drum unit. (See *Replacing the drum unit* on page 80.) 3.7 in. (94 mm) ■ Identify the color causing the problem and put in a new toner Colored spots at 1.2 in. (30 mm) cartridge. (See Replacing a Toner cartridge on page 68.) To identify the color of the toner cartridge, visit us at http://solutions.brother.com/ to view our FAQs and troubleshooting 1.2 in. tips. (30 mm) 1.2 in. (30 mm) Toner scatter or toner stain ■ Check the machine's environment. Conditions such as high humidity and high temperatures may cause this print quality problem. (See Choosing a location in the Safety and Legal Booklet.) ■ Identify the color causing the problem and put in a new toner cartridge. (See Replacing a Toner cartridge on page 68.) To identify the color of the toner cartridge, visit us at http://solutions.brother.com/ to view our FAQs and troubleshooting tips. ■ If the problem continues, put in a new drum unit. (See Replacing the drum unit on page 80.)

Examples of poor print quality	Recommendation
The color of your printouts is not what you expected	Make sure Toner Save mode is off in the control panel of the machine or the printer driver.
	■ Perform the calibration. (See Calibration in Appendix A of the Advanced User's Guide.)
	Adjust the color by using the custom setting in the printer driver and by using the control panel of the machine. Colors the machine can print and colors you see on a monitor are different. The machine may not be able to reproduce the colors on your monitor.
	■ If colors appear in the printed gray areas, make sure there is a check in the Improve Gray Color check box of the printer driver. (See Basic tab for Windows® printer driver, Advanced options for Windows® BR-Script printer driver, Print Settings for Macintosh printer driver or Printer Features for Macintosh BR-Script printer driver in the Software User's Guide.)
	If shaded areas look dull, remove the check from the Improve Gray Color check box.
	■ If a printed black graphic is too light, choose Enhance Black Printing mode in the printer driver. (See Settings Dialog for Windows® printer driver, Advanced options for Windows® BR-Script printer driver, Print Settings for Macintosh printer driver or Printer Features for Macintosh BR-Script printer driver in the Software User's Guide.)
	■ Identify the color causing the problem and put in a new toner cartridge. (See <i>Replacing a Toner cartridge</i> on page 68.)
	■ Put in a new drum unit. (See <i>Replacing the drum unit</i> on page 80.)
All one color	■ Put in a new drum unit. (See Replacing the drum unit on page 80.)
Color misregistration	■ Make sure that the machine is on a solid level surface.
B	■ Perform the auto color registration using the control panel (see Auto Registration in Appendix A of the Advanced User's Guide) or perform the manual color registration using the control panel (see Manual Registration in Appendix A of the Advanced User's Guide).
	Put in a new drum unit. (See Replacing the drum unit on page 80.)
	■ Put in a new belt unit. (See Replacing the belt unit on page 86.)

Examples of poor print	Recommendation
Examples of poor print quality	Recommendation
Uneven density appears periodically across the page	■ Perform the calibration. (See Calibration in Appendix A of the Advanced User's Guide.)
	■ Clean the scanner glass and scanner glass strip. (See Cleaning the scanner in Appendix A of the Advanced User's Guide.)
B	Identify the color that is uneven and put in a new toner cartridge for that color. (See Replacing a Toner cartridge on page 68.) To identify the color of the toner cartridge, visit us at http://solutions.brother.com/ to view our FAQs and troubleshooting tips.
	■ Put in a new drum unit. (See <i>Replacing the drum unit</i> on page 80.)
Thin lines do not print	Make sure Toner Save mode is off in the control panel of the machine or the printer driver.
	■ Change the print resolution.
	■ If you use a Windows [®] printer driver, choose Improve Pattern Printing or Improve Thin Line in Settings in the Basic tab. (See Settings Dialog in the Software User's Guide.)
Wrinkle	■ Change to the recommended type of paper. (See Recommended paper and print media on page 21.)
	■ Make sure that the back cover is closed properly.
	Make sure that the two gray levers inside the back cover are in the up position. When you are using thick paper or envelopes, make sure the gray levers are in the down position to prevent wrinkling.
	■ Make sure that the media type settings in the printer driver and in the machine's Paper Type menu matches the type of paper you are using. (See Acceptable paper and other print media on page 21 and Basic tab in the Software User's Guide.)
Offset image	Make sure that the media type settings in the printer driver and in the machine's Paper Type menu matches the type of paper you are using. (See Acceptable paper and other print media on page 21 and Basic tab in the Software User's Guide.)
	Make sure that the two gray levers inside the back cover are in the up position.
	■ Check the machine's environment. Conditions such as low humidity and low temperatures may cause this print quality problem. (See Choosing a location in the Safety and Legal Booklet.)
	■ Put in a new drum unit. (See <i>Replacing the drum unit</i> on page 80.)

Examples of poor print quality	Recommendation
Poor fixing	Make sure that the media type settings in the printer driver and in the machine's Paper Type menu matches the type of paper you are using. (See Acceptable paper and other print media on page 21 and Basic tab in the Software User's Guide.)
B	Make sure that the two gray levers inside the back cover are in the up position.
	■ Choose Improve Toner Fixing mode in the printer driver. (See Other
	Print Options (For Windows® printer driver), Advanced options (For Windows® BR-Script printer driver), Print Settings (For Macintosh printer driver) or Printer Features (For Macintosh BR-Script printer driver) in the Software User's Guide.) If this selection does not provide enough improvement, change the printer driver setting in Media Type to a thick setting.
Curled or wavy	■ Choose Reduce Paper Curl mode in the printer driver when you do
	not use our recommended paper. (See Other Print Options (For Windows [®] printer driver), Advanced options (For Windows [®] BR-Script printer driver), Print Settings (For Macintosh printer driver) or Printer Features (For Macintosh BR-Script printer driver) in the Software User's Guide.)
	If you do not use the machine often, the paper may have been in the paper tray too long. Turn over the stack of paper in the paper tray. Also, fan the paper stack and then rotate the paper 180° in the paper tray.
	Store the paper where it will not be exposed to avoid high temperatures and high humidity.
	Open the back cover (face up output tray) to let the printed paper out on the face up output tray.



Machine Information

Checking the Serial Number

You can see the machine's Serial Number on the LCD.

- 1 Press MENU.
- Press ▲ or ▼ to display
 Machine Info..

 Press Machine Info..
- The machine will display the machine's Serial Number on the LCD.
- 4 Press Stop/Exit.

Reset functions

The following reset functions are available:

1 Network

You can reset the internal print server back to its default factory settings such as the password and IP address information.

2 Address & Fax

Address & Fax resets the following settings:

- Address Book
 (One Touch Dial/Speed Dial/Setup Groups)
- Programmed fax jobs in the memory (Polled TX, Delayed Fax)
- Station ID (name and number)
- Coverpage Msg (comments)
- Remote Fax Options

(Remote Access Code, Fax Storage, Fax Forwarding, Paging, PC-Fax Send, and PC-Fax Receive (Windows® only))

■ Report settings

(Transmission Verification Report/ Tel Index List/Fax Journal)

- Setting Lock password
- 3 All Settings

You can reset all the machine settings back to the settings that were set at the factory.

Brother strongly recommends you perform this operation when you dispose of the machine.



Unplug the interface cable before you choose Network or All Settings.

How to reset the machine

- 1 Press MENU.
- Press ▲ or ▼ to display
 Initial Setup.
 Press Initial Setup.
- 3 Press ▲ or ▼ to display Reset.
 Press Reset.
- 4 Press Network, Address & Fax or All settings to choose the reset function you want to use.
- 5 Do one of the following;
 - To reset the settings, press Yes and go to step **6**.
 - To exit without making changes, press No and go to step ⑦.
- 6 You will be asked to reset the machine.
 Do one of the following;
 - To reset the machine press Yes for 2 seconds. The machine will begin the reset.
 - To exit without resetting the machine, press No. Go to step •
- 7 Press Stop/Exit.



You can also reset the Network settings by pressing MENU, Network, Network Reset.

C

Menu and features

On-screen programming

Your machine is designed to be easy to operate with LCD on-screen programming using the menu buttons on the Touchscreen. User-friendly programming helps you take full advantage of all the menu selections your machine has to offer.

Since your programming is done on the LCD, we have created step-by-step on-screen instructions to help you program your machine. All you need to do is follow the instructions as they guide you through the menu selections and programming options.

Menu table

You can program your machine by using the Menu table that begins on page 141. These pages list the menu selections and options.

MENU button and mode keys

MENU	Access the main menu.
SCAN COPY	Access each mode and its menu of temporary settings.
♥ Stop / Exit	Exit the menu or stop the current operation.

Menu table

The menu table will help you understand the menu selections and options that are found in the machine's programs. The factory settings are shown in Bold with an asterisk.



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
General Setup	Mode Timer	_	_	0 Sec	Sets the time to	See ¹ .
				30 Secs	return to Fax mode and the time the	
				1 Min	machine will change	
				2 Mins*	from a restricted user to Public user mode	
				5 Mins	when using Secure	
				Off	Function Lock.	
	Tray Setting	MP Tray	_	Paper Size	Sets the size and	18
				A4	type of paper in paper MP tray.	
				Letter*		
			Legal			
				Executive		
				A5		
				A5 L		
				A6		
				B5		
				В6		
				Folio		
				Any		
				Paper Type		
					Thin	
				Plain*		
				Thick		
				Thicker		
				Recycled Paper		
				Glossy		

See Advanced User's Guide



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
General Setup	Tray Setting	Tray#1	_	Paper Size	Sets the size and	18
(Continued)	(Continued)			A4	type of paper in paper tray #1.	
				Letter*	,	
				Legal		
				Executive		
				A5		
				A5 L		
				A6		
				B5		
				B6		
				Folio		
				Paper Type		
				Thin		
				Plain*		
				Thick		
				Thicker		
				Recycled Paper		
		Tray#2	_	Paper Size	Sets the size and	18
		(This menu		A4	type of paper in paper tray #2.	
		only appears if you have the		Letter*	,	
		optional		Legal		
		tray#2.)		Executive		
				A5		
				B5		
				В6		
				Folio		
				Paper Type		
				Thin		
				Plain*		
				Thick		
				Thicker		
				Recycled Paper		

¹ See Advanced User's Guide



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
General Setup	Tray Setting	Tray Use:Copy	_	Tray#1 Only	Chooses the tray that will be used for Copy mode.	19
(Continued) (Co	(Continued)	(Continued)		Tray#2 Only		
				MP Only	mode.	
				MP>T1>T2*		
				T1>T2>MP		
				(Tray#2 or T2 appears only if you installed the optional paper tray.)		
		Tray Use:Fax	_	Tray#1 Only	Chooses the tray that	19
				Tray#2 Only	will be used for Fax mode.	
				MP Only	mode.	
				MP>T1>T2		
				T1>T2>MP*		
				(Tray#2 or T2 appears only if you installed the optional paper tray.)		
		Tray Use:Print	_	Tray#1 Only	Chooses the tray that	20
				Tray#2 Only	will be used for Print mode.	
				MP Only		
				MP>T1>T2*		
				T1>T2>MP		
				(Tray#2 or T2 appears only if you installed the optional paper tray.)		



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
General Setup	Volume	Ring	_	Off	Adjusts the ring	See ¹ .
(Continued)				Low	volume.	
				Med*		
				High		
		Beeper	_	Off	Adjusts the beeper	
				Low	volume.	
				Med*		
				High		
		Speaker	_	Off	Adjusts the speaker	
				Low	volume.	
				Med*		
				High		
	Ecology	Toner Save	_	On	Increases the page	
				Off*	yield of the toner cartridge.	
		Sleep Time	_	Range varies depending on models.	Conserves power.	
				3 Mins*		
	LCD Settings	Backlight	_	Light*	You can adjust the	
				Med	brightness of the LCD backlight.	
				Dark		
		Dim Timer	_	Off*	You can set how long	
				10 Secs	the LCD backlight stays on after the last	
				20 Secs	key press.	
				30 Secs		
	Security	Function Lock	Set Password	_	You can restrict	
			Lock Off→On		selected machine operations for up to	
			Setup ID		25 restricted users and for all other non-authorized Public users.	
		Setting Lock	Set Password Lock Off→On	_	Stops unauthorized users from changing the machine's current settings.	

See Advanced User's Guide





Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Fax Setup Receive (In Fax mode only)	Ring Delay	_	0 1 2 3	Sets the number of rings before the machine answers in Fax Only or Fax/Tel mode.	35	
	F/T Ring Time	_	4* 20 Secs* 30 Secs 40 Secs 70 Secs	Sets the length of the pseudo/double-ring time in Fax/Tel mode.	35	
	Easy Receive	_	On*	Receives fax messages automatically when you answer a call and hear fax tones.	36	
	Remote Codes	_	On* (*51, #51) Off	Allows you to answer all calls at an extension telephone and use codes to turn the machine on or off. You can personalize these codes.	43	
		Auto Reduction	_	On*	Reduces the size of incoming faxes.	See
		Forward/Page/Store	_	Off* Fax Forward Paging Fax Storage PC Fax Receive	Sets the machine to forward fax messages, to call your pager or cell phone, to store incoming faxes in the memory (so you can retrieve them while you are away from your machine), or to send faxes to your PC.	
		(Backup Print)	_		If you choose Fax Forward or PC-Fax Receive, you can turn on the safety feature Backup Print.	

¹ See Advanced User's Guide



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Fax (Continued)	Setup Receive (In Fax mode only)	Print Density	_	-2 -1	Makes printouts darker or lighter.	See ¹ .
	(Continued)			0* +1 +2		
		Fax Rx Stamp	_	On Off*	Prints the received time and date on the top of the received faxes.	
		Duplex	_	On Off*	Prints receive faxes on both sides of the paper.	
	Setup Send	Batch TX	_	On Off*	Combines delayed faxes going to the same fax number at the same time of day into one transmission.	
		Coverpage Setting	Print Sample	_	You can print a sample of the fax cover page.	
			Coverpage Message	_	Set up your own comments for the fax cover page.	
	Report Setting	Transmission	_	On On+Image Off* Off+Image	Choose the initial setup for the Transmission Verification Report.	30
		Journal Period		Off Every 50 Faxes* Every 6 Hours Every 12 Hours Every 24 Hours Every 2 Days Every 7 Days	Sets the interval for automatic printing of the Fax Journal. If you have chosen other than off and Every 50 Faxes, you can set the time for the chosen option. If you have chosen Every 7 Days, you can also set the day of the week.	See ¹ .
	Print Fax	_	_	_	Prints incoming faxes stored in the memory.	
	Remote Access	_	_	X	Set your own code for]

Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Fax (Continued)	Dial Restrict.	Dial Pad	_	Off* Enter # twice On	You can set the machine to restrict dialing when using the dial pad.	See ¹ .
		One Touch Dial	_	Off* Enter # twice On	You can set the machine to restrict the dialing of One Touch numbers.	
		Speed Dial		Off* Enter # twice On	You can set the machine to restrict the dialing of Speed Dial numbers.	
		LDAP Server		Off* Enter # twice On	You can set the machine to restrict the dialing of LDAP server numbers.	
	Remaining Jobs	_	_	_	Check which scheduled jobs are in the memory and cancel chosen jobs.	
	Miscellaneous	Compatibility	_	High* Normal Basic(for VoIP)	Adjusts the equalization for transmission difficulties.	130
					VoIP service providers offer fax support using various standards. If you regularly experience fax transmission errors, choose Basic(for VoIP).	
		Distinctive	_	Distinctive Ring setting Off* Set (On)	Uses the telephone company's Distinctive Ring subscriber service to register the ring pattern with the machine.	38
			_	Ring Pattern 1 2 3		
				4		

¹ See Advanced User's Guide





Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Printer	Emulation	_	_	Auto*	Choose the	See ² .
				HP LaserJet	emulation mode.	
				BR-Script 3		
	Print Options	Internal Font	_	HP LaserJet	Prints a list of the	
				BR-Script 3	machine's internal fonts.	
		Configuration	_	_	Prints a list of the machine's printer settings.	
		Test Print	_		Prints a test page.	
	Duplex			Off*	Enables or disables	
				Long Edge	duplex printing. You can also choose long	
	Output Color			Short Edge	edge or short edge duplex printing.	
	Output Color	_	_	Auto* Color B&W	Chooses color or black & white printed documents. If you choose Auto, the machine selects a suitable option for the document (color or B&W).	
	Reset Printer	_	_	Yes	Restores the printer	
				No	settings to the original factory default settings.	
	Calibration	Calibrate	_	Yes	Adjusts the color	See ¹ .
				No	density or returns the color calibration to	
		Reset	_	Yes	the factory settings.	
				No		
	Auto Regist.	_	_	Yes	Adjusts the print	
				No	position of each color automatically.	

¹ See Advanced User's Guide

² See Software User's Guide



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Printer (Continued)	Manual Regist.	Print Chart	_	_	Print the chart to manually check the registration of the colors.	See ¹ .
		Set Regist.	1 Magenta Left	_	Sets the correction	
			2 Cyan Left		value on the chart you printed from	
			3 Yellow Left		Print Chart.	
			4 Magenta Center			
			5 Cyan Center			
			6 Yellow Center			
			7 Magenta Right			
			8 Cyan Right			
			9 Yellow Right			
	Frequency	_	_	Normal*	Sets the interval time	
				Low	you want to carry out the auto registration	
				Off	and the calibration.	

¹ See Advanced User's Guide

² See Software User's Guide





Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Print Reports	Transmission	View on LCD Print Report	_		You can view the Transmission Verification Report for your last 200 outgoing faxes and print the last report.	See 1
	Help List	_	_		Prints the Help List so you can see at-a-glance how to quickly program your machine.	
	Tel Index List	Numerical Order	_	-	Lists names and numbers stored in the One Touch and Speed Dial memory, in numerical or alphabetical order.	
		Alphabetical Order	_	_		
	Fax Journal	_	_	_	Lists information about your last 200 incoming and outgoing faxes. (TX means Transmit. RX means Receive.)	
	User Settings	_	_	_	Lists your settings.	
	Network Config	_	_	_	Lists your Network settings.	
	Drum Dot Print	_	_	_	Prints the drum dot check sheet.	
	WLAN Report	_	_	_	Prints the result of wireless LAN connectivity diagnosis.	See ²

See Advanced User's Guide

² See Quick Setup Guide





Level 1	Level 2	Level 3	Level 4	Level 5	Options	Descriptions
Network ¹	Wired LAN	TCP/IP	Boot Method	_	Auto* Static RARP BOOTP DHCP	Chooses the BOOT method that best suits your needs.
			(IP Boot Tries)		3* [00000-32767]	Specifies the number of setting trials when the Boot Method allows automatic IP setting.
			IP Address	_	[000-255]. [000-255]. [000-255]. [000-255]	Enter the IP address.
			Subnet Mask	_	[000-255]. [000-255]. [000-255]. [000-255]	Enter the Subnet mask.
			Gateway	_	[000-255]. [000-255]. [000-255]. [000-255]	Enter the Gateway address.
			Node Name	_	BRNXXXXXXXXXX	Enter the Node name. (Up to 32 characters)
			WINS Config	_	Auto* Static	Chooses the WINS configuration mode.
			WINS Server	_	Primary [000-255]. [000-255]. [000-255]. [000-255]	Specifies the IP address of the primary or secondary WINS server.
					Secondary [000-255]. [000-255]. [000-255]. [000-255]	

See Network User's Guide



Level 1	Level 2	Level 3	Level 4	Level 5	Options	Descriptions
Network ¹ (Continued)	Wired LAN (Continued)	TCP/IP (Continued)	DNS Server	_	Primary [000-255]. [000-255]. [000-255].	Specifies the IP address of the primary or secondary DNS
					[000-255]	server.
					Secondary	
					[000-255]. [000-255]. [000-255]. [000-255]	
			APIPA	_	On* Off	Automatically allocates the IP address from the link-local address range.
			IPv6	_	On Off*	Enable or Disable the IPv6 protocol. If you want to use the IPv6 protocol, visit http://solutions.brother.com/ for more information.
		Ethernet	_	_	Auto*	Chooses the
					100B-FD	Ethernet link mode.
					100B-HD	
					10B-FD	
					10B-HD	
		Wired Status	_	_	Active 100B-FD	You can see the
					Active 100B-HD	current wired status.
					Active 10B-FD	status.
					Active 10B-HD	
					InActive	
					Wired OFF	
		MAC Address	_	_	_	Shows the MAC address of the machine.
		Set to Default	_	_	Yes No	Restore the wired network setting to factory default.
		Wired Enable	_	_	On*	Enable or Disable the Wired LAN
					Off	manually.

See Network User's Guide



Level 1	Level 2	Level 3	Level 4	Level 5	Options	Descriptions
Network ¹	WLAN	TCP/IP	Boot Method	_	Auto*	Chooses the BOOT
(Continued)					Static	method that best suits your needs.
					RARP	
					BOOTP	
					DHCP	
			(IP Boot	_	3*	Specifies the
			Tries)		[00000-32767]	number of setting trials when the
						Boot Method
						allows automatic IP setting.
			IP Address	_	[000-255].	Enter the IP
					[000-255].	address.
					[000-255]. [000-255]	
			Subnet Mask	_	[000-255].	Enter the Subnet
					[000-255]. [000-255].	mask.
					[000-255]	
			Gateway	_	[000-255].	Enter the Gateway
					[000-255]. [000-255].	address.
					[000-255]	
			Node Name	_	BRWXXXXXXXXXXX	Enter the Node
						name. (Up to 32
						characters)
			WINS Config	_	Auto*	Chooses the WINS
					Static	configuration mode.
			WINS Server	_	Primary	Specifies the IP address of the
					[000-255]. [000-255].	primary or
					[000-255].	secondary WINS
					[000-255]	server.
					Secondary	
					[000-255].	
					[000-255]. [000-255].	
					[000-255]	

See Network User's Guide



Level 1	Level 2	Level 3	Level 4	Level 5	Options	Descriptions
Network ¹ WLAN (Continued)	TCP/IP (Continued)	DNS Server		Primary [000-255]. [000-255]. [000-255]. [000-255]. Secondary [000-255]. [000-255]. [000-255]. [000-255]. [000-255].	Specifies the IP address of the primary or secondary DNS server.	
					Off	allocates the IP address from the link-local address range.
			IPv6		On Off*	Enable or Disable the IPv6 protocol. If you want to use the IPv6 protocol, visit http://solutions.brother.com/ for more information.
		Setup Wizard	_	_	_	You can configure your internal print server.
		WPS/AOSS	_	_	_	You can easily configure your wireless network settings using the one-button push method.
		WPS w/PIN Code	_	_	_	You can easily configure your wireless network settings using WPS with a PIN code.
		WLAN Status	Status	_	Active(11b) Active(11g) Wired LAN Active	You can see the current wireless network status.
					WLAN Off AOSS Active Connection Fail	
	1 Con Natur	owk Hoorlo Cuide		<u> </u>	connecction rail	

See Network User's Guide



Level 1	Level 2	Level 3	Level 4	Level 5	Options	Descriptions
Network ¹	WLAN	WLAN Status	Signal	_	Strong	You can see the
(Continued)	(Continued)	(Continued)			Medium	current wireless network signal
					Weak	strength.
					None	
			SSID	_	_	You can see the current SSID.
			Comm. Mode	_	Ad-hoc	You can see the
					Infrastructure	current Communication
					None	Mode.
		MAC Address	_	_	_	Shows the MAC address of the machine.
		Set to Default	_	_	Yes	Restore the
					No	wireless network settings to factory
						default.
		WLAN Enable	_	_	On	Enable or disable
					Off*	the wireless LAN manually.
	E-mail/IFAX	Mail Address	_	_	_	Enter the mail address. (Up to 60 characters)
		Setup Server	SMTP	SMTP Server	Name (Up to 64 characters)	Enter the SMTP server address.
					IP Address	
					[000-255]. [000-255]. [000-255]. [000-255]	
				SMTP Port	25*	Enter the SMTP
					[00001-65535]	port number.
				Auth. for SMTP	None*	Selects the Security
					SMTP-AUTH	method for E-mail notification.
					POP bef. SMTP	
				SMTP SSL/TLS	None*	You can send or receive an E-mail
					SSL	via an E-mail server
					TLS	that requires secure SSL/TLS communication.
				Verify SMTPCert.	On	Verify the SMTP
				Smirodit.	Off*	Server Certificate automatically.
	1 See Netwo	ork User's Guide	•	•		



Level 1	Level 2	Level 3	Level 4	Level 5	Options	Descriptions
Network ¹ (Continued)	E-mail/IFAX (Continued)	Setup Server (Continued)	POP3	POP3 Server	Name (Up to 64 characters)	Enter the POP3 server address.
					IP Address	
					[000-255]. [000-255]. [000-255]. [000-255]	
				POP3 Port	110*	Enter the POP3
					[00001-65535]	port number.
				Mailbox Name	_	Enter the mail box name. (Up to 60 characters)
				Mailbox Pwd	_	Enter the password to login to the POP3 server. (Up to 32 characters)
				POP3 SSL/TLS	None* SSL TLS	You can send or receive an E-mail via an E-mail server that requires secure SSL/TLS communication.
				Verify POP3Cert.	On Off*	Verify the POP3 Server Certificate automatically.
				APOP	On Off*	Enables or disables APOP.
		Setup Mail RX	Auto Polling	_	On*	Automatically checks the POP3 server for new messages.
				Poll Frequency (When Auto Polling is set to On.)	10* [01-60] Min	Sets the interval for checking for new messages on the POP3 server.

¹ See Network User's Guide



Level 1	Level 2	Level 3	Level 4	Level 5	Options	Descriptions
Network ¹ (Continued)	E-mail/IFAX (Continued)	Setup Mail RX (Continued)	Header	_	All Subject+From+To None*	Selects the contents of the mail header to be printed.
			Del Error Mail	_	On*	Deletes error mails automatically.
			Notification	_	On MDN Off*	Receives notification messages.
		Setup Mail TX	Sender Subject	_	_	Displays the subject that is attached to the Internet Fax data.
			Size Limit	_	On Off*	Limits the size of E-mail documents.
			Notification	_	On Off*	Sends notification messages.
		Setup Relay	Rly Broadcast	_	On Off*	Relays a document to another fax machine.
			Relay Domain	_	_	Registers the Domain name.
			Relay Report	_	On Off*	Prints the Relay Broadcast Report.
	Fax to Server			_	On (Prefix/Suffix) Off*	You can store a prefix/suffix address in the machine and can send a document from a fax server system.
	Network Reset	_	_	_	Yes No	Restore all network settings to factory default.

See Network User's Guide





Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Machine Info.	Serial No.	_	_	_	You can check the serial number of your machine.	138
	Page Counter	_	_	Total	You can check the	See ¹ .
				Fax/List	number of total pages the machine	
				Сору	has printed during its life.	
				Print		
	Parts Life	Drum	_	_	You can check the percentage of a machine part's life that remains available. (PF Kit 2 appears only if you installed the optional LT-300CL paper tray.)	
		Belt Unit	_			
		Fuser	_	_		
		Laser	_	_		
	PF Kit MP PF Kit 1 PF Kit 2	PF Kit MP	_	_		
		PF Kit 1	_	_		
		PF Kit 2	_	_		
	1 See Advanc	ced User's Guide				





Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Initial Setup	Receive Mode	_	_	Fax Only* Fax/Tel External TAD	Chooses the receive mode that best suits your needs.	32
	Date&Time	Date&Time	_	Manual —	Puts the date and time on the LCD and in headings of faxes you send.	See ² .
		Auto Daylight	_	On Off*	Changes for Daylight Savings Time automatically.	See ¹ .
		Time Zone	_	UTCXXX:XX	Sets the time zone for your country.	See ³ .
	Station ID	_	_	Fax: Tel: Name:	Sets up your name and fax number to appear on each page you fax.	
	Tone/Pulse (in Canada)	_	_	Tone* Pulse	Chooses the dialing mode.	
	Dial Tone	_	_	Detection No Detection*	You can shorten the dial tone detect pause.	130
	Dial Prefix	_	_	On Off*	Sets a prefix number that will always be added before the fax number every time you dial.	See ¹ .
	Reset	Network	_	Yes	Restores all network settings to factory default.	138
		Address & Fax	_	Yes	Restores all stored phone numbers and fax settings.	
		All Settings	_	Yes No	Restores all the machine settings to the factory default.	

- ¹ See Advanced User's Guide.
- ² See Quick Setup Guide.
- ³ See Network User's Guide.



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Initial Setup	Local Language	_	_	(in USA)	Allows you to change	See ² .
(Continued)				English*	the LCD language for your country.	
				Español		
				(in Canada)		
				English*		
				Français		

- 1 See Advanced User's Guide.
- ² See Quick Setup Guide.
- ³ See Network User's Guide.



FAX (🕮)

Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Address Book More	More	Set One Touch Dial	_	_	Stores up to 40 One Touch Dial numbers, so you can dial by pressing one key (and Black Start or Color Start).	48
		Set Speed Dial			Stores up to 300 Speed Dial numbers, so you can dial by pressing only a few keys (and Black Start or Color Start).	50
		Setup Groups	_	_	Sets up to 20 Group numbers for Broadcasting.	See ¹ .
		Change	_	_	You can change One Touch and Speed Dial numbers.	
		Delete	_	_	You can delete One Touch and Speed Dial numbers.	
Duplex Fax	_	_	_	Off* DuplexScan : LongEdge DuplexScan : ShortEdge	Sets the duplex scanning format.	
Volume (Appears after pressing Hook)	_	_	_	Off Low Med*	Adjusts the volume level of the speaker.	
Fax Resolution		_	_	High Standard*	Sets the resolution	
TAX VESOTATION				Fine S.Fine Photo	for outgoing faxes.	
Contrast	_	_	_	Auto* Light Dark	Changes the lightness or darkness of faxes you send.	

¹ See Advanced User's Guide



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Glass ScanSize	_	_	_	A4 Letter* Legal/Folio	To fax an A4, Legal or Folio size document, you'll need to change the Glass Scan Size setting.	29
Broadcasting	Manual	_	_	_	You can send the	See ¹ .
	Address Book	_	_	_	same fax message to more than one fax number.	
Delayed Fax	_	_	_	On	Sets the time of day	
				Off*	in 24 hour format that delayed faxes will be sent.	
Real Time TX	_	_	_	On	Sends a fax without using the memory.	
				Off*		
Polled TX	_	_	_	On	Sets up your machine with a document to be retrieved by another fax machine.	
				Off*		
Coverpage Setup	_	_	_	On	Automatically sends	
				Off*	a cover page you have programmed.	
Polling RX	_		_	On	Sets up your	
				Off*	machine to poll another fax machine.	
Overseas Mode	_	_	_	On	If you are having	
				Off*	difficulty sending faxes overseas, set this to On.	
Set New Default	_	_	_	Fax Resolution	You can save your fax settings as the default settings.	
				Contrast		
				Glass ScanSize		
				Real Time TX		
Bankana Bank				Coverpage Setup	You can restore all	
Factory Reset		_		_	fax settings to the	
					factory settings.	

¹ See Advanced User's Guide



COPY (📳)

Level 1	Level 2	Level 3	Options 1	Options 2	Descriptions	Page
Quality	_	-	Auto* Text	_	You can choose the Copy resolution for your type of	See ¹ .
			Photo		document.	
			Graph			
Enlarge/Reduce	_	_	100%*	_	_	
			Enlarge	104% EXE → LTR	You can choose the enlargement ratio for the next copy.	
				141% A5 → A4		
				200%		
			Reduce	50%	You can choose the	
				70% A4 → A5	reduction ratio for the next copy.	
				78% LGL → LTR	,	
				83% LGL → A4		
				85% LTR → EXE		
				91% Full Page		
				94% A4 → LTR		
				97% LTR → A4		
			Custom (25-400%)	_	You can enter an enlargement or reduction ratio.	
Duplex Copy	_	_	Off*	_	Enables or disables	1
			2side→2side		duplex printing. You can also choose long	
			1side→2side LongEdgeFlip		edge or short edge duplex printing.	
			2side→1side LongEdgeFlip			
			1side→2side ShortEdgeFlip			
			2side→1side ShortEdgeFlip			
Tray Use	_	_	Tray#1 Only	_	Chooses the tray that will be used for the	
			Tray#2 Only		copy operation.	
			MP Only			
			MP>T1>T2*			
			T1>T2>MP			
			(Tray#2 or T2 appears only if you installed the optional paper tray.)			
	¹ See Advar	ced User's Guid	le	ı	1	



Level 1	Level 2	Level 3	Options 1	Options 2	Descriptions	Page
Brightness	_	_		_	Adjusts the	See ¹ .
			-2		brightness for copies.	
			-1			
			+1			
Contrast	_	_		_	Adjusts the contrast	
			-2		for copies.	
			-1			
			+1			
Stack/Sort	_	_	Stack*	_	You can choose to	
·			Sort		stack or sort multiple copies.	
Page Layout	_	_	Off(1in1)*	_	You can make N in 1	
			2in1(P)		and 2 in 1 ID copies.	
			2in1(L)			
			2in1(ID)			
			4in1(P)			
			4in1(L)			
Color Adjust	_	_	Red	-2	Adjusts the red color for copies.	
				-2 -1	Tor copies.	
				+2		
			Green		Adjusts the green	
				-2	color for copies.	
				-1		
				+1		
				+2		



Level 1	Level 2	Level 3	Options 1	Options 2	Descriptions	Page
Color Adjust	_	_	Blue		Adjusts the blue color	See ¹ .
(Continued)				-2	for copies.	
				-1		
				+1		
				+2		
Set New Default	_	_	Quality	_	You can save your copy settings as the	
			Brightness		default settings.	
			Contrast			
			Color Adjust			
Factory Reset	_	_	_	_	You can restore all copy settings to the	
					factory settings.	
Favorite Settings	Store	Favorite:1	Rename	_	After you make	
		Favorite:2	Rename		changes to the following settings,	
		Favorite:3	Rename		you can store them	
					as one of your Favorite settings:	
					Quality	
					Enlarge/Reduce	
					Duplex Copy	
					Tray Use	
					Brightness	
					Contrast	
					Stack/Sort	
					Page Layout	
					Color Adjust	
	Rename	Favorite:1	Rename	_	You can rename your	
		Favorite:2	Rename	_	Favorite settings.	
		Favorite:3	Rename	_		
Favorite	_	_	Favorite:1	_	You can apply your	
			Favorite:2		Favorite settings as the default settings.	
			i	1		

¹ See Advanced User's Guide



SCAN (🖹)

Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Scan to USB	Quality	_	_	Color 100 dpi*	You can choose the	See ¹ .
				Color 200 dpi	scan resolution and file format for your	
				Color 300 dpi	document.	
				Color 600 dpi		
				Gray 100 dpi		
				Gray 200 dpi		
				Gray 300 dpi		
				B&W 200 dpi		
				B&W 200x100 dpi		
	File Type	_	_	(If you chose a Color or Gray option in the Quality setting)		
				PDF*		
				PDF/A		
				Secure PDF		
				Signed PDF		
				JPEG		
				XPS		
				(If you chose a B&W option in the Quality setting)		
				PDF*		
				PDF/A		
				Secure PDF		
				Signed PDF		
				TIFF		
	Duplex Scan	_	_	Off*	Chooses the duplex	
				DuplexScan :LongEdge	scanning format.	
				DuplexScan :ShortEdge		
	File Name	_	_	_	Enter a file name for the scanned data.	

Software User's Guide



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Scan to USB (Continued)	Glass ScanSize	_	_	A4 Letter* Legal/Folio	To scan an A4, Legal or Folio size document, you'll need to change the Glass Scan Size setting.	See ¹ .
	File Size	_	_	Small Middle* Large	You can choose the file size for color or gray scale scanning.	
	Set New Default		_	Quality File Type Glass ScanSize File Size	You can save your scan to USB settings as the default settings.	
	Factory Reset	_	_	_	You can restore all scan to USB settings to the factory settings.	
Scan to Network	(Profile name)	Quality		Color 100 dpi* Color 200 dpi Color 300 dpi Color 600 dpi Gray 100 dpi Gray 200 dpi Gray 300 dpi B&W 200 dpi B&W 200 dpi	You can choose the scan resolution and file format for your document.	
		File Type	_	(If you chose a Color or Gray option in the Quality setting) PDF* PDF/A Secure PDF Signed PDF JPEG XPS		

Software User's Guide



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Scan to Network (Continued)	(Profile name) (Continued)	File Type (Continued)	_	(If you chose a B&W option in the Quality setting)		See ¹ .
				PDF*		
				PDF/A		
				Secure PDF		
				Signed PDF		
				TIFF		
		Duplex Scan	_	Off*	Chooses the duplex	1
				DuplexScan :LongEdge	scanning format.	
				DuplexScan :ShortEdge		
		Glass ScanSize	_	A4	To scan an A4, Legal	
				Letter*	or Folio size document, you'll	
		File Size -		Legal/Folio	need to change the Glass Scan Size setting.	
		File Size	_	Small	You can choose the	
				Middle*	file size for color or gray scale scanning.	
				Large	gray scale scarring.	
		File Name	_	BRNXXXXXXXXXX*	You can choose	
				Estimate	preset file names. If you choose <manual>, you can name the file as you like.</manual>	
				Report		
				Order sheet		
				Contract sheet		
				Check		
				Receipt		
				<manual></manual>		
Scan to FTP	(Profile name)	Quality	_	Color 100 dpi*	You can choose the	
				Color 200 dpi	scan resolution and file format for your	
				Color 300 dpi	document.	
				Color 600 dpi		
				Gray 100 dpi		
				Gray 200 dpi		
				Gray 300 dpi		
				B&W 200 dpi		
				B&W 200x100 dpi		



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Scan to FTP	(Profile name)	File Type	_	(If you chose a		See ¹ .
(Continued)	(Continued)			Color or Gray option in the		
				Quality setting)		
				PDF*		
				PDF/A		
				Secure PDF		
				Signed PDF		
				JPEG		
				XPS		
				(If you chose a		
				B&W option in		
				the Quality setting)		
				PDF*		
				PDF/A		
				Secure PDF		
				Signed PDF		
				TIFF		
		Duplex Scan	_	Off*	Chooses the duplex	
				DuplexScan	scanning format.	
				:LongEdge		
				DuplexScan :ShortEdge		
		Glass ScanSize	-	A4	To scan an A4, Legal	
				Letter*	or Folio size document, you'll	
				Legal/Folio	need to change the	
					Glass Scan Size setting.	
		File Size	_	Small	You can choose the	1
				Middle*	file size for color or	
				Large	gray scale scanning.	
		File Name	_	BRNXXXXXXXXXX*	You can choose	
				Estimate	preset file names. If you choose	
				Report	<manual>, you can</manual>	
				Order sheet	name the file as you like.	
				Contract sheet		
				Check		
				Receipt		
				<manual></manual>		



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Scan to E-mail	Manual/	Quality		Color 100 dpi*		See ¹ .
	Address Book			Color 200 dpi	scan resolution and file format for your	
				Color 300 dpi	document.	
				Color 600 dpi		
				Gray 100 dpi		
				Gray 200 dpi		
				Gray 300 dpi		
				B&W 200 dpi		
				B&W 200x100 dpi		
		File Type	_	(If you chose a Color or Gray option in the Quality setting)		
				PDF*		
				PDF/A		
				Secure PDF		
			— (Signed PDF		
				JPEG		
				XPS		
				(If you chose a B&W option in the Quality setting)		
				PDF*		
				PDF/A		
				Secure PDF		
				Signed PDF		
				TIFF		
		Duplex Scan	_	Off*	Chooses the duplex	
				DuplexScan :LongEdge	scanning format.	
				DuplexScan :ShortEdge		
		Glass ScanSize	_	A4 Letter* Legal/Folio	To scan an A4, Legal or Folio size document, you'll need to change the	
					Glass Scan Size setting.	

¹ Software User's Guide



Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page	
Scan to E-mail	Manual/	File Size	_	Small	You can choose the	See ¹	
(Continued)	Address Book			Middle*	file size for color or gray scale scanning.		
	(Continued)			Large			
		Number of Destinations	-	_	You can add multiple destination E-mail addresses.		
		Set New Default	_	Quality	You can save your		
				File Type	scan to E-mail settings as the		
				Glass ScanSize	default settings.		
				File Size			
		Factory Reset	_	_	You can restore all scan to E-mail settings to the factory settings.		
Scan to PC	E-mail	_	_	_	You can scan a black & white or a color document into your E-mail application.		
	Image	_	_	_	You can scan a color picture into your graphics application.	-	
	OCR	_	_		You can have your text document converted to an editable text file.	1	
	File	_	_	_	You can scan a black & white or a color document into your computer.		

Software User's Guide



Other Functions

Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Direct Print	(Select File)	Print Settings/	Paper Size	A4	Sets the paper size	55
		(Copy Pages (001–999))		Letter*	when printing directly from the USB flash	
				Legal	memory drive.	
				Executive		
				A5		
				A5 L		
				A6		
				B5		
				В6		
				Folio		
			Paper Type	Thin	Sets the print media	55
				Plain*	type when printing directly from the USB	
				Thick	flash memory drive.	
				Thicker		
				Recycled Paper		
				Glossy		
				1in1*	Sets the page layout	55
				2in1	when printing multiple pages directly from the USB Flash memory drive.	
				4in1		
				9in1		
				16in1		
				25in1		
				1 in 2x2 pages		
				1 in 3x3 pages		
				1 in 4x4 pages		
				1 in 5x5 pages		
			Orientation	Portrait*	Sets the page	55
				Landscape	orientation when printing directly from the USB Flash memory drive.	
			Duplex	Off*	Chooses the duplex	55
			I	Long Edge	print format when print directly from the	
				Short Edge	USB Flash memory drive.	

¹ See Software User's Guide



The factory settings are shown in Bold with an asterisk.

The \mathtt{Direct} \mathtt{Print} button on the LCD becomes active when a USB flash memory drive is connected to the USB direct interface.

Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Direct Print (Continued)	(Select File) (Continued)	Print Settings / (Copy Pages (001–999)) (Continued)	Collate	On*	Enables or disables page collation when printing directly from the USB Flash memory drive.	55
			Tray Use	Auto* MP Only Tray#1 Only Tray#2 Only (Tray#2 Only appears only if you installed the optional paper tray.)	Chooses the tray when printing directly from the USB Flash memory drive.	55
			Print Quality	Normal* Fine	Sets the print quality option when printing directly from the USB Flash memory drive.	55
			PDF Option	Document* Document&Markup Document&Stamps	Sets the USB direct print setting whether to print comments (Markup) or stamps in the PDF file along with the text.	55
	Index Print	_	_	_	You can print a thumbnail page.	55
	Default Settings	Paper Size	_	A4 Letter* Legal Executive A5 A5 L A6 B5	Sets the default paper size when printing directly from the USB flash memory drive.	56
				Folio		

See Software User's Guide



The factory settings are shown in Bold with an asterisk.

The Direct Print button on the LCD becomes active when a USB flash memory drive is connected to the USB direct interface.

Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Direct Print	Default Settings	Paper Type	_	Thin Plain*	Sets the default media type when	56
(Continued)	(Continued)				printing directly from	
				Thick	the USB flash memory drive.	
				Thicker		
				Recycled Paper		
				Glossy		
		Multiple Page	_	lin1*	Sets the default page style when printing	56
				2in1	multiple pages	
				4in1	directly from the USB	
				9in1	Flash memory drive.	
				16in1		
				25in1		
				1 in 2x2 pages		
				1 in 3x3 pages		
				1 in 4x4 pages		
	1 in 5x5 pages					
		Orientation	_	Portrait*	Sets the default page	56
				Landscape	orientation when printing directly from	
					the USB Flash	
					memory drive.	
		Collate	_	On*	Enables or disables default page collation	56
				Off	when printing directly	
					from the USB Flash	
		Print Quality		Normal*	memory drive. Sets the default print	56
		TITHE QUALITY		Fine	quality option when	
				Fille	printing directly from	
					the USB Flash memory drive.	
		PDF Option	_	Document*	Sets the default USB	56
				Document&Markup	direct print setting	
				Document&Stamps	whether to print comments (Markup)	
					or stamps in the PDF	
					file along with the text.	
		Index Print	_	Simple*	Sets the default index	56
				Details	print option, simple	
					format or details.	

See Software User's Guide



The factory settings are shown in Bold with an asterisk.

The \mathtt{Direct} \mathtt{Print} button on the LCD becomes active when a USB flash memory drive is connected to the USB direct interface.

Level 1	Level 2	Level 3	Level 4	Options	Descriptions	Page
Secure Print	(Select User)	(Select Secure Print Job)	Password:	Print Delete	You can print data saved in the memory drive when you enter your four-digit password. (The Secure Print button on the LCD becomes active when there is secure data.)	See ¹ .

¹ See Software User's Guide



The factory settings are shown in Bold with an asterisk.

The Direct Print button on the LCD becomes active when a USB flash memory drive is connected to the USB direct interface.

Entering text

When you are setting certain menu selections, you may need to enter text into the machine.

Press repeatedly to choose between letters, numbers or special characters. Press change between upper case and lower case.



Inserting spaces

To enter a space, press the space key button or ▶.

Making corrections

If you entered an incorrect character and want to change it, use the arrow buttons to move the cursor under the incorrect character. Then press . Enter the correct character. You can also insert letters by moving the cursor and entering a character.



- The characters available may differ depending on your country.
- The keyboard layout may differ depending on the function you are setting.

Specifications

General



This chapter provides a summary of the machine's specifications. For additional specifications visit http://www.brother.com/ for details.

Printer Type Laser

Print Method Electrophotography by semiconductor laser beam scanning

Memory Capacity 256 MB

LCD (liquid crystal

display)

Touchscreen 5 in. (12.6 cm) Color LCD ¹

Power Source 110 - 120 V AC 50/60 Hz

Power Consumption ² Peak: 1200 W


Copying (Average): Approx. 615 W ³
Sleep (WLAN: On) Approx. 10 W


(Average):

Deep Sleep (Average): Approx. 1.8 W Ready (Average): Approx. 75 W

- Measured diagonally
- ² USB connection to PC
- When making a copy from one sheet

Dimensions





Weight With Consumables: 62.8 lb (28.5 kg)

D

Noise level Sound power

Operating LwAd = 6.94 B (A)

(Colour Printing):

Operating LwAd = 6.88 B (A)

(Monochrome Printing):

Ready: LWAd = 4.8 B (A)

Sound pressure

Operating (Printing): LPAm = 57 dB (A)
Ready: LPAm = 33 dB (A)

Temperature Operating: 50 °F to 90.5 °F (10 to 32.5 °C)

Storage: $32 \,^{\circ}\text{F} \text{ to } 104 \,^{\circ}\text{F} \text{ (0 to } 40 \,^{\circ}\text{C)}$

Humidity Operating: 20 to 80% (without condensation)

Storage: 10 to 90% (without condensation)

ADF (automatic document

feeder)

Up to 50 pages (Staggered) 20 lb (80 g/m²)

Document Size

 Document Size
 ADF Width:
 5.8 to 8.5 in. (147.3 to 215.9 mm)

 (Single-sided)
 ADF Length:
 5.8 to 14 in. (147.3 to 356.0 mm)

Scanner Glass Max. 8.5 in. (215.9 mm)

Width:

Scanner Glass Max. 14.0 in. (355.6 mm)

Length:

 Document Size
 ADF Width:
 5.8 to 8.5 in. (147.3 to 215.9 mm)

 (2-sided (Duplex))
 ADF Length:
 5.8 to 14 in. (147.3 to 356.0 mm)

Print media

Paper Input Paper Tray

> ■ Paper Type: Plain Paper, Thin Paper or Recycled Paper

Letter, A4, B5 (ISO/JIS), A5, A5 (Long ■ Paper Size:

Edge), B6 (ISO), A6, Executive, Legal and

Folio

■ Paper Weight: 16 to 28 lb (60 to 105 g/m^2)

■ Maximum Paper Tray Up to 250 sheets of 20 lb (80 g/m^2)

Capacity: Plain Paper

Multi-purpose tray (MP tray)

■ Paper Type: Envelope, Env. Thin, Env. Thick, Labels 1,

Glossy Paper, Thin Paper, Thick Paper,

Up to 50 sheets of 20 lb (80 g/m²) Plain

Thicker Paper, Recycled Paper, Bond Paper or Plain Paper

■ Paper Size: Width: 2.75 to 8.5 in. (69.8 to 216 mm)

> Length: 4.57 to 16 in. (116.0 to 406.4 mm)

■ Paper Weight: 16 to 43 lb (60 to 163 g/m²)

■ Maximum Paper Tray

Capacity:

Paper Tray 2 (option)

■ Paper Type: Plain Paper, Thin Paper or Recycled Paper

■ Paper Size: Letter, A4, B5 (ISO/JIS), A5, B6 (ISO),

Paper

Executive, Legal and Folio

■ Paper Weight: 16 to 28 lb (60 to 105 g/m²)

■ Maximum Paper Tray Up to 500 sheets of 20 lb (80 g/m^2)

Capacity: Plain Paper

Paper Output Face-Down Output Tray Up to 150 sheets (face down print delivery

to the Face down output tray)

Face-Up Output Tray One sheet (face up print delivery to the

Face up output tray)

Duplex Printing

Manual Duplex: YesAutomatic Duplex: Yes

■ Paper Size Letter, Legal and Folio

(Automatic Duplex):

■ Paper Weight 16 to 28 lb (60 to 105 g/m²)

(Automatic Duplex):

■ Paper Type Plain Paper, Thin Paper, Recycled Paper

(Automatic Duplex): or Glossy Paper

For labels, we recommend removing printed pages from the output paper tray immediately after they exit the machine to avoid the possibility of smudging.

Fax

Compatibility ITU-T Super Group 3

Modem Speed Automatic Fallback: 33,600 bps

2-sided (Duplex) Print Yes

Receiving

Automatic 2-sided (Duplex) Yes (from ADF)

Sending

Scanning WidthMax. 8.2 in. (208 mm)Printing WidthMax. 8.2 in. (208 mm)

Gray Scale 8 bit/256 levels

Resolution Horizontal: 203 dot/in. (8 dot/mm)

Vertical

■ Standard: 98 line/in. (3.85 line/mm) (Mono)

196 line/in. (7.7 line/mm) (Color)

■ Fine: 196 line/in. (7.7 line/mm) (Mono)

196 line/in. (7.7 line/mm) (Color)

■ Photo: 196 line/in. (7.7 line/mm) (Mono)

■ Superfine: 392 line/in. (15.4 line/mm) (Mono)

One Touch Dial $40 (20 \times 2)$ Speed Dial300 stationsGroupsUp to 20Broadcasting390 stations

Automatic Redial Yes. 1 time after 5 minutes

Memory Transmission Up to 500 ¹ pages ²
Out of Paper Reception Up to 500 ¹ pages ²

¹ 'Pages' refers to the 'ITU-T Test Chart #1' (a typical business letter, Standard resolution, JBIG code). Specifications and printed materials are subject to change without prior notice.

Black & White only

Copy

Color/Mono Yes/Yes

Copy Width Max. 8.3 in. (210 mm)

Automatic 2-sided (Duplex)

Copy

Yes (from ADF)

Multiple CopiesStacks or Sorts up to 99 pagesReduce/Enlarge25% to 400% (in increments of 1%)

Resolution Up to 1200×600 dpi

First Copy Out Time

(Monochrome)

Less than 19 seconds (from Ready mode and standard tray)

First Copy Out Time (Color) Less than 21 seconds (from Ready mode and standard tray)

Scanner

Color/Mono Yes/Yes

TWAIN Compliant Yes (Windows® 2000 Professional/Windows® XP/

Windows® XP Professional x64 Edition/Windows Vista®/

Windows® 7)

Mac OS X 10.4.11 - 10.6.x 1

Yes (Windows® XP/Windows Vista®/Windows® 7) **WIA Compliant**

ICA Compliant Yes (Mac OS X 10.6.x)

Color Depth 48 bit internal / 24 bit external color

Resolution Up to 19200×19200 dpi (interpolated) ²

Up to 1200 × 2400 dpi (optical) (from Scanner Glass)

Up to 1200×600 dpi (optical) (from ADF)

Scanning Width Max. 8.3 in. (210 mm)

Automatic 2-sided

(Duplex) Scanning

Yes (from ADF)

Gray Scale 256 levels

For the latest driver updates for the Mac OS X you are using, visit us at http://solutions.brother.com/.

Maximum 1200 × 1200 dpi scanning with the WIA driver in Windows® XP, Windows Vista® and Windows® 7 (resolution up to 19200 × 19200 dpi can be chosen by using the scanner utility)

П

Printer

Automatic 2-sided Yes

(Duplex) Print

Emulations PCL6, BR-Script3 (PostScript[®] 3™)

Resolution 600 dpi \times 600 dpi, 2400 dpi (2400 \times 600) quality

Print Speed Up to 14 sides/minute (7 sheets/minute)

(Monochrome Duplex) (Letter size) 1

Print Speed Up to 14 sides/minute (7 sheets/minute)

(Color Duplex) (Letter size) 1

Print Speed Up to 30 pages/minute (Letter size) 1

(Monochrome)

Print Speed Up to 30 pages/minute (Letter size) ¹

(Color)

First Print Out Time Less than 16 seconds (from Ready mode and standard tray)

(Monochrome)

First Print Out Time Less than 16 seconds (from Ready mode and standard tray)

(Color)

¹ The print speed may vary depending on the type of document you print.

Interfaces

USB It is recommended you use a USB 2.0 cable (Type A/B) that is no

more than 6 feet (2 meters) long. 12

Ethernet ³ Use an Ethernet UTP cable category 5 or greater.

Wireless LAN ³ IEEE 802.11 b/g (Infrastructure / Ad-hoc Mode)

Your machine has a Hi-Speed USB 2.0 interface. The machine can also be connected to a computer that has a USB 1.1 interface.

Third party USB ports are not supported.

See Network (LAN) on page 192 and the Network User's Guide for detailed network specifications.

Direct Print feature

Compatibility PDF version 1.7 ¹, JPEG, Exif + JPEG, PRN (created by Brother

printer driver), TIFF (scanned by all Brother MFC or DCP models), PostScript[®] 3[™] (created by Brother BR-Script 3 printer driver), XPS

version 1.0.

Interface USB direct interface

¹ PDF data including a JBIG2 image file, a JPEG2000 image file or a transparency file is not supported.

Scan to USB feature

File formats Black and white

TIFF, PDF, PDF/A, Secure PDF, Signed PDF

Color and Gray document

JPEG, PDF, PDF/A, Secure PDF, Signed PDF, XPS

Computer requirements

	Minimum	System Requirem	nents and	Supported	d PC Soft	ware Fund	tions	
Computer Operating		Processor Minimum Speed	Minimum RAM	Recommended RAM	Hard Dis	-	Supported PC	Supported PC
Version					For Drivers	For Applications	Software Functions	Interface ³
Windows [®] Operating System ¹	Windows [®] 2000 Professional ⁵	Intel [®] Pentium [®] II or equivalent	64 MB	256 MB	150 MB	500 MB	Printing, PC-Fax ⁴ , Scanning	USB, 10/100 Base Tx
	Windows [®] XP Home ^{2 6} Windows [®] XP Professional ^{2 6}		128 MB					(Ethernet), Wireless 802.11 b/g
	Windows® 64-bit (Intel®64 or XP AMD64) Professional x64 Edition ^{2 6}							
	Windows Vista ^{® 2 6}	Intel [®] Pentium [®] 4 or equivalent 64-bit (Intel [®] 64 or AMD64) supported CPU	512 MB	1 GB	500 MB	1.2 GB		
	Windows® Intel® Pentium® 4 or equivalent 64-bit (Intel® 64 or AMD64) supported CPU 1 GB (64-bit) 650 MB (64-bit) 650 MB (64-bit) 650 MB							

Minimum System Requirements and Supported PC Software Functions								
Computer Platform & Operating System		Processor Minimum Speed	Minimum RAM	Recommended RAM	Hard Disk Space to install		Supported PC	Supported PC
Version					For Drivers	For Applications	Software Functions	Interface ³
	Windows Server [®] 2003 (print only via network)	Intel [®] Pentium [®] III or equivalent	256 MB	512 MB	50 MB	N/A	Printing	10/100 Base Tx (Ethernet), Wireless 802.11 b/g
	Windows Server® 2003 x64 Edition (print only via network)	64-bit (Intel [®] 64 or AMD64) supported CPU						
	Windows Server [®] 2008 (print only via network)	Intel® Pentium® 4 or equivalent 64-bit (Intel® 64 or AMD 64) supported CPU	512 MB	2 GB				
	Windows Server [®] 2008 R2 (print only via network)	64-bit (Intel [®] 64 or AMD64) supported CPU						
Macintosh Operating System	Mac OS X 10.4.11 10.5.x	PowerPC [®] G4/G5 Intel [®] Core [™] Processor	512 MB	1 GB	80 MB	400 MB	Printing, PC-Fax Send ⁴ , Scanning	USB, 10/100 Base Tx (Ethernet), Wireless
	Mac OS X 10.6.x	Intel [®] Core™ Processor	1 GB	2 GB				802.11 b/g

¹ Internet Explorer[®] 6.0 or greater.

For the latest driver updates, visit http://solutions.brother.com/.

All trademarks, brand and product names are property of their respective companies.

² For WIA, 1200 x 1200 resolution. Brother Scanner Utility enables to enhance up to 19200 x 19200 dpi.

³ Third party USB ports are not supported.

⁴ PC-Fax supports black and white only. (Letter/A4 size)

⁵ PaperPort™ 11SE supports Microsoft[®] SP4 or higher for Windows[®] 2000. (Available from the Internet)

PaperPort™ 12SE supports Microsoft® SP3 or higher for Windows® XP and SP2 or higher for Windows Vista® and Windows® 7.

Consumable items

Toner Cartridge Life Starter Toner Cartridge:

Black Approx. 2,500 pages

(Letter or A4) 1

Cyan, Magenta, Yellow Approx. 1,500 pages

(Letter or A4) 1

Standard Toner Cartridge:

TN-310BK (Black): Approx. 2,500 pages

(Letter or A4) 1

TN-310C (Cyan): Approx. 1,500 pages

(Letter or A4) ¹

TN-310M (Magenta): Approx. 1,500 pages

(Letter or A4) 1

TN-310Y (Yellow): Approx. 1,500 pages

(Letter or A4) 1

High Capacity Toner Cartridge:

TN-315BK (Black): Approx. 6,000 pages

(Letter or A4) 1

TN-315C (Cyan): Approx. 3,500 pages

(Letter or A4) 1

TN-315M (Magenta): Approx. 3,500 pages

(Letter or A4) 1

TN-315Y (Yellow): Approx. 3,500 pages

(Letter or A4) 1

Drum Unit DR-310CL Approx. 25,000 pages

(Letter or A4)²

Belt Unit BU-300CL Approx. 50,000 pages

(Letter or A4)³

Waste Toner Box WT-300CL Approx. 50,000 pages

(Letter or A4)³

Approx. cartridge yield is declared in accordance with ISO/IEC 19798.

² Drum yield is approximate, and may vary by type of use.

Approx. yield is based on Letter or A4 single-sided pages.

Network (LAN)



For details about the full Network specifications, see Network User's Guide.

LAN You can connect your machine to a network for Network Printing,

> Network Scanning, PC-Fax Send, PC-Fax Receive (Windows® only) and Remote Setup 1. Also included is Brother BRAdmin Light 2

Network Management software.

Security Protocols

■ Wired APOP, POP before SMTP, SMTP-AUTH, SSL/TLS (IPPS, HTTPS,

SMTP, POP), SNMP v3, 802.1x (EAP-MD5, EAP-FAST, PEAP,

EAP-TLS, EAP-TTLS), Kerberos

■ Wireless APOP, POP before SMTP, SMTP-AUTH, SSL/TLS (IPPS, HTTPS,

SMTP, POP), SNMP v3

Wireless Network

WEP 64/128 bit, WPA-PSK (TKIP/AES), WPA2-PSK (AES), 802.1x Security

(LEAP, EAP-FAST, PEAP, EAP-TLS, EAP-TTLS)

AOSS™ Yes **Wireless Network Setup Support Utility WPS** Yes

See Computer requirements on page 189.

BRAdmin Professional and Web BRAdmin are available as a download from http://solutions.brother.com/.

Index

A
Accessories and suppliesi ADF (automatic document feeder) using
В
Belt unit replacing
Cleaning corona wires
See Software User's Guide. ControlCenter4 (for Windows®) See Software User's Guide. Cordless telephone (non-Brother)

Data Ident-A-Call	
a pause	46
automatic fax redial	45
manual	44
one touch	44
speed dial	44
using the Search	
Direct print	
Direct key	
specification	187
Distinctive ring	
choosing ring pattern	39
setting ring pattern	
turning off	
Document	
how to load	26, 27
Drum unit	,
cleaning	74
replacing	79
E	
Envelopes 14, 21,	22. 24
Equalization	
Error messages on LCD	
Comm. Error	
No Paper	
Out of Memory	
Print Unable XX	
Scan Unable XX	
Extension telephone, using	
External telephone, connecting	

F Labels12, 21, 22, 25 Fax codes LCD (liquid crystal display)6, 140 changing43 fax receive code43 telephone answer code43 М Fax, stand-alone Machine information receiving32 easy receive36 how to reset the machine 139 from extension telephone43 reset functions138 serial number 138 ring delay, setting35 Macintosh telephone line interference130 sending28 See Software User's Guide. telephone line interference130 Maintenance, routine replacing Fax/Tel mode belt unit 86 answering at extension telephones43 easy receive36 toner cartridge68 F/T ring time (double-ring)35 waste toner box92 fax receive code43 ring delay35 Manual telephone answer code43 dialing 44 Folio 18, 22 receive32, 34 Menu Table141 G Mode, entering copy 53 Gray scale 182, 184 scan 6 Multi-line connections (PBX)41 н **HELP** Ν LCD messages140 Menu Table141 Network faxing See Software User's Guide. printing See Network User's Guide. Ident-A-Call38 scanning See Software User's Guide. Ident-A-Ring38 Jacks One touch

changing 51

setting up 48

EXT

external telephone42

TAD (answering machine)40

P

Paper
how to load10
in paper tray10
in the multi-purpose tray12
recommended21, 22
size 18, 21
tray capacity22
type 18, 21
PaperPort™ 12SE with OCR
See Software User's Guide and Help in the
PaperPort™ 12SE application to access
How-to-Guides.
PC-Fax
See Software User's Guide.
Personalized Ring38
Presto! PageManager
See Software User's Guide. See also Help
in the Presto! PageManager application.
Print
difficulties 121, 125
drivers
quality
resolution
specifications185
Printing
See Software User's Guide.
Programming your machine140
Q
Quality
printing 127, 131
Quick dial48
Group dial
changing51
One Touch dial
changing51
custom scan profile48
setting up48
using44
Search45
Speed Dial
•
changing51
custom scan profile50
setting up50
using44

R

Redial/Pause key45, 46 Remote setup See Software User's Guide. Replacing	6
belt unit	9 8
Reports Transmission Verification	
Resolution	
copy183 fax (standard, fine, superfine,	3
photo)	
scan 184	
Ring delay, setting	
S	
Scanner glass	_
Scanner glass using	7
Scanner glass using	
Scanner glass using	.i
Scanner glass using	.i 8
Scanner glass using	.i 8
Scanner glass using	.i 8
Scanner glass using	.i 8 8

T

TAD (telephone answering device),		
external	32	, 34
connecting	40	, 41
recording OGM		
Teen Ring		
Telephone line		
connections		41
difficulties		
interference		130
multi-line (PBX)		
Text, entering		
Toner cartridge		
replacing		68
Troubleshooting		
document jam		
error messages on LCD		
if you are having difficulty		
copy quality		124
incoming calls		124
network		
paper handling		127
print quality		
printing	121,	125
receiving faxes		122
scanning		
sending faxes		124
software		
telephone line		
maintenance messages on LCD .		
paper jam 110, 111, 112,		
	,	

Voice Mail	 37
VoIP	 130

W

Warranties	
Canada	vi
Notice-Disclaimer	٠.i،
USA	٠١
Waste toner box	
replacing Windows [®]	92
Windows [®]	
See Software User's Guide.	
Wireless Network	
See Quick Setup Guide and Network	
User's Guide.	
World Wide Web	

EQUIPMENT ATTACHMENT LIMITATIONS (Canada only)

NOTICE

This product meets the applicable Industry Canada technical specifications.

NOTICE

The Ringer Equivalence Number is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.

Brother International Corporation 100 Somerset Corporate Boulevard P.O. Box 6911 Bridgewater, NJ 08807-0911 USA

Brother International Corporation (Canada) Ltd. 1 rue Hôtel de Ville, Dollard-des-Ormeaux, QC, Canada H9B 3H6



Visit us on the World Wide Web http://www.brother.com/

This machine is approved for use in the country of purchase only. Local Brother companies or their dealers will only support machines purchased in their own countries.